

ZENT-B60

MANUAL

Lampitude



1. The lamp must be installed in rated voltage and assure safety earth.
2. Installing and fixing the lamp should be processed by professional under the condition power off.
3. When change the lamp bulb please noted that the max wattage shouldn't exceed the labeled wattage.
4. If the external electrical wire damage please change by the professional in time in case of any danger.

Rated voltage: In accordance with the product labeled

Rated power: In accordance with the product labeled



CAUTION

In case of any doubt, please contact the qualified electrician.

