

We highly recommend you set failsafe feature while flying your models. An example of a useful Failsafe setting would be to shut down the model’s throttle, so that it does not fly or drive away uncontrolled.

LED status indicated under normal working status:

RED LED	GREEN LED	Status
solid	off	No signal searched
off	solid	Signal is very good
off	solid and flash	Signal is not very good
off	flash	Signal is weak



**RADTRON 2.4GHz Spread Spectrum
(FASST COMPATIBLE)
Receiver Instruction Manual(R8FA)**

Compatibility:

RADTRON 2.4GHz Spread Spectrum FASST Compatible Receiver is designed to use with FUTABA FASST 2.4GHz transmitters, such as TM7, TM8, TM10, TM14 or T6EX-2.4G, 7C-2.4G, 8FG, 10CG, 12FG, 14SG, 18MZ

Specifications:

Operating Current: 70mA @ FASST 7ch mode normal and 110 mA max,
80mA @ FASST multi-channel mode normal and 110 mA max
Operating Voltage: 4.0 ~8.4V
Latency: 14mS for low speed PPM (LS) @ FASST multi-channel mode
16mS for low speed PPM (LS) @ FASST 7ch mode
Sensitivity: about -98dBm

Setup:

Bind procedure:

- Turn on the FASST transmitter
- Connect the battery to the receiver while pressing receiver’s F/S button.
- The Dual-color LED’s continuous will cycle through the following:
 - o Red LED light (searching radio signal)
 - o Green LED light (acquired the radio signal)
 - o Red LED off (bind ok)
 - o Green LED flashes 10 times (ID store in memory)
 - o Green LED lights solid (normally operation)

Fail-safe setting:

There are two ways to set the Failsafe setting on the RADTRON 2.4GHz Spread Spectrum FASST Compatible Receiver;

1. TX-failsafe feature: This method is to set failsafe on the FASST transmitter and has priority (works on channel 3 only under FASST 7ch mode or on multiple-channels under FASST multi-channel mode) while the receiver is working on, just like the FUTABA receivers.
2. RX-failsafe feature: Turn on FASST transmitter and turn on

the RADTRON 2.4GHz Spread Spectrum Receiver, put all the sticks and switches to where give the control inputs you want if the receiver loses signal and Press the F/S button down for about 5 - 6 seconds while the Green LED light solid (Rx in normal operation), then release the button. You will see the Red LED will flash for about 4 - 5 seconds. (Note: The Red LED will FLASH high speed to indicate the RX-failsafe is turned on OR FLASH low speed to indicate the RX-failsafe is turned off). If you press the F/S button a second time while the Red LED is flashing, the receiver will change its RX-failsafe status (on / off),then the LED will return to Green solid again. If you not press the F/S button .Nothing will be changed and the LED will return to Green solid again. If you want to cancel the RX-failsafe feature (not just turn it off), you can do it by binding the receiver again.

Note: If you do not set a failsafe setting, the receiver will hold all controls at the position of the last command received before signal was lost. When RX-failsafe is turned on, the receiver will initiate the RX-failsafe settings after losing signal for over 1 second, the receiver will hold the last received positions until the failsafe takes over. When the RX-failsafe and TX-failsafe feature are both turned on, the receiver will use the TX-failsafe command.