



## **INSTRUCTION MANUAL      LAPCOUNTER-TIMER MODEL (LCT #90010, Blue Logo)**

### **GENERAL INSTRUCTIONS**

Congratulations on your SportCount Lap Counter & Timer (LCT) purchase! You will be able to count laps, keep track of elapsed time, and review summary statistics at the end of your workout. Your SportCount can be used for swimming, walking, running, cycling, in-line and speed skating, or any activity where you need to keep an accurate count and/or keep track of time. SportCount is easy to use. It's operated with one hand and doesn't interfere with the natural flow of exercise. You should take the time to try it before you jump into your exercise routine. Practice putting the LCT through its functions a few times. In most cases, you will want to wear it on your index finger (either the right or left hand may be used). Make sure it is oriented so you can comfortably reach the button with your thumb.

### **PRACTICE SESSION**

This section of the instructions takes you through a practice session. The figures illustrate what you should see on the display as you work through the paces.

### **POWER-UP**

Press the button with your thumb to start the LCT. On power-up, the display will show all "0's", which means that your LCT is ready to use



Fig. 1

### **TIMING AND COUNTING LAPS**

Press the button to start timing. The display will show running time (Fig. 2). Press the button again when the first lap is completed (Fig. 3). The lap number will show on the display for 7 seconds. The display will then show the Lap Split Time for the lap just completed for 5 seconds (Fig. 4), then the display will return to cumulative running time again. If the button is pressed within 10 seconds or less from the last press, the next lap number and time will be displayed without showing total elapsed time.




Fig. 2

Fig. 3

Fig. 4

### **TIMING OVER 1 HOUR**

When elapsed time exceeds 1 hour, the display shifts two digits, i.e., instead of displaying minutes, seconds, and hundredths of seconds, it will now display hours, minutes, and seconds. A black bar will appear over the two digits on the right to indicate that they now refer to seconds (Fig. 5). The LCT will time up to 99:59'59", after which the display will show 00'00.00 and start over. In Running Mode, if no button has been pushed for 24 hours, the LCT will go into sleep mode (the display goes blank to save battery life). All display data will begin to blink when the hours exceed 100.



Fig. 5

## SUMMARY MODE

Press the button at the end of your final lap (a regular quick press) and then, to finish the timed activity and go into the **SUMMARY** mode, press and hold the button for three seconds. You can do this immediately or even hours later. Your SportCount LCT "knows" that the time between the end of the final lap and the time you held the button down to go into summary mode was not a true lap, and it will automatically eliminate the "false lap" so that your workout statistics will be accurate. For example, if you completed 30 laps, and some time later held the button down to go into the summary mode, the LCT will display the "false lap" number 31, as shown in (Fig. 6). It will then discard the false lap data, and display the corrected total lap count, "T 30". In 1.5 seconds, it will automatically display the **TOTAL TIME**, and flip back and forth between **TOTAL LAP** count and **TOTAL TIME** every 1.5 seconds.

Push the button again to show the **AVERAGE LAP**, 1,10.02 in the Fig.7 example. **FASTEST LAP** number and **FASTEST LAP** time come next (Fig. 8), followed by. **SLOWEST LAP** number and **SLOWEST LAP** time (Fig.9). Pressing the button after this will start the summary over again with **TOTAL LAP** count and **TOTAL TIME**.




Fig. 6

Fig. 7

Fig. 8

Fig. 9

## RESET/TURN OFF

From the SUMMARY MODE, press and hold the button 3 seconds to **RESET** the LCT, and the display will once again return to zeros. But be careful, because when you reset your SportCount LCT, all lap times will be erased. When left in the reset mode for 30 minutes, the display will shut down automatically to conserve battery life. Press the button to re-activate.

## CARE FOR YOUR SPORTCOUNT

### WATER-RESISTANCE

All SportCount models are designed and manufactured to withstand the water pressure involved with normal swimming. After swimming, please be sure to wash the SportCount with fresh water and clean it with a dry cloth before storage.

### TEMPERATURE

Do not leave your SportCount under direct sunlight or in very high temperatures for a long time, or the display may darken. Do not leave your SportCount in very low temperatures as this may cause a slight time loss or gain. In both cases, the above conditions will be corrected when the SportCount returns to normal temperature.

## **SHOCKS**

Be careful not to drop your SportCount or hit it against hard surfaces as it may cause mechanical damage.

## **STATIC ELECTRICITY**

The integrated circuit in your SportCount can be affected by static electricity. Avoid touching electronic devices, and be careful of clothing made of synthetic materials in dry weather that might create a strong static shock,

## **CHEMICALS**

Do not expose your SportCount to solvents such as gasoline and alcohol, spray of cosmetics, cleaners, paints, etc., as they may cause damage to the SportCount.

## **BATTERY CHANGE**

When the display becomes dim or blank, battery replacement is necessary. We recommend you to go to a qualified technician or contact SportCount Inc. Replace with Lithium battery CR2016 or equivalent.

## **LIMITED ONE YEAR WARRANTY**

Your SportCount is warranted to be free from defects in material and workmanship for a period of one year from the date of purchase except as specified below. Within the warranty period, your SportCount will either be repaired at the Service Center or, at our discretion, replaced with a new or refurbished SportCount. This warranty does NOT cover the battery, crystal, or band. Warranty service will not be provided if:

- there was damage while in the possession of the consumer not resulting from a defect of manufacture
- there was damage caused by tampering with or opening the SportCount or by other than normal use

## **SERVICE OR REPAIR**

If your SportCount requires a service or repair, pack it securely and send it to:

**SportCount Australia  
29 Bolwarra Ave  
West Pymble NSW 2073**

## **QUESTIONS?**

Contact SportCount Customer Service by email at [info@sportcount.com.au](mailto:info@sportcount.com.au)  
You can also find useful information at the Website: [www.sportcount.com](http://www.sportcount.com)