

# lillagunga

## CLASSIC

USER'S MANUAL

ver. 1.4

READ THIS MANUAL CAREFULLY BEFORE INSTALLING  
AND USING YOUR LILLAGUNGA SWING.

**NOTE** This manual guides you through the installation and use of your Lillagunga Rings to a ceiling.

**NOTE** This product is intended for indoor use. Please refer to "outdoor use" for more information.

**NOTE** This package does NOT include curl hooks.

**NOTE** This product is intended for home use. The rings shall be used by one (1) person at a time.

**NOTE** This product is NOT intended for children under three (3) years of age.

**NOTE** The maximum permitted weight of a person using the swing is 60 kg.

**WARNING!** We do not take ANY responsibility for possible accidents or damage caused by failure or neglect to follow, or misunderstanding this manual.

## REQUIRED TOOLS

**Power drill and a drill bit**  
(type and size dependant on hook model)

**Pencil**

**Ladders, a tall chair or similar to reach the ceiling**

**A measuring tape**


**WARNING!** Don not place the swing near an open fire or other sources of strong heat, such as electric bar fires, gas fires etc due to the risk of fire.

**WARNING!** Avoid placing the swing over hard floor/ground materials such as asphalt, concrete or glazed tile. A shock-absorbing padding under the swing is recommended for use.

## INSTALLATION


1. Reserve at least two (2) meters in front/behind, and on both sides of the swing seat.
2. Use the ladders to reach the ceiling. Make sure that the ladders are stable and stand firmly, drilling vertically may distract your balance.
3. Use a measuring tape and mark two points at 56 cm apart from each other. Drill two holes, and screw the hooks into the ceiling.
4. Rotate the ends of the hooks pointing to the side, linear with the swing seat (fig. 2, the arrow indicating direction of swinging)
5. Make sure that both hooks are tightly in place.
6. Test before use.

**WARNING!** Ensure that the hooks will be attached to a bearing part of a ceiling. Consult an expert in uncertainty.



# ADJUSTING HEIGHT

1. Loosen the knot of the UPPER Rope lock by pulling up the rope (fig. 1). Do NOT adjust the lower rope lock.
2. Slide the rope block up and down to adjust (fig. 2)
  - a. To raise the swing: move the rope lock DOWN by sliding the looped rope (B)
  - b. To lower the swing: move the rope lock UP by sliding the looped rope (B)
3. Pass the loose end (A) back under the loop, and secure the knot by pulling the rope (B) from opposite directions (fig. 3).
4. On our web page ([www.lillagunga.com/pages/guides](http://www.lillagunga.com/pages/guides)) you can find a video that shows how to adjust the height of the ropes.



# MAINTENANCE AND SAFETY

**The swing shall be inspected once a month.**

- Frequently inspect all parts of the swing. In particular all rope locks, the swivels and the hooks shall be held under inspection as they may become safety risks if damaged or worn out.
- If a fracture (clearly visible to the eye) is identified in a rope lock, remove and replace it.
- Inspect the ropes by sliding your palm gently over the ropes. If the rope is damaged or torn, the braid may loosen up, and thus it becomes a safety risk.
- If a part gets worn out or damaged stop using the product immediately and replace it to a new original Lillagunga part.

## OUTDOOR USE

**This product is intended for indoor use. Outdoor use is at own responsibility with the following guidance:**

- The swing must always be placed under shelter, properly protected from rain.
- Sun and moisture will eventually cause changes in materials. These may appear as color changes, fractures or slight change in shape (particularly the wooden parts).
- Outdoor use weakens all parts and thus shortens the lifetime of the swing. As outdoor conditions are very varying our warranty applies only for indoor use.
- Always take the swing indoors when not in use.

### NOTE

This package does not include components or parts that enables the attachment of the swing to a tree or to branches.

## SAFETY IN MIND

**Safety shall always be taken very seriously.**

1. Do a routine check of the swing before use. See: "Maintenance"
2. Ensure that the swing height is adjusted right, and that the swing is in symmetric balance.
3. Avoid hard speeds and sideways swinging.
4. Do not swing with a child in your arms.

### NOTE

A careful use and maintenance of the swing according to this manual will extend the lifetime of the Lillagunga swing, and prevent possible accidents.

### WARNING!

**NEVER** leave a child unattended. A parent should always have visibility to the swing, and be within reachable distance from the swing.

## CONTACT

We are happy to assist you in all matters related to Lillagunga. We do our best to respond to all incoming emails within 24 hours at: [info@lillagunga.com](mailto:info@lillagunga.com)

### WARRANTY

INDOOR USE: 3 years on all wooden and metal parts, 2 years on ropes and leather parts. All related to material or workmanship defects.

This warranty does not apply to defects from normal wear and tear, product misuse, after market product alterations, or failure to follow instructions supplied with the product.

Uniq Works  
lillagunga.com

