



USER GUIDE - CHRONOGRAPH SERIES



USER GUIDE FOR THE CHRONOGRAPH SERIES

A) DISPLAYS AND BUTTONS


B) SETTING THE TIME

C) SETTING THE DATE

D) USING THE CHRONOGRAPH

E) CHRONOGRAPH RESET (INCL. AFTER REPLACING BATTERY)

A) DISPLAYS AND BUTTONS



B) SETTING THE TIME

1. Pull the crown out to the 2nd position so that the second hand stops at 0 position.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position in synchronization with a time signal, small second hand begins to run.

C) SETTING THE DATE

1. Pull the crown out to the 1st position.
2. Turn the crown to left to set the date.
 - * If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.
3. After the date has been set, push the crown back to the normal position.

D) USING THE CHRONOGRAPH

This chronograph is able to measure and display time in 1/20 second united up to maximum of 12 hours.

The chronograph 1/20 second hand keeps continuously for 30 seconds after starting, and then stops at 0 position.

Measuring time with the chronograph

1. Press button B to change the watch to the chronograph mode.
 - The second hand stops at the 0 position, and changes to the chronograph 1/20 second hand
2. The chronograph can be started and stopped each time button A is pressed.
 - The chronograph 1/20 second hand stops at the 0 position 30 seconds after starting,
 - When button A is pressed to stop the chronograph,
 - the chronograph 1/20 second hand advances rapidly to display the measured time.
3. Pressing button B resets the chronograph and all hands return to their 0 positions.

E) CHRONOGRAPH RESET (INCL. AFTER REPLACING BATTERY)

This procedure should be performed when the chronograph second hand and chronograph 1/20 second hand do not return to the 0 position after the chronograph has been reset, and including after the battery has been replaced.

1. Pull the crown out to the 2nd position.
2. Press button A to set the chronograph second hand to the 0 position.
3. Press button B to set the chronograph 1/20 second hand to the 0 position.

The chronograph hands can be advanced rapidly by continuously pressing button A or B.

4. Once the hands have been zeroed, reset the time and return the crown to its normal position.
5. Press button B to check that the chronograph hands are reset to the 0 position.

* Do not return crown to normal position while chronograph second hand and 1/20 chronograph second hand return to 0 position.

Each hands stop on the way when crown is returned to normal position and these hands position are recognized as 0 position.

These specifications might be changed without prior notice.