



iVision+ Connect

Purpose

This manual covers the basic to advanced operations for using the IVPC system. When installing the system, please refer to the settings and installation guide provided with each device. The goal of this manual is to help readers understand what is needed for their application. A simple home video intercom doorbell application may only need two devices (IVPC-DM or equivalent), whereas an office may wish to further expand their system to include multiple mobile stations (IVPC-MS or smartphones/tablets running the OPTEX Vision App) and a door interface (IVPC-DI).

Check the following overview sections to get started. Thank you for choosing OPTEX!

User manual EN

For details about each lineup, please visit www.optexamerica.com/security-products/ivpc-dm

IVPC-DM Door Station and Mobile Station

The basic set for the iVision+ Connect. When a visitor presses the doorbell button on the IVPC-DS, a notification is sent to the Mobile Station. Expandable to include multiple IVPC-DS/MS/DI or devices running the OPTEX Vision App.



IVPC-DS Door Station

Doorbell replacement adding video and audio communication when used with the IVPC-MS or a device running the OPTEX Vision App. Needed for use of the IVPC-DI.

0 0

IVPC-MS Mobile Station

Wi-Fi only Mobile Station for responding to visitors. Features live video and audio on a wide display.



<Optional> IVPC-ANT External Antenna

External antenna extension to avoid dead spots in the Wi-Fi coverage.



IVPC-DI Door Interface

Can be used as a door unlocking device and chime. Must be used in conjunction with IVPC-DS. Operates as a chime even when Wi-Fi is down.



<Optional> OPTEX Vision Smartphone/Tablet App

Substitutes the Mobile Station with your smartphone/tablet. Capable of answering calls out of Wi-Fi range using mobile data.



Dverview

Operations



Visitor Calling 6 p. Respond on the go with the OPTEX Vision App on your smartphone. Have a dedicated mobile station at the office with the IVPC-MS.





Answering a Visitor 7 p. See and converse with a visitor before opening the door.

Local network(IVPC-MS only)



Live View / Event List 8 p. Use your smartphone or IVPC-MS to get a live view from your IVPC-DS. Examine past event stored locally at any time.

* To use on a smartphone, search and install OPTEX Vision at App store or Google play.

Refer to page 2 & 3 of the SETTINGS AND INSTALLATION GUIDE.





Overview

Operations Appendix

Operations



A

Expand Your System 9 p.

Add more devices to meet your needs.



Door Unlock 9 p. You can unlock an electric lock with the optional IVPC-DI. Door unlock function is limited to one per IVPC-DS.

Appendix

- App Settings 10 p.
- Device Settings 11 p.
- Retrieving Images 12 p.
- Updates 13 p.
- Cloud Setting 13 p.
- Troubleshoot 14-15 p.

IVPC-DS Indicators



| *1 Low battery warning | : The battery has approximately a week of charge left. Please recharge soon. |
|---------------------------|--|
| *2 Low battery error | : The battery is completely drained. Please recharge immediately. |
| *3 Wi-Fi connection error | : Please check connection of IVPC-DS & Wi-Fi router. |
| *4 Device error | : Please contact a service provider. |
| *5 SD card error | : Please contact a service provider. |

Battery Charge

The IVPC-DS can be powered by batteries or wired. When battery operated, please charge regularly. The battery level of the IVPC-DS can be checked by looking at the top right corner of the live view or by the LED indicator on the IVPC-DS. The battery level symbol will be completely white when fully charged. *Caution: Please recharge only when temperature is 10 °C to 40 °C (50 °F to 104 °F).*



Charge with the included USB cable **

* If the IVPC-DS battery becomes low, it will automatically enter battery saving mode. This will disable the option to turn on the live view from the device list. Refer to page 8. After charging, the battery saving mode returns to OFF.

* In case of wired operation, the IVPC-DS does not charge the battery.

Visitor Calling

When a visitor presses the doorbell button on the IVPC-DS, a notification is sent to the IVPC-MS or the OPTEX Vision App. You can see the live view with (2), close with (2). All calls, whether they are answered or not, automatically record to the IVPC-DS microSD card as set in the device settings menu.



Answering a Visitor

Touch the **u** to turn the microphone on when speaking to a visitor. Touch the **u** to manually record videos. Touch the **o** to record a still image. Touch the **o** to unlock an electric strike or maglock. Touch the **o** to end the call. The same can be done by accessing the live view without an active caller as explained in the next page.



* You can select the recording time from (5/10/15/30/60 s) on the Device settings ** Optional IVPC-DI is required.



7

Live View / Event List

When you launch the IVPC-MS or the OPTEX Vision App, the Device List is displayed.

You can see a live view by touching the screen on the Device List.* You can check recorded videos and still

images from the Event List



Event List of recorded video and still image

* Wired Operation

It is always valid.

* Battery Operation

It is valid only when the battery saving mode is OFF and there is an internet connection. The default setting is battery saving mode OFF. However, if the IVPC-DS battery becomes low, the battery saving mode will be turned ON automatically. When the charging of the battery is completed, the battery saving mode returns to OFF. The battery saving mode can be switched ON/OFF with Device settings

Expand Your System* / Door Unlock

Additional users can join an existing system by adding IVPC-MS or downloading the OPTEX Vision App. Please reference the setup information provided by the installer when using the app wizard. One IVPC-DI per IVPC-DS can be assigned through the device settings menu to unlock an electric strike or maglock. All IVPC-DI per IVPC-DS can work as chimes, even if the Wi-Fi is down.

Maximum system structure

Operational image

IVPC-DI IVPC-DS IVPC-MS Max 6 per Max 4 per DS OPTEX MS or smartphone Vision App aл No limit*** IVPC-MS OPTEX Vision 2.4GHz Wi-Fi Route IVPC-DI ал IVPC-DS 4 A Door unlock Chimes at the visitor event **

- * An admin and device password (default 123456) is required. Refer to the instruction guide.
- ** 5 selectable chime tones by IVPC-MS or OPTEX Vision App.
 - 3 levels chime volume and mute by IVPC-DI button.
- *** Limit depends on the network capacity, not the IVPC system itself.

Appendix

App Settings

You can change the settings of the App from the Device List button

App settings

Front Door at a

IVPC-DI settings (Refer to next page)

existing device)

Add De

Device list edit (Change name or delete an

Device settings

(Refer to next page)

Notification

Enable or disable notifications on IVPC-MS or Android smartphone. iOS users must go to their smartphone settings to change this feature. Individual notification settings are not available; notifications are either ON or OFF for all paired IVPC-DS.

Device List



Video Hardware Acceleration (Android phone only)

By turning on the hardware acceleration function, improvement of drawing performance can be expected. However, it consumes a lot of memory. The default is ON.



About

You can check the version of OPTEX Vision.

Device Settings

The main customization settings of IVPC-DS are as follows. You can change them from Device Settings of Device List or Live View.* An admin password (default 123456) is required. Refer to the SETTINGS AND INSTALLATION GUIDE. Press 'Save' after setting and IVPC-DS may reboot. Do not manually restart the IVPC-MS or OPTEX Vision App.

Battery Saving



It is effective only when battery operated. Default setting is OFF. By setting it to ON, you can extend the battery life of IVPC-DS. (About 1 year @ 25 $^{\circ}$ C/77 $^{\circ}$ F) However, when the battery saving mode is ON, Live View only works when answering a visitor.



Device Sounds

You can change the volume of the IVPC-DS. Chime tone is fixed.



Device Edit

You can rename or delete devices that appear in IVPC-MS or OPTEX Vision App.



Unlock Settings

Select which IVPC-DI will activate its output relay for a selectable duration time. You can set from IVPC-DI settings . Refer to previous page.

* In case of battery operated, press the doorbell button to wake up IVPC-DS before entering the setting menu.

Appendix

Retrieve Image from IVPC-DS

Videos are stored on the memory card of the IVPC-DS. From the Event List or Event Play, you can download them to the IVPC-MS or a device running the OPTEX Vision App. UHS-1 microSD card (not included) can be used to save the videos and images off the IVPC-MS.



Updates

When you receive the Update message on IVPC-MS or OPTEX Vision App, please update according to the screen.



Appendix

Cloud Setting

You can transfer images stored in IVPC-DS to your registered cloud service.

It can be set from the device settings

If you want to remove cloud service, you will need to unbind from the IVPC-DS by going to the device settings - cloud settings - sign in - device management and click

| Conclusion C | 4 | Destine | 0.020 | < Advectation | | | | |
|---|---------------|--------------|--|-----------------------|-----------|-----------|---|---------------------|
| Just State J | - Contemp | | | The annually property | 140.00.00 | agis Bree | | e es suelles hadres |
| Annee Latings 2 Bangelichen Manneen Prose Bennee Annee Same Annee Same Annee Same | · Just Plater | 14 | | | | | | |
| Next Rengineer - Ren Rengineer - Rengineer Rengineer - Rengineer Rengin Rengineer Rengineer Reng | fecal betting | T. Bergidten | a first a | Tanan | | D | | |
| International and Annual An | Post Drogenet | 9. Balance | and the second s | | 2 | | | |
| | Invest States | - | - | Ches is take | 3 | | 2 | |
| 6 c 0 0 0 0 0 | | | | | | | | |

How to check the signal strength indicator using IVPC-MS or OPTEX Vision App



Troubleshoot

Chime does not sound / Audio is interrupted / No device or battery error indicated

Please check the signal strength between the IVPC-DS and Wi-Fi router. Signal strength can be confirmed with the IVPC-MS or OPTEX Vision App. If the signal strength is poor, please check whether there was any change in the installation environment from the time the IVPC was installed. (Example: Metal placed around IVPC - DS, changed location of the Wi-Fi router. Construction scaffolding was built around the building.) If you improve the installation environment, communication status will recover. If the cause can not be specified or can not be restored to the state at the time of installation, contact a service provider.

Troubleshoot options:

- Wi-Fi range extender (When the IVPC-DS and the Wi-Fi router are far away.)
- IVPC-ANT External antenna (When the IVPC-DS and the Wi-Fi router are close.)

IVPC-ANT External Antenna (optional)

The IVPC-ANT helps by providing an antenna at a position that avoids obstacles against radio waves such as walls and doors. The best communication is achieved by a direct open path between the communicating devices, in this case the Wi-Fi router and the IVPC-DS. For details please contact a service provider.

LED slow blinking (Blue & White & Off)

Please check connection of IVPC-DS & Wi-Fi router.

LED fast blinking (Blue & White)

IVPC-DS is faulty. Please contact a service provider.



LED fast blinking (White)

IVPC-DS SD card has encountered an error. Please contact a service provider.

Chime does not sound (LED OFF)

Power may not supplied to the IVPC-DS. Please charge the IVPC-DS.

Battery life of IVPC-DS is short

Check the setting of the battery saving mode with the IVPC-MS or OPTEX Vision App. By setting it to ON, you can extend the battery life of IVPC-DS. (About 1 year @ 25 °C/77 °F) However, when the battery saving mode is ON, Live view only works when answering a visitor.

Forgot admin password, device password

Check if the installer wrote down the passwords on the 2nd page of the IVPC DS and MS SETTINGS AND INSTALLATION GUIDE.

If the password was not written down, you may need to delete the device and pair again.

Change admin password, device password

Admin password and device password can be changed from the However, if you change the device password, you must also reset the device password for the IVPC-MS / Smartphone that is paired. The device password can be set from the transformer and th

Latest software

Download the latest software and IVPC-MS OPTEX Vision from the following URL. IVPC-DS navi.optex.net/firmware/50259/ IVPC-MS navi.optex.net/firmware/50260/



URL: www.optexamerica.com

OPTEX CO., LTD. (JAPAN)

URL: www.optex.net



Video and FAQ available:

optexamerica.com/resource/ivision-connect

Copyright (C) 2019-2020 OPTEX CO., LTD.

5927508

OPTEX INC. (U.S.)

Technical assistance: (800)966-7839