



Pellet Burner Quick Start Guide





⚠️ *Remove your scoop/cap.*



⚠️ *Keep your door on while lit unless adding or removing food.*



① *Fill your grate with 100% hardwood pellets to the level shown above.*

*If you are lighting using a blow torch, slide the grate back in to your burner and skip to step 4.*



② Place a natural firelighter at the lip of your grate.



③ Light the firelighter and slide the grate back in to your burner using the hopper lid handle. Place the hopper lid back on top of the hopper.

*Skip to step 5.*



④ If lighting using a blow torch, point the flame through the hole on the side of your burner. Hold it here for 30-45 seconds or until your pellets are alight.



⑤ Once your pellets are fully alight, gradually top up a little at a time.



⑥ Maintain a pellet level to approximately 3cm (1") below the top of your hopper throughout your cook. Use the bolt on the hopper as a level guide.

⚠ *If your pellets drop below this level, gradually top up as in step 5: adding too much at once can smother the flames and result in incomplete combustion.*

## Disposing of ash:

When you have finished cooking, allow your Uuni to burn through any remaining pellets. Once your Uuni has completely cooled, follow the steps below to dispose of any residual ash.

ⓘ Please note that pellets may still be warm and that heatproof gloves should be worn.



① While wearing heatproof gloves, carefully remove the grate using your hopper lid.



② Gently shake the ash in to a large metal bucket of water.

ⓘ Do not submerge or expose your Uuni grate directly to the water as this can cause damage.

If you have any questions, you can contact us at [support@uuni.net](mailto:support@uuni.net)