


## LIMITED LIFETIME WARRANTY & INSTRUCTIONS MANUAL



Please use the following instructions to set your watch. NOTE: The product image shown is for illustration purposes only and may vary from the watch you purchased.

### SETTING THE TIME

*NOTE: Never pull the Crown out when the watch is wet.*

1. Pull the Crown out to the **1st** click position when the second hand is at the 12 o' clock position. The second Hand will stop on the spot.
2. Turn the Crown to set the time, taking AM/PM into consideration.  
*NOTE: As the Hour Hand moves, the 24-Hour Hand moves correspondingly. When setting the Hour Hand, Check if the 24-Hour Hand is set Properly.*
3. When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.
4. Push the Crown back into the normal position to re-engage time keeping.

### SETTING THE DATE AND DAY OF THE WEEK.

1. Day Correction: press the button 'A', the Day Hand advances to the next day.
2. Date Correction: press the button 'B', the Date Hand advances one day.
3. While setting the Date and the Day Hands, check that they move properly in one day increments.

*NOTE: Do not set the Date and the Day hands between 9:00 PM and 4:00 AM otherwise, they may not move properly. It is necessary to adjust the date on the first day after a 30-day month and February.*

### CHANGING THE BATTERY

Change the battery when the watch becomes slow, the readout darkens or does not appear, or the backlight fails. Before removing the old battery, be sure to denote its polarity so that the new battery is installed in exactly the same way. Replace with the same kind of equivalent only. This watch contains precise electronic components and should only be opened by a qualified watch technician. However, it is not necessary return your watch to the manufacturer for battery replacement. It is recommended that you bring your timepiece to a local jeweler.

## LIMITED WARRANTY

This Armitron Watch is warranted to you, the owner, for your lifetime against all defects in material or workmanship. This warranty does not apply to normal wear and tear or abuse and excludes batteries, case, strap, crystal, or bracelet. In the event of a defect or malfunction of the movement within this period it will be repaired or replaced, at our option, provided that it is returned prepaid with a check or money order for \$9.95 to cover the cost of handling and return postage. This charge does not apply to California residents. (This is not a repair charge.) **DO NOT SEND CASH.** No additional charge will be made unless additional servicing is necessary for reasons beyond our control such as accident, misuse, neglect or replacement of parts not warranted is required such as case, crystal, strap, bracelet or batteries in which event a moderate charge will be made. The movement of any timepiece requires periodic cleaning/timing which is not a defect and, as such not warranted. After one year from the date of purchase each cleaning/timing will be performed as required without charging a fee in excess of the specified \$9.95 handling charge. The above remedy is exclusive. Armitron Adventure shall not be liable for any incidental or consequential damages. Should any other part of your watch require repair, please use our Service Center for quick and inexpensive repairs on your watch. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. In the event of a problem with warranty service or performance, you may be able to go to Small Claims Court, a State Court or a Federal District Court. **CALIFORNIA RESIDENTS ONLY!!** There is no handling charge for in warranty service. Charges apply only for **NON-WARRANTY ITEMS** such as cleaning after one year and other routine maintenance.

### WATER RESISTANCE

This is a WATER RESISTANT watch. Do not operate push buttons below the surface of the water. Should water or condensation appear in the watch, immediately have the watch checked. Water can corrode electronic parts inside the case.

### USE OUR NATIONWIDE SERVICE CENTERS. YOU CANNOT RETURN WATCH FOR SERVICE WHERE IT WAS PURCHASED.

If your watch requires cleaning, lubrication, battery changing, or needs a crystal replaced, Armitron approved Service Centers are available in your area. These repair facilities use Armitron parts and components to assure quality and future performance. Free estimates are available in advance, should you need servicing or repairs not covered under the warranty. Repairs covered under the warranty may require proof of purchase, so retain the purchase receipt.

### RETURN YOUR WATCH FOR SERVICING

Please call (718) 482-4195 for a listing of all approved and authorized service centers and locations, or visit our website at: [WWW.ARMITRON.COM](http://WWW.ARMITRON.COM)  
**YOUR WATCH SHOULD NOT BE RETURNED TO THE PLACE OF PURCHASE.**

Carefully pack your watch in a sturdy box (do not send in a gift box for same will not be returned) and mail to the nearest approved authorized service station. Because of possible loss, we recommend that you insure the watch, return receipt requested, when using the mail. If you do not receive a receipt within a reasonable time, start a tracer through the originating post office. Never include a special watch band or any other article of personal value in your shipment.