

## INSTRUCTIONS MANUAL

### FEATURES

- Time Telling Mode (Hours and Minutes)
- Calendar Mode
- LED Display

### SELECTING FEATURES

1. Press 'A' to display the Hour and Minutes. The time is displayed for 4-5 seconds.
2. While the Hour and Minutes are displayed, press 'A' again to enter the Calendar Mode. The Month and Date are displayed for 4-5 seconds.
3. While the Month and Date are displayed, press 'A' again to display the Seconds. The Seconds are displayed for 4-5 seconds.

### SETTING THE TIME AND CALENDAR


1. Press 'A'. While the Hour and Minutes are displayed, press and hold 'B' to enter the Time Setting Mode. The 12 Hour Format flashes. Press 'A' to select either 12 Hour or 24 Hour (Military) Time (0,00-23'59). When 12 Hour Format is selected, 'l' indicates 'p.m.' times; there is no indicator for 'a.m.' times.
2. Press 'B'. Hours flash. Press 'A' to advance the Hour. NOTE: Pressing and holding 'A' will advance digits rapidly.  
*NOTE: Pressing and holding 'D' will advance digits rapidly.*
3. Press 'B'. Minutes flash. Press 'A' to advance the Minutes.
4. Press 'B'. Seconds flash. Press 'A' to zero out the Seconds.
5. Press 'B'. The Year flashes. Press 'A' to advance the Year (2000-2059).
6. Press 'B'. The Month flashes. Press 'A' to advance the Month.
7. Press 'B'. The Date flashes. Press 'A' to advance the Date.
8. Press 'B' to end the set sequence.

### CHANGING THE BATTERY

Change the battery when the watch becomes slow, the readout darkens or does not appear, or the backlight fails. Before removing the old battery, be sure to denote its polarity so that the new battery is installed in exactly the same way. Replace with the same kind or equivalent only. This watch contains precise electronic components and should only be opened by a qualified watch technician. However, it is not necessary to return your watch to the manufacturer for battery replacement. It is recommended that you bring your timepiece to a local jeweler.

### WATER RESISTANCE

This is a **WATER RESISTANT** watch. Do not operate push buttons below the surface of the water. Should water or condensation appear in the watch, immediately have the watch checked. Water can corrode electronic parts inside the case.



**USE OUR NATIONWIDE SERVICE CENTERS. YOU CANNOT RETURN WATCH FOR SERVICE WHERE IT WAS PURCHASED.**

If your watch requires cleaning, lubrication, battery changing, or needs a crystal replaced, Armitron Adventure approved Service Centers are available in your area. These repair facilities use Armitron Adventure parts and components to assure quality and future performance. Free estimates are available in advance, should you need servicing or repairs not covered under the warranty. Repairs covered under the warranty may require proof of purchase, so retain the purchase receipt.

### RETURN YOUR WATCH FOR SERVICING

Please call **(718) 482-4195** for a listing of all approved and authorized service centers and locations, or visit our website at:

**WWW.ARMITRON.COM**

**YOUR WATCH SHOULD NOT BE RETURNED TO THE PLACE OF PURCHASE.** Carefully pack your watch in a sturdy box (do not send in a gift box for same will not be returned) and mail to the nearest approved authorized service station. Because of possible loss, we recommend that you insure the watch, return receipt requested, when using the mail. If you do not receive a receipt within a reasonable time, start a tracer through the originating post office. Never include a special watch band or any other article of personal value in your shipment.