



The latest MojoDesk hand control allows the option of setting upper and lower limits. These are useful if you want to avoid your desk bumping into something under or above your desk. These limits can be programmed on mistake by pressing multiple buttons at once. The instructions below show you how to program these limits and to clear them if you have done this on accident.

Setting Upper Limit :

1. Operate the system and stop at the preferred height of upper limit.
2. Press ▲ + ▼ together, and release ▼ in 3 seconds (before it goes to reset mode)
3. Keep holding ▲ for 5 seconds
4. Beep- setting completed!

Setting Lower Limit :

1. Operate the system and stop at the preferred height of lower limit.
2. Press ▲ + ▼ together, and release ▲ in 3 seconds (before it goes to reset mode)
3. Keep holding ▼ for 5 seconds
4. Beep- setting completed!

Clean Upper Limit:

1. Go the upper limit has been set
2. Press ▲ + ▼ together, and release ▼ in 3 seconds (before it goes to reset mode)
3. Keep holding ▲ for 5 seconds
4. Beep- cancellation completed!

Clean Lower Limit:

1. Go the lower limit has been set
2. Press ▲ + ▼ together, and release ▲ in 3 seconds (before it goes to reset mode)
3. Keep holding ▼ for 5 seconds
4. Beep- cancellation completed!