



# 7-DAY SINGLE OUTLET DIGITAL HEAVY DUTY GROUNDED TIMER INSTRUCTIONS

## SETTING THE CLOCK

Hold down the "CLOCK" button while pushing the "WEEK", "HOUR", and "MIN" buttons respectively to set the day of the week, hour, and minute. To set the seconds, hold down the "CLOCK" button and push the "ON/AUTO/OFF" button until the desired number of seconds is displayed.

## PROGRAMMING THE TIMERS

This timer has the capacity to hold 8 separate timer programs.

To set the first timer program press the "PROG" button once to access Program Mode and the screen will display "1 ON" in the bottom left corner. This indicates you are setting the time that Timer #1 will turn on. Press "HOUR" to set the hour you want the timer to turn on, "MIN" to set the minutes, and "ON/AUTO/OFF" to set the seconds. Press the "WEEK" button to set the day or days of the week that you want the timer to turn on. Press the "PROG" button again, and the screen will display "1 OFF". This indicates you are setting the time that Timer #1 will turn off. Use the "HOUR", "MIN", "ON/AUTO/OFF", and "WEEK" buttons again to set the time and day or days of the week that you would like the first timer to turn off.

Continue to press the "PROG" button to access the "on" and "off" times for all subsequent timer programs. You may have a maximum of 8 timer programs. Follow the above steps to set the "on" and "off" times for all other timer programs and to change the "on" or "off" times of any previously set timer programs.

## ON/AUTO/OFF MODES

In order for your timer programs to take effect, the timer must be in the "AUTO" mode. If you would like continuous power, regardless of timer programs, set the timer to the "ON" mode, and if you would like no power, set it to "OFF". In addition to setting the seconds when in Program Mode or Clock Mode, the "ON/AUTO/OFF" button also switches between modes. Press it repeatedly when on the main screen until your desired mode is displayed.

**NOTE:** If the timer mode is set to "ON", it must first be set to "OFF" before it can be switched to "AUTO".

## EXITING PROGRAM MODE

To exit Program Mode and return to the main screen, which displays the current day and time, simply press the "CLOCK" button once. The timer will also automatically return to the main screen after several minutes of inactivity.

## DEACTIVATING/REACTIVATING A TIMER PROGRAM

If you would like to deactivate a timer program without affecting your other current programs, press the "PROG" button until the "on" time is displayed for the timer program you wish to remove. Press the "R" button once and the time will disappear. Press the "PROG" button again to display the "off" time for that timer program, and press the "R" button again, and the "off" time will also disappear. Once both "on" and "off" times have been removed, the timer program has been deactivated. If you wish to re-activate a previously deactivated timer program, simply repeat the above steps and the times will reappear upon pressing the "R" button. Once the "on" and "off" times have reappeared, the timer program is active again.

**CAUTION:** Output loading should not exceed 1725W/15A

DISTRIBUTED BY



DL WHOLESALE  
DLWHOLESALE.COM