

Precautions

READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a convenient place for future reference.

Power Supply

Always use a DC 9V center negative AC adapter. Use of an adapter other than that specified could damage the unit or cause malfunction and pose a safety hazard. Always connect the AC adapter to an AC outlet that supplies the rated voltage required by the adapter. Disconnect the AC adapter from the AC outlet when during lightning storms or not using the unit for an extended period.

Connections

Always turn off the power before connecting or disconnecting. Make sure to disconnect all cables and AC adapter before moving the unit. This will help prevent malfunction and damages.

Environment Considerations

Avoid using the unit in any of the following conditions that could cause malfunction:

- Extremely hot or cold places
- Under direct sunlight
- Magnetic fields
- Near heaters and other heat sources
- Sandy or dusty places
- Places that are extremely humid or exposed to splashing water
- Places with lots of vibrations

Electrical Interference

Devices that are very susceptible to interference or that emits powerful electromagnetic waves (e.g. radios and TVs) should not

be placed near this unit, as interference could occur. Electromagnetic interference could cause malfunction and could corrupt or destroy data. Always operate this unit at a suitable distance from these devices.

Handling

Do not apply excessive force to the switches and other controls, exposing the unit to strong impacts, which could cause it to break. Do not put foreign objects or liquids into the unit. Never open the case or attempt to modify the product in any way since this can result in damage to the unit. Clean only with a soft, dry cloth.



www.donnerdeal.com



Owner's Manual

Introduction

Path Seeker is a dual-mode, fully-functional ABY switcher for amps/pedalboards signal routing. You can route your signal to either A/B outputs, or feed it to A and B together. Each output channel has independent volume control for signal mixing, and a 0°-180° polarity toggle is for signal phase correction.



PATH SEEKER

Overview

● Easy Controls

The Path Seeker features an easy-to-use interface: Each output channel has an independent volume control for detailed signal mixing, and LEDs under knobs indicate output channel working status.

● 2 Working Modes

This unit features two modes: A or B mode and A and B mode. You can select an output channel in A or B mode by tapping left footswitch, or select both in A and B mode by tapping right footswitch.

● Phase Correction

When you split your signal to two amps, sometimes it may cause phase cancellations, resulting a thin, hollow sound. If so, inverting the phase will help. In this case, you can use the toggle to invert the phase of channel B by 180° when necessary.

● Carefully Selected Components

The Path Seeker is designed and built with carefully selected components to ensure best sound quality and road performance. The solid Aluminum-alloy chassis ensures touring reliability.


Features

- Convenient compact size
- Buffer bypass
- Two output channels with independent volume control
- Polarity reverse toggle (OUT B) for output signal phase correction
- LED indicator shows working state
- Flexible design for a variety of scenarios

Specifications

Power Requirement: 9V DC center negative
Current Consumption: 5mA
Dimensions: 132x64x45mm
Weight: 235g
Material: Aluminum alloy

Connection & Controls



- A IN Jack:** 1/4" mono audio jack, for connecting instruments or other pedals.
- B 9V DC Jack:** For power supply, use a 9-volt DC regulated by AC adapter, 500mA (plug polarity is positive on the barrel and negative in the center).
- C OUT A/B Jacks:** 1/4" mono audio jacks, for connecting amps or other devices.
- D VOL A Knob:** Controls the output volume of channel A (OUT A).
- E VOL B Knob:** Controls the output volume of channel B (OUT B).
- Footswitches:** Use the footswitches to select an output channel or engage both output channels. This unit features two modes: A or B mode and A and B mode. In A or B mode, either LED will lit up to indicate current working channel; in A and B mode, all LEDs will lit up to indicate that all output channels are working.
- F A OR B Footswitch:** In A or B mode, tap the footswitch to toggle between A/B output channels.
- G A AND B Footswitch:** Tap the footswitch to engage/disengage A and B mode.
- H 0°-180° Toggle:** Switch to 180° to invert the phase of channel B by 180° when necessary. When you split your signal to feed two amps, sometimes it may cause phase cancellations, resulting a thin, hollow sound. If so, inverting the phase will help. Switching to 0° to keep the signal neutral.