



Single Press Wheel Instruction Manual

Here are some guidelines to help you correctly set up your Single Press Wheel for optimized performance.

Parts Included

1x Single Press Wheel Includes:

1x Wheel

1x Main Frame

1x Axle

2x M12 50 x 80 U-Bolt


1x M24 Nyloc Nut

4x M12 Nyloc Nut

2x Spacer

Step 1:


Put the axle through the hole and lay the main frame down.



Step 2:

Take one Bushing and place it over the axle.

*Tip: You can put anti seize inside the spacer to prevent it from rusting onto the axle.




Step 3:

Place the wheel onto the axle and then put the remaining spacer on.


Step 4:

Fasten on the M24 Nyloc Nut and tighten.
Do not over tighten.



Step 5 :

Bolt your Single Press Wheel to your bar
using the U-bolts provided.




BAR
EXTENSION

VERTICAL
BAR

We recommend 1 x
vertical/extension
bar set per 5 press
wheels.

*Recommendation only,
Some seeding bars
require different
configurations.



If you have any questions about installing your Single Press Wheel, please do not hesitate to give us a call on 08 9354 1111

Reorder Part No.

Part	Part No.
Wheel	SP-1100
M12 50x80 U-Bolt	FA-0702
M24 Nyloc Nut	FA-0406
M12 Nyloc Nut	FA-0403
Spacers	FA-0871

*For all other parts please see our website or price guide

www.maxipoint.com.au



Tel: 08 9354 1111

sales@maxipoint.com.au

HEAD OFFICE: 69-71 Catalano Circuit, Canning Vale 6155, WA