

# KLEVA RANGE™ SUMO SLICER™

## Slice, Grate And Shred In Seconds!

### USE AND CARE

Kleva Range Sumo Slicer™ is a multi-function kitchen tool with 3 interchangeable drums that can assist you to effortlessly prep food with just a turn of the handle.

You can easily make salads, breadcrumbs, cauliflower rice, coleslaw, potato chips, hash browns, pizza toppings and so much more.

⚠ Keep away from children. Blades are very sharp.

### FEATURES:

- Includes suction base, hopper, safety hat, crank handle and 3 easily interchangeable, high quality stainless steel drums: fine grater, super slicer, coarse shredder.
- The suction base allows you to slice, grate and shred effortlessly and safely on any smooth surface.
- Easy to take apart for cleaning.
- Stainless-steel drums are top-rack dishwasher safe.
- The BPA free ABS plastic with silicone suction base, hopper and hat are hand wash only in warm water.



### HOW TO USE:

- Install the hopper into the base by pushing it in until you hear or feel a "Click".
- Put the suction base on a flat, smooth, clean countertop, then lock by turning the grip lock clockwise.
- Install the stainless-steel drum into the hopper.
- Lock the drum into the hopper by attaching the handle to the base of the drum until it is tight.
- Put the food into the hopper and turn the handle while pushing down to use.
- Cut food into pieces that will fit into the hopper.
- Note: All blades are very sharp. Always ensure you use the safety hat.

### SPECIFICATIONS:

- |   |
|---|
| ▪ Material: Stainless steel, BPA-Free ABS plastic and silicone. |
| ▪ Size: H 25.4cm x W 13.2cm                                     |

### WARNINGS:

 **Keep away from children**  
Blades are very sharp

## Foods that work well with the Sumo Slicer™

FOOD	COARSE	FINE	SLICE
Potato	✓		✓
Sweet potato	✓		✓
Zucchini	✓		✓
Carrots	✓	✓	✓
Cauliflower	✓	✓	
Broccoli	✓	✓	
Pumpkin	✓		✓
Onions	✓	✓	✓
Cabbage	✓		✓
Capsicum			✓
Mushrooms			✓
Radish	✓		✓
Garlic	✓	✓	✓
Celery			✓
Cucumber	✓		✓
Apples			✓
Strawberries			✓
Pickles	✓		✓
Frozen fruit	✓	✓	✓
Coconut	✓	✓	
Herbs	✓	✓	
Nuts		✓	
Boiled eggs	✓		
Cheese	✓	✓	✓
Biscuits	✓	✓	
Chocolate	✓	✓	
Toast / bread		✓	
Sugar clumps		✓	



### Using your Sumo Slicer™

Slide the hopper into the suction base until you hear or feel a 'click!'

Place your Sumo Slicer™ onto a flat, smooth, clean surface, and turn the easy grip lock clockwise. This will stick it to the bench, and ensure the hopper is secure.

To remove the hopper, the base will need to be released by turning the easy grip lock counter clockwise.



### Handy Hat

The hat is designed to fit perfectly inside the hopper to ensure your hands never go near the blades. Place the shorter side closer to the handle to get the perfect fit

## Food that shouldn't be used in the Sumo Slicer™

- Tomato, leek, large chili, frozen meat, soft fruit i.e. banana, avocado etc.



### Hard, Root Vegetables

In order to slice, grate or shred hard vegetables like potato or pumpkin, you may need to pause and pulse the handle by pulling it backwards and forwards in short movements, similar to a pulse done by a food processor.



### Onions

For onions to be sliced or grated easily, ensure the skin side is facing in.



### Garlic

As garlic is a very sticky vegetable, ensure you slice or grate immediately. Once they go into the hopper, do not let them sit as they may clump together and clog the blade.

## Hints and Tips