

tend

LET'S
GET
STARTED

TEND
SECURE


LYNX INDOOR



01.

DOWNLOAD THE TEND APP


Download the Tend Secure app from the Apple App Store or the Google Play store. (Hint: search for "TendSecure")



02.

MOUNTING THE CAMERA

You can place your camera on a table top or mount it on the wall.



For detailed mounting instructions, please visit: www.tendinsights.com/lynx-indoor

03.

POWER YOUR CAMERA

Connect your Lynx Indoor to the micro-USB cable and then connect that into the power adaptor...then plug it all into an electrical outlet. Wait for the LED to flash green and amber (this may take up to 1 minute when the camera is first powered on).

04.

CONNECT YOUR SMARTPHONE OR TABLET TO LYNX INDOOR

Enable WiFi on your smartphone or tablet, as well as your home network. Open the WiFi settings on your smartphone or tablet, and connect to the network LynxIndoorXXXX (where XXXX are the last 4 digits of the camera's MAC ID, as seen on the back of the camera). Make sure you connect to a 2.4GHz router and not a 5GHz router.

RE-SETUP YOUR CAMERA

If you need to re-setup your camera, press the round button located on the bottom of the camera, connect your smartphone to the camera, and follow the setup steps in the app.

05.

LAUNCH THE TEND SECURE APP

Once your smartphone or tablet establishes its connection to Lynx Indoor (this can take up to 30 seconds) launch the Tend Secure app. The app will guide you through the rest of your camera set up process.

MOTION-TRIGGERED EVENT STORAGE

Your Lynx Indoor is capable of recording motion-triggered events, to give you peace of mind while you are away.

To store these events for up to 7 days, turn on "Event Recording" from your Tend Secure app.

To view recordings, click the Events tab in your Tend Secure app.

FACIAL RECOGNITION

Want to know when your children come home from school? Add a family member's picture to the Tend Secure app, and get notified every time he or she checks in.

To add a new profile, click on "Facial Recognition" in your Tend Secure app, then click on "Add new profile".

06.

CAMERA LED INDICATOR

GREEN:

Connected to Tend Servers

SOLID AMBER:

Disconnected from Tend Servers

SLOWLY FLASHING AMBER:

Not connected to the internet. Please check your home router or modem.

QUICKLY BLINKING AMBER:

Home network connection issue. Please check your home router or modem.

FLASHING AMBER AND GREEN:

Camera is not set up. Please follow the instructions in this manual to set up your camera.

For help or more information:
support@tendinsights.com
www.tendinsights.com/lynx-indoor