

WARRANTY INFORMATION

ALL CRUA OUTDOORS® PRODUCTS CARRY A LIMITED TWO-YEAR WARRANTY REFER TO OUR TERMS AND CONDITIONS AT WWW.CRUAOUTDOORS.COM.
EXCEPT FOR THE WARRANTY EXPRESSLY SET FORTH HEREIN, SELLER MAKES NO WARRANTY WHATSOEVER WITH RESPECT TO THE GOODS, INCLUDING ANY
(A) WARRANTY OF MERCHANTABILITY;
(B) WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE;
(C) WARRANTY AGAINST INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS OF A THIRD PARTY, WHETHER EXPRESS OR IMPLIED BY LAW, COURSE OF DEALING, COURSE OF PERFORMANCE, USAGE OF TRADE OR OTHERWISE.

For more information in English, go to www.cruaoutdoors.com

Pour consulter ces consignes et instructions de sécurité en français, veuillez visiter www.cruaoutdoors.com



Um diese Sicherheitsrichtlinien und Anweisungen in deutscher Sprache anzuzeigen, besuchen Sie bitte www.cruaoutdoors.com



Para ver estas pautas e instrucciones de seguridad en español, visite www.cruaoutdoors.com



ALL OUR LOCATIONS



www.cruaoutdoors.com

Crua Outdoors USA
2501 S Lemay STE 7 #432
Fort Collins, CO 80525
1-518-354-3987



SLEEP

Instruction Manual

- INCLUDES:**
Mattress (1)
Quilt (1)
Optional Items:
Airpoles (2)
Bug Mesh (1)
Culla (1)
Canopy (1)
Porch Poles (1)
Bag of Stakes (1)

EVERYONE WHO USES THIS TENT SHOULD READ THIS MANUAL AND BECOME FAMILIAR WITH ALL SAFETY WARNINGS AND PRECAUTIONS FOR SAFE USE, ASSEMBLY, CARE, MAINTENANCE, AND STORAGE. KEEP THIS MANUAL SO YOU CAN REFER TO IT LATER.

Failure to follow these directions can cause an unsafe situation leading to fire, burns, serious injury, permanent disability, or death to you or others.

FIRE, VENTILATION & GENERAL PRECAUTIONS FOR YOUR SAFETY

- Do not use gas or other combustion appliances anywhere in, or near your tent.
- Do not place hot appliances near the walls, roof or curtains.
- Always observe the safety instructions for these appliances.
- Never allow children to play near hot appliances.
- Make sure all ventilation openings on inner and outer tents as well as any Reflective Flysheets are open all the time to avoid possible suffocation.



Indicates an imminently hazardous situation which, if not avoided, may result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in property damage or injury.



FLAMMABILITY

Keep all flame and heat sources away from this tent fabric. This tent is not treated with flame-resistant chemicals, and is not fireproof. The fabric will burn if left in continuous contact with any flame source and could result in serious injury, permanent disability, or death to you or to others. **THIS TENT IS NOT FIREPROOF, for these reasons:**

- DO NOT spray the tent with insecticide.
- DO NOT use other than Crua Outdoors® recommended water repellent compounds on your tent.
- DO NOT use matches, lighters, stoves, heaters, grills, lanterns, candles, cooking equipment or any other fuel-burning devices, in or near the tent.
- DO NOT build fires in or near a tent.
- DO NOT leave campfires unattended.



CARBON MONOXIDE GAS WILL KILL YOU

Stoves, heaters, grills, lanterns, candles, and any other fuel burning devices that burn propane, natural gas, charcoal, kerosene, coal, or other fuel, produce a toxic gas called Carbon Monoxide. Carbon Monoxide is an invisible, odorless and colorless gas. A dangerous level can accumulate in a tent that cannot be detected by sight, smell or taste. When breathed in, even in small quantities, Carbon Monoxide is absorbed into the bloodstream, replacing, and reducing the oxygen in the bloodstream and causing Carbon Monoxide poisoning and suffocation which will cause serious injury, permanent disability, or death to you or to others.

For these reasons:

- DO NOT use matches, lighters, stoves, heaters, grills, lanterns, candles, cooking equipment or any other fuel-burning devices, in or near the tent.
- DO NOT build fires in or near a tent.
- DO exercise care when using electricity and lighting in and near your tent.



SEVERE WEATHER

In some climatic conditions (for example, severe storms, high winds, heavy snow) stakes and guy lines may not be sufficient to anchor a tent securely, which could result in the tent being picked up or blown away, which could cause serious injury, permanent disability, or death to you or to others.

Under such conditions:

- DO NOT use the Crua AER on the roof during severe weather.
- DO use supplemental means to anchor the tent if using the Crua AER on the ground.
- DO seek appropriate shelter, for example, in a house, cabin building or a secure structure during such severe weather.



SUFFOCATION HAZARD

Any tent must be properly ventilated in all weather conditions to allow sufficient airflow into and out of the tent. If airflow into and out of the tent is obstructed (for example, heavy snow or bedding/pillows covering vents) you and other persons will suffer from a lack of oxygen and suffocate resulting in serious injury, permanent disability, or death to you or to others.

For these reasons:

- DO clear snow or other materials away from any external vents frequently.
- DO ensure that bedding, pillows, backpacks, etc. are kept away from any internal vents.
- DO NOT use matches, lighters, stoves, heaters, grills, lanterns, candles, cooking equipment or any other fuel-burning devices, in or near the tent. (SEE CARBON MONOXIDE WARNING).



PROTECT YOUR CHILDREN

- DO NOT leave children unattended inside or around a tent.
- DO NOT allow children to set-up or take down a tent.
- DO NOT allow children to enter or exit a tent except through the door.
- DO NOT allow children to remain in a closed-up tent on hot days.
- DO NOT allow children to play with any plastic bags or other packaging material as there is a risk of suffocation. Your failure to follow this warning will cause death, serious injury or permanent disability to your children.



FOR YOUR SAFETY

Before using this product, read and fully understand:

- (1) Attached Warning Labels.
- (2) This instruction manual and all accompanying documentation.

KEEP ALL EXITS CLEAR



VENTILATION

Any tent must be properly ventilated in all weather conditions to allow sufficient airflow into and out of the tent. Please familiarize yourself with all vents and openings in your tent to ensure you can maintain adequate ventilation. There are three main reasons we promote ventilation within a tent, as in the same way we would in any dwelling like a house or apartment. These are Airflow, Air quality, and Condensation Reduction.

- **AIRFLOW:** Without airflow or fresh air into the tent, your environment will become stale and stuffy. It is important to promote good quality airflow throughout the tent.
- **AIR QUALITY:** A buildup of any harmful gasses (carbon dioxide, carbon monoxide, and others) is possible in an enclosed space. For this reason, you must always have adequate ventilation in your tent to ensure a good flow of air from outside.
- **CONDENSATION REDUCTION:** Leaving the vents open, supplemented by partially opening windows and doors at night to provide cross ventilation is a good way to reduce condensation.

Given the importance of proper ventilation, for airflow, air quality and condensation reduction, we use high and low venting in most of our tents. This allows cooler air in through the low vents and warmer, moist air up and out through the high vents. Opening both the high and low vents is important as this allows for this cross ventilation. If your tent has vents in the porch / vestibule, then it is important to also keep those vents open. Failure to vent your tent properly, may result in serious injury, permanent disability, or death to you or to others.



IN TRANSIT WITH YOUR ROOF TOP TENT

- DO, at the start of every journey and at regular intervals during every journey check that your roof tent is firmly fixed to your roof bars and the mounting brackets and all of the locking straps on the cover are securely fastened. Only ever check your roof tent in a safe and suitable location.
- DO NOT drive over 60mph (100km/h) while using your rooftop tent and that you always adhere to speed limits.
- Be aware that secured loads and incorrectly mounted roof bars can come loose during journeys and can cause serious accidents.
- The height of your vehicle can increase by up to 90cm (depending on your roof bars) Make sure that you give due consideration to the change in your vehicle height and driving behaviour (side-wind sensitivity, corner and braking behaviour).
- Be sure to check that you are using the AER within the safe limits of static and dynamic weights of your roof rack system.
- Beware of low entrances, bridges, low hanging branches etc.
- Wind noise may be generated when travelling with a roof tent.
- Remove your roof tent before using an automatic car wash facility.
- You must always consult your vehicle and roof bar manuals to ensure that you are following their advice, these must be always carried in your vehicle along with your roof tent safety and fitting instructions.
- For reasons of fuel economy and the safety of other road users, your roof tent and roof bars should be removed when not in use.



GENERAL PRECAUTIONS

- Make sure you know the fire precaution arrangements on the site.
- Consider the possibility of falling rocks or tree limbs, lightning, flash floods, avalanches, strong winds, and other potential hazards.
- Make sure you anchor your tent at all times.
- Please be mindful of guylines, bathtub floors, straps, and other parts of tents as they can be a potential trip hazard.

SET-UP


A. MATTRESS

- A1. Take out and organize all the contents from the carry bag.
- A2. Unroll the mattress. Open the valve at the bottom corner of the mattress to allow air to inflate the mattress. If the mattress does not feel firm enough for you, you can add more air by blowing or with the included pump.



B. AIR-POLES AND BUG MESH/CULLA

- B1. If you purchased the optional bug mesh and air-poles. Attach the bug mesh OR Culla by zipping it to the base.
- NOTE: You can only use the Culla or the Bug Mesh, but not both at the same time. The Culla has a built in bug mesh.
- B2. Un-roll the two air-poles and open the valve for inflation. The air-poles can be inflated by mouth, however, to achieve the correct PSI for the most stability, use the included pump to fill the air-poles.
 - B3. Once inflated, place the air-poles on the Velcro patches on either side of the mattress. The larger air-pole goes on the head end and the smaller on the foot end.
 - B4. Locate the toggles on the bug mesh or Culla and place the toggles through the loops on the air-poles.



C. THE CANOPY - CLOSED

- C1. Place the canopy over the base tent lining up the air-poles with the center seams of the flysheet.
 - C2. Stake down the head and foot first ensuring that the flysheet is centered appropriately.
 - C3. Stake down the rest of the guy points.
- NOTE: the guy points on the left and right side of the flysheet have an elastic rope on them. This is to make it easier for you to get in and out of the tent when using the flysheet.



NOTE: The Crua Canopy is reversible. Place the reflective side in if you want to direct heat into your tent. Place the reflective side out if you want to reflect the heat away from your tent.


D. THE CANOPY - OPEN

- D1. On the side you will be using as a porch, locate the two circular eyelets and place the included porch poles into the eyelet.
- D2. Tie a knot at the end of the two extra guy lines provided. Slip the knot over the porch pole and guy down each pole.



E. THE CANOPY - HAMMOCK

- E1. Find suitably spaced trees. You should look for trees that are roughly 15 ft (4.5 meters) apart. Your Canopy comes with adjustable straps, so there is flexibility on distance.
- E2. Wrap tree straps around the tree a minimum of 4.5 ft (1.3 meters) off the ground.
- E3. Pull the end with multiple attach points, through the single loop end. NOTE: based on the size of the tree or distance between trees, you may need to wrap the strap around the tree more than once.
- E4. Use the included carabiner to attach the tree strap to the webbing at either end of the flysheet.
- E5. If the hammock feels too saggy, try to move the carabiner up to the next adjustment point. Continue until you find the fit comfort level for you.



IMPORTANT

We make every effort to ensure the accuracy of our information. We do, however, have a policy of continuous improvement and we therefore reserve the right to change or amend designs and specifications without prior notice. Please refer to www.cruaoutdoors.com/pages/instructions for the most up-to-date safety setup and instructions.