


For suspender use attach the harness to a H160 by threading B into C. Double back the webbing for added security. (See the reverse side of this sheet for step-by-step instructions.)

Webbing "A" is only for attaching to a long lens case or tripod bag (see p. 2).

J-Shaped "movable snap-hooks" for attaching holster case. Some camera neck straps can hang from this too.

Sternum strap is vertically adjustable—it slides up and down.

Snap-hooks attach to D-rings on front of belt.



H344 is similar, but with less padding.

This end of the H160 attaches to the back center of your belt with a Slik Clip® buckle. Slip through the webbing loop near the top of belt and snap closed, otherwise the buckle will break.

The removable "wrap-around strap" on the optional H152/H153 Chest Adapter (see pix to the right) slips through this opening on the H160. Turn the snaphook sideways and squeeze through.

This set of metal figure 8s are for attaching "movable snap-hooks" for a holster case in backpack mode (see pix at the bottom of this page). Other figure 8's provide versatility in positioning the movable snap-hooks.

H245 or H250 Harness Applications

Suspender Mode

1. Assemble the front and back (B to C) of the harness as shown on the left-hand column of this sheet. The sternum strap buckle slides up or down vertically. The front of the harness snaps into the the pair of D-rings on the belt as shown. (H245 + H160 shown on model.)



2. Attach the back of the harness using the Slik Clip® buckle to the single webbing loop on the top center of the belt. Snap this buckle closed, otherwise the buckle may break.




For optimum comfort, adjust the harness so it is not touching your neck. If necessary, lengthen the front and shorten the back section to accomplish this.

Attaching Pouches to the Harness Front

The optional H150 Pouch to Harness adapter (sold in pairs) enables you to attach any Kinesis single-wide pouch to each side of the shoulder harness.

1. Remove the J-shaped "movable snap-hooks."
2. Slip the H150 Adapter into a pair of metal figure 8's with the attachment uniloops facing the harness.
3. Attach one or two small single-wide pouches to this adapter by bringing the TwinBuckles around the back side of the H150. (Double-wide pouches don't work.) You may find it easier to attach the pouch to the adapter first and then attach both of them to the harness.



Chest Harness Mode

The H717 harness provides a more comfortable fit compared to this configuration. Shown is the removable H153 kit attached to a harness. It is composed of two components: 1) a neck pad which Velcro's around the spreader bar of the harness (place the concave part of the pad facing your neck), and 2) a H152 "wrap-around" chest strap which is only used when a holster case is carried on your chest. It wraps around your body and clips into the lower D-rings found on all C-Series holster cases.



A holster case (C500 shown) hangs from the pair of J-shaped movable snap hooks found on the front of the harness. The H153 Chest Adapter is required to obtain four-point suspension as shown in this photo.

The harness can be used with or without a waistbelt. The webbing snap hook hanging from the front of the harness can be removed if you are not using a belt.



Carrying a Holster Case as a Backpack

The "movable snap-hooks" found on the front of the harness can be placed near the top of the harness (going the other direction). Attach to rear holster (C640 shown) case D-rings (shown), or for added stability, clip to the side D-rings. An "around the chest" strap is also helpful, such as the H152 strap. This configuration will work without the H160 back piece (if you are not attaching the harness to a belt) or with the H160 when using a belt.

