

eelo[®]

1885

USER GUIDE



CONTENTS

- Product Overview
- Package Contents
- How To Fold
- Modes of Operation
- Charger and Battery Information
- Maintenance
- Warranty
- Returns and Exchange
- Notices When Riding
- Precautions
- Warnings

PRODUCT OVERVIEW



PACKAGE CONTENTS

- 1 x Folding Bike
- 1 x Bike Computer
- 1 x User Guide
- 1 x Charger

HOW TO FOLD

1. Open the quick-release clamp on the seat post and push the seat all the way down.
Move the pedals to the 3/9 o'clock position. (See images 1 & 2)
2. Push inward and fold both pedals.
3. Unlock and release the handlebar stem quick-release clamp and fold the stem. (Images 2 & 3)
4. Unlock and release the Folding Clamp, fold the bike until both wheels are parallel.



BIKE COMPUTER

The eelo 1885 comes with a pre-attached bike computer that allows you to view your speed, battery level and distance travelled. For more information on your bike computer, please refer to its user guide.

MODES OF OPERATION

Hybrid Mode: Turn the power-switch ON, the motor will provide power assist when you pedal.

Manual Mode: Turn the power-switch OFF, and the eelo 1885 behaves and operates identical to an ordinary bike.

Electric Mode: Turn power-switch ON, use the throttle on the right handle to accelerate and control your speed.

CHARGER AND BATTERY INFORMATION

- Charge the battery in a well-ventilated environment. First, insert the charging plug into the charging socket beneath the frame, then connect the adapter to the power source.
- On average, it takes between 4 – 6 hours to fully charge the battery. When fully charged, the LED indicator on the adapter will turn from Yellow to Green. **DO NOT** charge the battery for more than 6 hours.
- After charging, disconnect the adapter from the power source first, then remove the charging plug from the bike. Do not leave the adapter plugged into the power source when not in use.

BATTERY CARE

- Do not over charge or fully drain the battery.
- Do not cover the charger or battery with anything when charging – doing so would create a risk of overheating and fire.
- Only use the charger supplied in the original packaging. The usage on an unapproved charger will void the warranty.
- You don't need to fully drain the battery before recharging it. Leaving a fully drained battery for a prolonged time will have a permanent, negative impact on battery life. Proper charging of the battery can maintain the battery capacity to a level of 85% after 5000 cycles. But due to the characteristics of the li-ion batteries, a decrease of the total capacity over the course of time is inevitable.
- Keep the battery away from direct exposure to the sun. If not using the bike for a long time, charge it at least once every 30 days.
- Do not short circuit the battery or it will create a risk of fire and will void the warranty.
- Always dispose of the battery according to local laws and regulations.
- Please contact our customer service team if you have any questions regarding the battery.

USING THE CHARGER

The charger supplied with the electric bicycle should be regularly examined for damage to the cord, plug, enclosure and other parts. In the event of such damage, the eelo 1885 must not be charged until the charger has been repaired by a suitable technician or replaced.

- Use only with supplied charger.
- Use caution when charging.
- The charger is not a toy. The charger should be operated by an adult.
- Do not operate the charger near flammable or hazardous materials. Always charge in a well-ventilated area.
- Unplug the charger and disconnect from eelo 1885 and main power source when not in use.
- Always disconnect the eelo 1885 charger prior to wiping down and cleaning your bike with a damp cloth.

MAINTENANCE

- Front and Rear wheel should always be aligned with the centre of the front and rear fork. Tension of each spoke should be similar so that there is no bouncing or oscillating of the wheel. There should be no missing or broken spokes. Wheels should have a smooth rotation - otherwise you risk serious injury or death.
- Your eelo 1885 is equipped with a high quality chain – please keep it clean and clear from foreign objects and make sure it is lubricated at all times.
- Check the brake pads regularly and have them replaced if they are worn. Please do not attempt to replace the brake pads by yourself – these should be replaced by a bicycle technician. Do not lubricate the wheel rim – this will impact the performance and risk injury.
- Check the tyres regularly for damage. Damaged or worn tyres should be replaced.
- Regularly maintain, clean and lubricate your bike. Please contact our customer service team if you have any questions.

WARRANTY

Please refer to our website www.eeloproducts.com/warranty for all warranty terms, conditions and how to make a claim.

RETURNS AND EXCHANGE

Please refer to our website www.eeloproducts.com/returns for all product and exchange information and procedures.

Please keep the original packaging for return shipping. The warranty does not include damage from shipping in inadequate packaging.

NOTICES WHEN RIDING

- It is essential that tyre pressures are checked regularly
Min 35 psi Max 85 psi (Min. 2.5 BAR. Max. 5.9 BAR)
- Actual mileage is affected by the battery level, tyre pressure, mode of operation and frequent turning OFF/ON of the system.
- Before riding, always check if the battery is sufficiently charged, tyre pressure is normal, and brakes are working properly. When braking, always use the rear brake first to avoid risk of injury.
- Always wear a helmet and other appropriate protective gear when using the eelo 1885.
- Obey local traffic rules.
- Use the head light when riding at night or in poorly lit areas.
- Never ride in snow/rain or on wet surfaces as these conditions will severely impact the braking performance. Riding in these conditions creates a risk of serious injury or death.
- This eelo 1885 is for riding on a paved road only – this is not an off-road vehicle and severe injury could occur if used off-road or on unpaved surfaces.
- Do not modify your eelo 1885 without consulting us first.

PRECAUTIONS

- If lending your eelo 1885 to others, please let the other user read this guide as well. This will reduce the chance for injury and accidents.
- Please wear a helmet and other suitable safety gear at all times and reflective or light-emitting gear when riding at night.
- Please do not exceed local speed limits.
- Please do not touch any of the power connectors or couplers with bare hands to avoid the risk of accidental electrical discharge.
- Full throttle starts, frequent braking, riding against the wind, riding with heavy loads and insufficient tyre pressure will cause more pronounced battery consumption and will affect electrical/hybrid use. In order to obtain optimum battery capacity, we advise that you:
 - Avoid full throttle starts and frequent braking (unless necessary).
 - Use manual mode when riding uphill or against wind.
 - Avoid heavy loads
 - Check and maintain proper tyre pressure regularly.
- Avoid prolonged exposure to sunlight or rain, avoid storing the bike in a high temperature / high humidity environment or near corrosive / hazardous materials. These may damage electrical components and can compromise the bikes performance.
- The eelo 1885 is not a toy! A person must be 16 years old to operate an eelo 1885. Always follow the local laws and regulations of your area when using this product.
- This guide may not cover every situation you may encounter using this product. For more information please contact our customer support team.

WARNINGS

We want you to be able to fully enjoy this bicycle. Please read this section carefully.

RIDE AT YOUR OWN RISK AND USE COMMON SENSE. FAILURE TO USE COMMON SENSE AND HEED THE WARNINGS BELOW ONLY SERVES TO INCREASE THE RISK OF SERIOUS INJURY AND/OR DEATH. USE AT YOUR OWN RISK AND WITH APPROPRIATE AND SERIOUS ATTENTION TO SAFE OPERATION. USE CAUTION AT ALL TIMES.

Using any electric bicycle presents potential risks/hazards – suitable caution and common sense is required at all times. There are inherent hazards associated with the use of this product (such as falling off). It is, of course, possible to lose control or otherwise get into dangerous situations even with taking all appropriate precautions. All riders and any person supervising them must recognise that a rider can be seriously injured or die even when using safety equipment and other precautions.

THIS BICYCLE IS NOT A TOY – IT IS A MACHINE CAPABLE OF SPEEDS UP TO 15.5 mph.

WARNING: PARENTAL AND ADULT RESPONSIBILITY AND SUPERVISION IS NECESSARY: because products, like electric bicycles, can and do present a potential hazards plainly associated with their use, it is well recognised THE NEED FOR EXERCISE OF PARENTAL RESPONSIBILITY IN SELECTING RIDING PRODUCTS APPROPRIATE TO THE AGE OF THE CHILD, OR PARENTAL SUPERVISION IN SITUATION IN WHICH CHILDREN OF VARIOUS AGES MAY HAVE ACCESS TO THE SAME RIDING PRODUCTS, IS IMPORTANT.

Not every product is appropriate for every person and the recommendations found within this section are intended to reflect the nature of the hazards which could be encountered during use and the expected mental or physical ability, or both, of a rider to cope with the hazards. The recommended minimum rider age is 16 and older. Any rider, regardless of age, who is unable to fit comfortably on the bicycle should not attempt to ride it. A parent's decision to allow his or her child to ride this product should be based on the child's maturity, skill and ability to follow rules.

Keep this product away from small children and remember that it is intended for use only by persons who are, at a minimum, completely comfortable and competent while operating the bicycle.

Persons with any condition (mental or physical) that may make them susceptible to injury, impair their physical dexterity or mental capabilities to recognise and follow safety instructions and to be able to understand the hazards inherent in bicycle use, should not use or be permitted to use this product. Persons with heart conditions, head, back or neck ailments (or prior surgeries to these areas of the body) should be cautioned not to operate such products. Pregnant women should never use this product.

DO NOT EXCEED THE WEIGHT LIMIT OF 100kg. Rider weight does not necessarily mean a person's size is appropriate to fit or maintain control of the bicycle.

CHECK AND MAINTAIN THE BICYCLE BEFORE EACH USE. Before each use, check to confirm that the bicycle frame is in good condition with no cracks or other breaks. Check that the brakes are functioning properly, that the tyres are securely fastened and rotate smoothly. The bicycle should be maintained and repaired in accordance with the manufacturer's specifications, using only that manufacturer's authorised replacement parts, and should not be modified from the manufacturer's original design and configuration.

THANK YOU FOR PURCHASING THE eelo 1885 Electric Bike

If you have any questions regarding your purchase or require assistance using the eelo 1885 please contact our friendly customer service team.

Phone: (+44) 0800 652 7780

Email: info@eeloproducts.com

Website: www.eeloproducts.com



eelo[®]

