

CACTUS™

KidoCall

Smartwatch phone
User manual



www.cactuswatches.com

Please read this manual carefully before starting to use the watch, and note that pictures are for reference only. Your KidoCall watch works in the same way as a mobile phone.

1. Preparation

A. Prepare a 4G LTE NANO SIM card and please turn the watch off (screen blank) before inserting the SIM Card. The SIM card needs activated data flow, GPRS and caller display functions. Charge the Kidocall fully using the USB cable provided.

B. Download the APP SeTracker or SeTracker2 to your mobile phone


C. Register and bind the watch

A. Layout and Inserting SIM card



SIM card size: Nano SIM card

How to install SIM card: SIM card chip facing up, notch facing in




B. APP Download

Scan the below QR code to download the APP SeTracker or SeTracker2 to your mobile phone. The APP QR code can also be found in the last screen interface of the watch >QR code>AppCode.




C. Register and Bind the watch

Once the APP download is completed, you will need to register a new account & enter a valid email address. Create a password and register. Note for Australia and New Zealand area is: Asia and Oceania. You will be prompted with a verification code - enter this code and register.



After the account is successfully registered, turn the watch on and bind the watch to the account using your phone's camera. The Registration QR code can be found in the last screen interface of the watch >QR code>RegCode. You will be able to fill in some details in the App about the child/wearer of the watch, such as a nickname and a photo. This is helpful if you have more than one KidoCall watch.

Note: The registration code will appear after the SIM card is installed and the watch is connected to the network for 3 minutes. If the SIM card is changed, please reboot the watch and re-bind the registration code of the watch. If inserting a different SIM card, the registration code will be different.



2. Product Functions

- GPS + AGPS + LBS +WiFi Location on Map
- Mobile phone APP or computer GPRS platform can control the watch.
- GPRS real-time locating, tracking and monitoring (Sound Guardian)
- Two-way Voice Calls
- Two-way Video Calls

- Messaging Voice Chat
- WiFi, BT
- Camera
- Phone book
- Class Schedule
- Class Mode - disable during class
- Connect with Friends
- Intercom - max 15 seconds voice clips
- Health - pedometer, distance, calories, sleep monitor
- Games
- Rewards
- Safe Zones
- SOS Emergency Call
- Multiple Alarms
- Low Battery Alerts
- Remote Shutdown
- IP67 water resistant - Splash proof for daily use; Not for Swimming


3. The Watch - Home Screen & Menu

Press the Power On / SOS button for 2 seconds to turn on your KidoCall watch. Swipe left and right to move from screen to screen. Tap on selected icon to open. Tap on home / back button to go back to the Home Screen. Swipe down from the top of the screen to see the battery level, wifi and 4G.

To send an SOS signal, hold the SOS button for 3 seconds and the watch will automatically dial the SOS numbers listed in the APP sequentially until answered. Your watch comes with several different designs for the Home Screen. To change, hold your finger on the centre of the Home Screen for 2 seconds, swipe left and right to access different Home Screen designs. Tap on the selected screen to set your choice.



Main Menu: Swipe right to access 1st screen



Contact: Tap this icon to see the 15 authorized contact numbers (added in the APP phone book), select and click / tap any of the numbers to call.

WeChat: Tap this icon to chat with the APP, hold to talk and send a voice clip or tap on the + to open the camera & take a photo. Tap on the ✓ to send the photo to the APP. Note that the watch cannot send text messages to the APP, while the APP can send text messages to the watch. Text must be initiated on the APP in WeChat

Phone: the watch can make calls call to any number. This function can be disabled in the APP - go to switch setting, dialing function off, save - this locks the dial keypad on the watch. The watch cannot receive calls from any number other than those authorized in the contact list.

Friends: to connect with friends who have KidoCall watches, both watches must simultaneously be open on the Friends interface, and within 10cm of each other; shake the 2 watches to add each other as friends; if successful a notification will ring and the animal picture will change colour. Once the 2 friends are connected,

click the animal pictures to send voice message and photos to each other. Hold the message to delete the chatting record. Hold the animal picture to delete / remove the friend.

Main Menu: Swipe right to access 2nd screen



Video Call: Tap this icon to see the authorized contacts (added in the APP>video call) select and tap to make a video call.

Camera: Tap this icon to take photos. All the photos are saved in the Gallery

Gallery: Tap this icon to check photos, press on an image to see a larger version, and delete. Photos can be shared with the APP. In settings>clear tools>file explorer>images, then share via Bluetooth pairing when APP is paired with Kidocall.

Childhood: Tap this icon to open Schedule or Math Schedule: Tap this icon to view the Monday to Friday schedule. The schedule is modified in the APP. Tap on the serial numbers 1/2/3 to set the time, and tap on the + to add the course name.

Math: Tap this icon, then click begin and start to play. The game is divided into 3 levels, Easy, Normal, and Hard. Can change the level in the setting on Game interface.

Main Menu: Swipe right to access 3rd screen



Settings: This is where you can view and set volume (for ring tone, media and alarms), screen brightness, screen dormancy time, launcher style (choose four for same interface as pictured above), set device time and date, check all related system information, wifi, network, device, software version, SIM card status and IMEI.

Connecting your device to WiFi can reduce your data bill and will allow you to send messages and make video calls when your mobile network coverage is poor. Clear tools>clear tasks>clear cache to free up memory when needed. File Explorer>do not delete any folders

Steps: Tap this icon to see your daily steps taken (this function must first be switched on in the App)

QR Code: Tap this icon to view AppCode and RegCode icons

Line: Register for Line chat and messages with other Line users that are on the authorized contact list (added in the APP phone book). Other numbers cannot access Line contact with the device.

4. The APP – Functions and Setup

Phone Book: Add up to 15 authorized numbers; these are the only contacts that can call or receive calls from the KidoCall watch. The phone book provides space for you to add a contact name and number.

Chat: You can send a voice clip, a short text message or emoticon, or a photo to the watch. Note that the watch cannot send text messages to the APP.

Call: You can make a voice call to the KidoCall watch.

Other Features:

Health: In the APP, fill in data on your child's weight and step size, and switch setting on for the pedometer to calculate steps taken, distance travelled and calories burned. You can also switch setting on for sleep monitoring. Health history is recorded daily and stored for the past 7 days on the APP.

Message: Receive SOS prompts and low battery prompts here.

Alarm Clock: You can set up to 3 different alarm clocks and the repeat frequency daily / weekly in the APP. When the alarm rings on the watch, you can either press dismiss or snooze.

Rewards: You can send rewards to the Kidocall watch; these will be shown as hearts on the face of the watch, together with a numerical value. Rewards can be cleared in the APP manually.

Remote Camera: You can send a command to the watch to initiate a photo remotely. The photo will be received on the APP; long press the photo to save or delete.

Timetable: You can modify the Monday to Friday schedule in the APP. Tap on the serial numbers 1/2/3 to set the time, and tap on the + to add the course name. This modifies the schedule on the watch.

Video Call: You can make a video call to the KidoCall watch.

SOS Number: in the APP you can enter 3 numbers that will be called when the SOS button on the watch is pressed for 3 seconds. The 3 numbers are called sequentially until one number is answered. Note: if the called number has an automatic answering function on voice mailbox, the watch considers the call as answered by the mobile phone and it will not continue to dial. The SOS button also sends a message to the APP and this notification will be received by the mobile phone.

Location Update Schedule: Control how often the watch sends you location updates. 3 modes, normal, power saving and sleep mode. The more often the watch sends tracking location updates, the quicker the battery on the watch will drain.

Sound Guardian: Through the APP settings, the watch passively dials the set number (usually the parent's number) and this provides the mobile phone one-way listening to the watch and its surrounds. This process has to be actioned each time by entering the number.

Family members: Shows all family member accounts that are linked to the KidoCall watch.

Do Not disturb / School Mode: 3 time periods can be set and the watch blocks all calls, notifications, alarms and sounds during these time periods. Valid from Monday to Friday. School Mode disables all features of the watch with the exception of the SOS function.

SMS Alerts: You can choose to have SMS alerts for low battery prompts and/or for SOS prompts sent from the watch to a pre-set mobile number. This will incur normal SMS charges. The SMS prompts are additional to the message prompts from the watch to the APP.

Set Local Base Station: When the base station is switched off, its location will not be transmitted to the APP, but WiFi or GPS location will be transmitted to the APP, so as to improve the accuracy of the positioning (see 6). Switching off LBS also saves on battery drain.

Watch Finder: Find my watch function.

Switch Setting: This is the partial function switch. In the APP, you can switch off the dialing function on the watch. This does not prohibit calls made from the watch to contacts in the phone book. In the APP, you can prohibit GPS positioning being communicated from the watch to the APP.

Timer switch: From the APP, schedule a reboot or a shutdown at specified times.

Language: can be selected in the APP

Time Zone: can be selected in the APP

Night Power Saving Mode: When switched on in the APP, this mode will disconnect the watch from the network between 10pm and 6am.

Shutdown the device: After the watch is turned on, it cannot be turned off accidentally or deliberately by pressing the power on button, and only the app can force the watch to shut down remotely.

Map: The Home Screen of the APP shows the position of the KidoCall on the map.

Safe Zones: You can set up to 3 safe zones in the APP and you will receive notifications if your child moves outside one of these areas. To add a safe zone, tap on the map in the home screen of the APP to enlarge it, tap on the icon for Geofence - this will open a map centered on the watch's last reported position. Tap the + symbol at the bottom of the screen. Tap where you would like the centre of the Geofence to be. Name the zone and adjust the radius (size of safe zone). Tap ok to set.

Tracking history: As well as showing your child's real-time location in the APP, you can view a history of all location data. Tap on the map in the home screen of the APP, tap on the icon for tracking history, and select the date at the top to view tracks.

5. Authorizing a Secondary Administrator

If a watch has already been registered, the first person to register is the main administrator. If you wish to add another trusted person (e.g. other parent) to bind the KidoCall to their APP, they will require the main administrator account to authorize this action. When the secondary administrator account binds the device, the interface notifies the applicant to wait for authorization. The notification is received by the primary administrator who can authorize the secondary administrator to manage the device.



6. Tracking Accuracy

Your KidoCall uses GPS + AGPS + LBS +WiFi for tracking. Positioning accuracy is 5-50M with GPS, 10-500M with WiFi, 100-1000M with LBS. GPS technology is not suitable for use indoors, or among high-rise buildings as GPS requires a direct line of sight between your GPS device and the sky (GPS satellites). This limitation is derived from the GPS network and not the device. Two alternative positioning technologies come into play when the GPS network is unavailable to communicate with the device - WiFi positioning and LBS positioning. These use radio waves and either mobile phone towers or WiFi hotspots to estimate the device's position. These systems are reliable indoors or in built-up areas, but are much less accurate. The APP informs you which technology is being used. On the map in the APP, you will see an address in a bubble and the APP will display either GPS, WiFi or LBS.

WARRANTY

This product is warranted to be free from defects in materials and workmanship for a period of one year from date of purchase. This warranty covers manufacturing and mechanical defects but excludes band and lens damage.

www.cactuswatches.com