

# Service Manual



## **TRM10<sup>1</sup>/GEN06** Treadmill

---

<sup>1</sup>TRM800 version 1 treadmills mfg. dates 2010 thru 2014.

# Contents

<b>Introduction</b> .....	<b>1</b>
Safety Guidelines .....	3
Safety guideline you need to know and follow: .....	3
<b>General Information</b> .....	<b>5</b>
Orientation .....	5
Tools .....	5
Parts .....	6
Lubrication .....	6
Cleaning Solutions .....	7
Electrical Requirements .....	7
Dedicated Branch Circuit .....	7
Input Power .....	8
Frame Ground .....	8
<b>Operation Verification</b> .....	<b>9</b>
Operation Verification Tests .....	9
<b>Standard Service Menus</b> .....	<b>12</b>
About .....	12
Service Access Codes .....	12
LED Consoles: P10, P30, P30i and P31 .....	12
Touchscreen Consoles: P62, P80, and P82 .....	13
How to Access the Service Menus .....	14
P10, P30, P30i and P31 LED consoles .....	14
P80 touchscreen console .....	14
P62 and P82 touchscreen consoles .....	15
Diagnostics menu access .....	16
Touchscreen Calibration shortcut .....	16
Debug Information Report shortcut .....	16

Navigating the Service Menus .....	18
P10, P30, P30i and P31 LED consoles .....	18
P10 and P30 consoles .....	18
P30i consoles .....	18
P80 and P82 touchscreen consoles .....	19
P62 touchscreen consoles .....	19
LED Console Standard Service Menus .....	20
Hardware Validation Diagnostics Tests Menu (51765761) .....	20
Club Settings Menu (5651565) .....	22
Information Display (65) .....	24
Touchscreen Console Standard Service Menus .....	26
Service Menus ( (51765761) .....	26
About menu .....	27
Equipment Usage menu .....	29
Maintenance menu .....	29
System Settings menu .....	31
System Tests menu .....	36
Club Settings (5651565) .....	37
Information Display (65) .....	37
<b>Adjustment Procedures .....</b>	<b>39</b>
Available Adjustment Procedures .....	39
Drive Belt Tension & Alignment Adjustment .....	40
About .....	40
Procedure .....	40
Lift Motor Calibration .....	43
About .....	43
Procedure .....	43
Running Belt Tension and Tracking Adjustment .....	45

---

About .....	45
Procedure .....	45
<b>Replacement Procedures .....</b>	<b>48</b>
Available Replacement Procedures .....	48
Auto Stop Magnet Replacement .....	49
About .....	49
Procedure .....	49
Auto Stop Sensor Replacement .....	51
About .....	51
Procedure .....	51
Circuit Breaker Replacement .....	53
About .....	53
Procedure .....	53
Drive Belt Replacement .....	55
About .....	55
Procedure .....	55
Drive Motor Replacement .....	59
About .....	59
Procedure .....	59
Drive Roller Replacement .....	62
About .....	62
Procedure .....	62
End Cap & Belt Guard Cover Replacement .....	66
About .....	66
Procedure .....	66
Incline Lift Motor Replacement .....	68
About .....	68
Procedure .....	68
Incline Lift Platform Replacement .....	71

---

About .....	71
Procedure .....	71
Input Module Replacement .....	73
About .....	73
Procedure .....	73
Line Filter Replacement .....	75
About .....	75
Procedure .....	75
Power Control Module Replacement .....	77
About .....	77
Procedure .....	77
Power Cord Replacement .....	79
About .....	79
Procedure .....	79
Running Belt and Deck Replacement .....	81
About .....	81
Procedure .....	81
Take-Up roller Replacement .....	86
About .....	86
Procedure .....	86
<b>Troubleshooting .....</b>	<b>88</b>
About .....	88
Introduction To Troubleshooting .....	88
Basic Steps .....	88
Validate the customer reported issue: .....	88
Verify the Input Power (Powered units only) .....	89
Verify that the console is operating correctly .....	89
Review the Error Log or CPA Event Log for any active error codes .....	90
Verify (reproduce) the issue. ....	90

---

Perform hardware validation diagnostic tests .....	90
Verify Club Settings .....	91
Verify that there are no new error codes .....	91
Verify service bulletins .....	91
Standard Error Codes .....	92
About .....	92
Viewing Error Codes (Error Log & Event Log) .....	93
Error Code and Troubleshooting Guide .....	93
Troubleshooting with Error Codes .....	93
Error Log & CPA Event Log .....	95
About .....	95
LED Console (P10, P30, P30i and P31) Error Log .....	96
Touchscreen Console (P62, P80, and P82) CPA Event Log .....	96
System Troubleshooting Procedures .....	99
Available Troubleshooting Procedures .....	99
Auto Stop Troubleshooting .....	100
Tripped Circuit Breaker .....	103
Communications Error Troubleshooting .....	106
No Power to the Console Troubleshooting .....	107
Drive Motor System Troubleshooting .....	108
E-Stop Not Communicating .....	111
Heart Rate Monitor Troubleshooting .....	112
Incline System Troubleshooting .....	115
Input Power and Machine Controls Troubleshooting .....	116
Running Belt and Deck Troubleshooting .....	117
Tripped Circuit Breaker .....	119
<b>Preventive Maintenance .....</b>	<b>122</b>
About .....	122
Maintenance Schedule .....	122

---

Precor Preventative Maintenance Plan .....	122
Running Belt and Deck Cleaning Procedure .....	123
<b>Theory of Operation .....</b>	<b>126</b>
About .....	126
Console Operation .....	126
Controls .....	126
Features .....	126
Treadmill Base Operation .....	128
System Diagrams .....	134
System Block Diagram - 120 VAC .....	134
<b>Parts .....</b>	<b>135</b>
Exploded View Diagram .....	136
Parts Identification List .....	141
<b>Appendix A : Edition Information .....</b>	<b>i</b>
Edition .....	i
Additional Documentation .....	i
Copyright .....	i
<b>Appendix B : Notices and Safety .....</b>	<b>ii</b>
Trademarks .....	ii
Intellectual Property .....	ii
Warranty .....	ii
Safety Notices .....	ii
Service Safety Guidelines .....	iii

## Introduction

If you are not a Precor certified servicer, you must not attempt to service any Precor Product. Call your dealer for service information.

**WARNING:** This service documentation is for use by Precor certified servicer providers only. Personal injury can result from electrical shock and/or mechanical moving parts.

### This service manual applies to the following treadmill models:

- GEN06 series treadmill (120 VAC<sup>1</sup> and 240 VAC models): The GEN-06 treadmill base is defined as any treadmill produced between April 2006 and April 2011. GEN-06 Treadmills include the following models; C952, C954, C956, and C966.
- TRM10<sup>2</sup> series treadmill (120 VAC and 240 VAC models): The TRM10 treadmill base is defined as any treadmill produced after April 2011 and is configured with a Pxx series console. All of the base and console combinations are part of the "Experience" line of products.



This document contains information required to perform troubleshooting and replacement procedures required to repair and maintain this equipment including: general product information, software diagnostic procedures, preventative maintenance procedures, inspection and adjustment procedures, troubleshooting procedures, replacement procedures and system block and wiring diagrams.

### Separate Base and Console Service Manuals

This document provides information to service the equipment base independent of the installed console. For console service documentation, refer to the particular console service manual.

### Additional Documentation

---

<sup>1</sup>voltage in an alternating current circuit

<sup>2</sup>TRM800 version 1 treadmills mfg. dates 2010 thru 2014.



There is also an online web version if you have internet access at: [Online Service Manual](#)

## See Also

"General Information" on page 5

"Safety Guidelines" on the facing page

"Operation Verification" on page 9

"Standard Service Menus" on page 12

"Adjustment Procedures" on page 39

"Replacement Procedures" on page 48

"Troubleshooting" on page 88

"Preventive Maintenance" on page 122

"Theory of Operation" on page 126

"Parts" on page 135

"Theory of Operation" on page 126

## Safety Guidelines



**WARNING:** Only Precor certified servicers and technicians are permitted to service Precor products. Personal injury can result from electrical shock and/or mechanical moving parts.

### Safety guideline you need to know and follow:

- Read and follow all **Warning** notices to protect yourself from personal injury.
- Read and follow all **Caution** notices to prevent damage to the equipment.
- Read the owner's manual and follow all operating instructions.
- Operate the equipment on a solid, level surface.
- Visually check the equipment before beginning service or maintenance operations. If it is not completely assembled or is damaged in anyway, do not attempt to operate the equipment.
- Never place liquids on any part of the equipment while performing service.
- To prevent electrical shock, keep all electrical components away from water and other liquids.
- Do not use accessory attachments that are not recommended by the manufacturer. Non-OEM accessories can cause injuries.
- Do not stand or climb on the handlebars, display enclosure or cover.
- On a self-powered unit, it will either be necessary to either equip the unit with the optional external power supply or have an assistant pedal on the unit while voltage measurements are being taken. Because of the danger of working on the unit while it is in motion using the optional external power supply is strongly recommended.
- On ATM units when the stairarms are in motion; the generator will operate and produce potentially hazardous voltages even when the battery is disconnected.
- On **AMT**<sup>1</sup> units with Cardio Theater **PVS**<sup>2</sup> units will have external power supply and coaxial cable routed through the bottom of the unit to the top of the display console. Cord management must be maintained
- On ATM units, a pinching hazard exists when the unit is operated. It is possible to seriously pinch a finger. The AMT can be mechanically locked by inserting a screwdriver through the primary sheave and frame.
- On treadmills, removing the hood exposes high voltage components and potentially dangerous machinery. Exercise extreme caution when you perform maintenance procedures with the hood removed.

#### When servicing the equipment:

---

<sup>1</sup>Adaptive Motion Trainer

<sup>2</sup>Personal Viewing System display.

- During service operations you will be very close to moving machinery and voltage bearing components:
  - Remove jewelry (especially from ears and neck),
  - Tie up long hair,
  - Remove neck ties, and
  - Do not wear loose clothing

### **See Also**

---

"Notices and Safety" on page ii

"Safety Notices" on page ii

## General Information

The following information provides general equipment and service information that will help you to use this manual to properly repair and maintain the treadmill.

### Orientation

The equipment orientation (front, right, left, back) used in manual is referenced to a user standing on the equipment facing the console.



### Tools

General set of service and repair tools.

- US and Metric Hex Key set
- US SAE and Metric Wrench set
- **Torque**<sup>1</sup> wrench
- US SAE and Metric socket set
- Running belt tension gauge (pn PPP00000002000710)
- Standard and Philips screw driver set
- DVM Multimeter
- Crank Puller (recommended Park Tool CCP-22)
- Belt Tension Gauge (recommended Kent-Moore BT-33-73-F)

<sup>1</sup>Torque is a measure of the force that can cause an object to rotate about an axis. Bolt/nut example: 5 nM torque is equivalent to 5 newtons of force applied one meter from the center of the bolt, 6 ft-lb is equivalent to 6 lb of force applied 1 foot away from the center of the bolt.

## Parts




**IMPORTANT:** Always purchase OEM replacement parts and hardware from Precor. If you use parts not approved by Precor, you could void the Precor Limited Warranty. Use of parts not approved by Precor may cause injury.

### Exploded View Diagram and Parts List

There is a copy of the parts *Exploded View Diagram* and *Parts Identification List* included in the "Parts" on page 135 chapter that you can use as a quick reference. It is recommended that you go to the servicer partners [Precor Connect](#) (or [Precor Connection](#)) website to view the most current parts information including the *Exploded View Diagram* and *Parts Identification List*.

- [Precor Connect Partner](#) website



Exploded View Diagram and Parts list, see "Parts" on page 135.

---

## Lubrication

Use only NLGI class 2 PTFE (Teflon) synthetic type grease (recommend Mobil 1<sup>®</sup> synthetic grease or Super Lube<sup>®</sup> with Teflon grease, or equivalent). Use of unapproved lubricants, cleaners, or solvents may void the product warranty.



**CAUTION:** Do not apply any lubricants or wax to the deck and belt. Do not use Wax Blast, silicon sprays, or other applied lubricants. The use of these lubricants will quickly degrade the low-friction surface of the deck.



**CAUTION:** Do not use petroleum based lubricants on mechanical components such as the lift, as this may result in degradation of nylon gearing mechanisms. Use only synthetic lubricants such as "Super Lube with Teflon" or "Mobile One Synthetic" grease (RED).

Use of unapproved lubricants, cleaners, or solvents may void the treadmill warranty.

## Cleaning Solutions

Wipe down equipment with recommended cleaning solution. Use dry cloth to remove residue solution.

- **General:** 1 oz. mild soap (Simple Green) to 30 oz. water.
- **Console and PVS<sup>1</sup>:** a diluted solution of one part 91% Isopropyl alcohol to one part water.



**CAUTION:** Do not use acidic cleaners and do not spray directly onto the equipment surfaces.

---

## Electrical Requirements

### Dedicated Branch Circuit

It is required that the treadmill be connected to and operated on a dedicated 20 amp **AC<sup>2</sup>** branch circuit. A Dedicated Branch Circuit is defined as a circuit fed by a single circuit breaker feeding a single load, with a single non-shared neutral providing a return line. A treadmill operating from a non-dedicated branch circuit or a circuit breaker of less than 20 amps capacity will not have the necessary power to operate normally under higher load conditions.

### 120 Vac Systems

120 **VAC<sup>3</sup>** distribution systems utilize a single pole circuit breaker (power lead) and a neutral lead connected to a common neutral (ground) bar. The AC. safety ground (green wire) is connected to a separate ground bar in the distribution system.

If it is determined that any of the above electrical conditions are in question, please consult with a qualified electrician to make appropriate circuit changes.



**CAUTION:** The treadmill requires a 20-amp individual branch circuit grounded per NEC (National Electric Code) guidelines or local region electric code.



**IMPORTANT:** If the AC circuit feeding a treadmill is found to be a non-dedicated branch circuit or a circuit equipped with a capacity of less than 20 amps, the AC circuit must be corrected before any reliable Troubleshooting can be performed. More importantly, a non-dedicated branch circuit may constitute a safety hazard to the treadmill operator.

---

---

<sup>1</sup>Personal Viewing System display.

<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

<sup>3</sup>voltage in an alternating current circuit

## Input Power

Nominal 120 VAC models

- Operating voltage: 90 VAC to 132 VAC.
- Frequency: 47-65 Hz<sup>1</sup>

Nominal 240 AC Models

- Rated Operating voltage: 180 VAC - 264 VAC.



**NOTE:** An Internal operating voltage range of 180 - 275 VAC with reduced performance is allowed.

- Frequency: 47-65 Hz

## Frame Ground

For operator safety and to minimize electrostatic discharge conditions the AC frame ground continuity must also be verified to be a low resistance connection to the AC distribution ground bar.

---

---

<sup>1</sup>The hertz (symbol: Hz) is the derived unit of frequency in the International System of Units (SI) and is defined as one cycle per second.

## Operation Verification

This section provides a method to verify that the machine is operating correctly and can be returned to service. Do these operation verification tests at the end of a maintenance procedure or whenever it is necessary to ensure that the machine is operating properly.

### Operation Verification Tests

#### Error Code Verification Test

Verify that there are no current active logged error codes:

1. Access either the Error Log (or **CPA**<sup>1</sup> Event Log) and record any current active logged error codes:
  - On P10, P30, P30i and P31 LED consoles, Press & hold down the PAUSE/RESET key for 6 seconds minimum to access the Error Log.
  - On P62, P80, and P82 touchscreen consoles, access Service menu (51765761), select **About > CPA Even Log**.
2. Resolve any current active logged error code issues.
3. Delete resolved error codes:
  - On P10, P30, P30i and P31 LED consoles, clear the Error Log, see "[Error Log & CPA Event Log](#)" on page 95. Press and hold the **PAUSE/RESET** key for 6 seconds minimum to access the Error Log. If there are no logged error codes, the "Stuck Key" message will show. To remove an error code, press/hold down the **QUICK START** key until the "NO ERRORS" message shows.
  - On P62, P80, and P82 touchscreen consoles, error codes cannot be deleted from the CPA Event Log)

#### Console Verification Tests

Verify the LED console or touchscreen console operation.

##### **LED consoles (P10, P30, P30i and P31) only**

1. Access the Diagnostic/Test menu (51765761) and run the following tests:
  - **KEYPAD TEST**: Select KEYPAD TEST and follow prompts to run test.
  - **DISPLAY TEST**: Select DISPLAY TEST and follow prompts to run test.
2. Exit the Diagnostic Test menu (press the **PAUSE/RESET** key).

##### **Touchscreen consoles (P62, P80, and P82) only**

1. Access the Service menu (51765761) and perform the following console System Tests (**Settings > System Settings > System Tests**):

---

<sup>1</sup>Touchscreen console Control Processing Assembly.



- **Touchscreen Calibration:** Follow screen prompts to complete test. When the test is completed the console will automatically exit and return to the System Tests menu.
- **Touchscreen Test:** Verify that there is a trace created that follows your finger movement across the touchscreen surface. Select **Finish** to exit. move your finger and verify that a trace follows
- **Backlight Test:** Tests the display backlight brightness. Follow prompts to complete test.
- **RGB Test:** Touch the screen to cycle through the test colors: Red, Green, Blue, White, & Black. Returns to the System Tests menu when completed.
- **Numeric Backlight Test:** Tests the controls numeric display brightness. Returns to the System Tests menu when completed.
- **Numeric Display Test:** Tests the controls numeric display. Returns to the System Tests menu.

2. Exit the Diagnostic Test menu. (press **Back** to exit & return to the banner screen)

#### **Motion Controls Test**

Verify the machine operation.

1. Select **QUICKSTART** to begin a manual workout and operate the treadmill at least 5 minutes. While walking on the unit perform the following tests:
2. Operate the **SPEED** motion control from minimum to maximum range while verifying the machine operation.
  - Make sure that the console **SPEED** paddle control operation is smooth and working correctly.
  - Verify that the running belt can reach the maximum speed and then returns to the minimum speed level.
  - Make sure that the running belt speed change is smooth and that there are no unusual noises.
  - Verify that the console **SPEED** indicators and workout displays are showing correct information.
3. Operate the **INCLINE** motion controls from minimum to maximum range while verifying the machine operation.
  - Make sure that the console **INCLINE** paddle controls operation is smooth and working correctly.
  - Verify that the running deck can reach the maximum incline and then return to the minimum incline level.
  - Verify that the lift motor operation is smooth while changing the **INCLINE** from minimum to maximum levels.
  - Verify that the console **INCLINE** level indicators and user workout displays are showing correct information.

#### **Running Belt Test**

Verify the running belt alignment and tracking.

1. Step off the running belt and operate the treadmill at 12 mph (19 kph) for one minute.
2. Verify the running belt alignment is centered and tracking.

**ESTOP Switch Test**

Verify the ESTOP emergency switch operation.

1. While walking on the treadmill, press the **STOP** emergency button and verify that the running belt immediately slows to a stop.
2. While walking on the treadmill, pull the **ESTOP** lanyard and make sure the running belt immediately slows to a stop.
3. Inspect the condition of the **ESTOP** lanyard clip, that the spring is in place and that the clip will firmly hold when attached.

**Heart Rate Test**

Verify the Hand Held Heart Rate (**HHHR**<sup>1</sup>) monitor operation.

**LED consoles (P10, P30, P30i and P31) only**

1. Access the Diagnostic menu (51765761) and run the following test:
  - **HEART RATE TEST**: Select HEART RATE TEST and follow prompts run test.

**Touchscreen consoles (P62, P80, and P82) only**

1. Access the Service menu (51765761) and run the following test.
  - **HEART RATE TEST**: Select HEART RATE TEST and follow prompts run test (System Tests (select **System Settings** > **System Tests**)).

Verify the wireless heart rate monitor operation.

1. Use a wireless heart rate monitor chest strap (pn PPP000000038819103 or **ANT+**<sup>2</sup> wireless compatible **HR**<sup>3</sup> chest strap) and verify that the console heart rate icon is flashing and the HR indicator is showing the heart rate beats per minute (bpm).

**Return to service**

1. Switch the power OFF.
2. Make sure that the machine is setting level and stable.
3. Make sure that any external power cords or interface cables are properly routed, connected, and safe from being damaged.
4. On successful completion of all verification tests, return to service.

---

<sup>1</sup>Hand Held Heart Rate

<sup>2</sup>ANT+ (pronounced ant plus) is a wireless protocol for monitoring sensor data such as a person's heart rate or a bicycle's tire pressure

<sup>3</sup>Heart Rate

# Standard Service Menus

## About

The Standardized Service Menus are supported across Precor cardio product lines designed to allow servicers and clubs to manage, configure/setup, and maintain/test the equipment: The service menus are grouped into functional service categories depending on the console type as follows:

- |   |   |
|---|---|
| <p><b>LED Consoles</b><br/>(P10, P30, P30i and P31)</p> <ul style="list-style-type: none"> <li>• Hardware Validation (51765761)</li> <li>• Club Settings (5651565)</li> <li>• Information Display (65)</li> </ul> | <p><b>Touchscreen Consoles</b><br/>(P62, P80, and P82)</p> <ul style="list-style-type: none"> <li>• Service Menu (51765761)</li> <li>• Club Settings (5651565)</li> </ul> |
|---|---|

On LED consoles, there are three service menus grouped by function; the Hardware Validation menu provides a set of automated diagnostic tests used to troubleshoot, calibrate, and verify machine operation, the Club Settings menu is used to configure the equipment workout settings, and the Information Display menu provides information about the equipment hardware, software, usage, and error log data.

On touchscreen consoles, there are two service menus; one intended for service technicians (the Service menu) and one intended for club operators (Club Settings menu). The Service Settings menu provides access to all available equipment service menus used by service technicians to service and maintain the equipment. The Club Settings menu is a subset of service menus directed toward club operation used by club operators to manage, configure, and maintain the equipment.

Each service menu is assigned a unique service access code. To access a service menu, type in the access code at the service menu login, see "[Standard Service Menus](#)" above.

## Service Access Codes

### Service Access Codes

#### LED Consoles: P10, P30, P30i and P31

SERVICE ACCESS CODE	SERVICE MENU	FUNCTION
51765761	Hardware Validation	Set of automated diagnostic tests used to troubleshoot, calibrate, and verify machine operation.

SERVICE ACCESS CODE	SERVICE MENU	FUNCTION
5651565	Club Settings	Used to configure the club specific workout, console and maintenance reminder settings.
65	Information Display	Used to access the equipment usage, hardware, software, error code, and maintenance information.







**Touchscreen Consoles: P62, P80, and P82**

SERVICE ACCESS CODE	SERVICE MENU	FUNCTION
51765761	Service Menus	Service Menu access code provide access to all available equipment service menus used to service, configure, test, and maintain the equipment including the legacy Information Display, Club Settings, and Hardware Validation Diagnostic Tests menus.
5651565	Club Settings	Club Settings access code is a subset of service menus directed toward club operation, used by club operators to manage, configure, and maintain the equipment.

Note: Service access code 65 "Information Display" is not used on touchscreen consoles.

## How to Access the Service Menus

### P10, P30, P30i and P31 LED consoles

		<i>Menu access:</i>	Press & Release
	Press & Release		Type in the Access
P10 Console		<b>PAUSE</b>	
	Press & Release		Type in the Access
P30 Console		<b>PAUSE</b>	
	Press & Release		Type in the Access
P30i Console		<b>PAUSE</b>	

**NOTE:** Press/hold **PAUSE/RESET** to quickly access Error Codes.

Steps:

- On P10/P30 consoles: Press the **PAUSE** hardkey and immediately use the keypad to type in the access code.
- On P30i consoles: Press the **PAUSE** hardkey and immediately use the **INCLINE** number keys to type in the access code.

---

### P80 touchscreen console

P80 Console



**Menu access:**




Steps

1. Make sure the P80 is set to the Welcome home page.
2. Press and hold the **Pause** key while pressing **CH up >VOL down > VOL up > CH down**:
3. Use the touch keypad to type in the service access code.

---

## P62 and P82 touchscreen consoles

## Diagnostics menu access



### Steps

1. Make sure the console is set to the Welcome banner.
2. Press and hold the **VOL down** key while pressing **CH up > CH down > CH down > CH up**:
3. At the Sign-In screen, type in the service access code.

## Touchscreen Calibration shortcut

Console shortcut to access the **Touchscreen Calibration** test.

### Steps

1. Make sure the console is set to the Welcome banner.
2. Press and hold the **VOL down** hardkey while pressing **CH up > Pause > Pause > CH up**:
3. Touch the designated display positions and follow prompts to complete the touchscreen calibration.

## Debug Information Report shortcut

Console shortcut to download an event log debug information report.

### Steps

1. Make sure the console is set to the Welcome banner.
2. Insert a **USB**<sup>1</sup> flash drive into the Chin USB port.
3. Press and hold the **VOL Up** hardkey while pressing **CH up > CH Dwn > CH Dwn > CH up**:
4. Wait for the download to finish and then remove the USB drive.

**IMPORTANT:** Do not remove the USB drive until the "Report was successful" message is shown, (approx. 1 min).

---

---

<sup>1</sup>Short for Universal Serial Bus, is an industry standard developed in the mid-1990s that defines the cables, connectors and communications protocols used in a bus for connection, communication, and power supply between computers and electronic devices.



## Navigating the Service Menus

### P10, P30, P30i and P31 LED consoles

LED console service menus are organized in a sequential top-menu to sub-menu item architecture. Select the top level menu and sequentially navigate through the sub-menus until the particular item is found. Then return to the top-level menu to select a different menu item. Refer to the following tables for console hardkey and keypad functions.

#### P10 and P30 consoles

CONSOLE KEY	FUNCTION/DESCRIPTION
<b>Up/Down</b>	Scrolls up and down through the current menu.
<b>OK</b>	Selects the current menu item or confirms settings.
<b>BACK/CLEAR</b>	<ul style="list-style-type: none"> <li>• Returns to the previous menu level without saving changes.</li> <li>• Hold <b>Back</b> to exit the <b>Display</b> test.</li> </ul>
<b>PAUSE</b>	<ul style="list-style-type: none"> <li>• Exits service mode</li> <li>• Press and hold PAUSE for greater than 6 sec will open the Error Log or show the "Stuck Key" message when there are no logged errors.</li> </ul>
<b>Numeric Keypad</b>	Use to type in numeric inputs (e.g. access codes).

#### P30i consoles

Available exclusively on the 700 Line Treadmill, the P30i Interval Console is an easy-to-use console that facilitates interval training with one-touch speed and incline keys.

CONSOLE KEY	FUNCTION/DESCRIPTION
<b>SPEED 1/2 - DWN/UP (US std)</b> <b>SPEED 2/4 - DWN/UP (metric)</b>	Use the SPEED numeric 1 & 2 keys to scroll up and down through the current menu.
<b>OK or INCLINE 0</b>	Selects the current menu item or confirms settings.
<b>INCLINE 0</b>	Returns to the previous menu level without saving changes.
<b>PAUSE</b>	<ul style="list-style-type: none"> <li>• Exits service mode</li> <li>• Press and hold PAUSE for greater than 6 sec will open the Error Log or show the "Stuck Key" message when there are no logged errors.</li> </ul>
<b>INCLINE</b> numeric keys	Use as the numeric keypad to type in numeric inputs (access codes etc.).

## P80 and P82 touchscreen consoles

The P80 and P82 consoles use the touch sensitive touchscreen controls to select items and navigate the service menus. Only one hardkey "Pause" is used to stop a running diagnostic test.

Follow the on-screen prompts to run the diagnostic tests.



CONSOLE KEY	FUNCTION/DESCRIPTION
<b>Touchscreen controls</b>	There are various touch sensitive softkey controls (OK, START, STOP, BACK, etc.) and icon controls (image boxes, buttons, etc.) used to control and operate the console. Make selection by touching the softkey control or icon.
<b>Scroll Up/Dwn</b>	Use your finger to swipe the touchscreen up or down to scroll through menu items. Some menus provide a vertical scroll bar on the screen right side to scroll Up/Dwn.
<b>BACK</b> softkey	<ul style="list-style-type: none"> <li>• Use the touchscreen <b>BACK</b> softkey to return to the previous menu display.</li> <li>• Continue selecting the <b>BACK</b> softkey to exit the service software.</li> </ul>
<b>PAUSE</b> hardkey	Stop a running diagnostic test.

## P62 touchscreen consoles

The P62 console uses a combination of touchscreen softkeys/icons and keypad hardkeys to select and navigate thru the service and diagnostics menus. The P62 uses the **BACK** keypad button to return to the previous menu and the **PAUSE** hardkey to stop a running diagnostic test.

Follow the on-screen prompts run the diagnostic tests.

CONSOLE KEY	FUNCTION/DESCRIPTION
<b>Touchscreen controls</b>	There are various touch sensitive softkey controls (OK, START, STOP, BACK, etc.) and icon controls (image boxes, buttons, etc.) used to control and operate the console. Make selection by touching the softkey control or icon.
<b>Scroll Up/Dwn</b>	Use your finger to select while swiping your finger Up/Dwn to scroll through menu lists. Some menus provide an on-screen scroll bar to scroll Up/Dwn.

CONSOLE KEY	FUNCTION/DESCRIPTION
<p><b>BACK</b></p>	<ul style="list-style-type: none"> <li>On P62 consoles, use the control keypad <b>BACK</b>  button to go back or return to the previous menu.</li> <li>Continue selecting the <b>BACK</b> hardkey to exit the service software.</li> </ul> <div style="text-align: center;">  <p>P62 Console</p> </div>
<p><b>PAUSE</b> hardkey</p>	<p>Stop a running diagnostic test.</p>

## LED Console Standard Service Menus

Standard service menus for LED consoles (P10, P30, P30i and P31).

### Hardware Validation Diagnostics Tests Menu (51765761)

Service Access Code: 51765761 (see "Service Access Codes" on page 12)

menu: Access code (51765761) > Hardware Validation Tests.

The Hardware Validation menu provides a set of automated diagnostic tests and hardware calibration routines used to troubleshoot, calibrate, and verify machine operation. The diagnostic tests are customized for the particular equipment type and console configuration.

DIAGNOSTIC TEST	TEST DESCRIPTION
<p><b>DISPLAY TEST</b></p>	<p>Tests the console LEDs. Successively press the <b>OK</b> key to verify each group of LEDs and verify that all LEDs illuminate. Press <b>Back</b> to exit the test.</p>

DIAGNOSTIC TEST	TEST DESCRIPTION
<b>KEYBOARD TEST</b>	An illuminated LED map of the function keys will be shown. Press each individual key and verify that the corresponding LED extinguishes. Press and hold <b>BACK</b> to exit the test.
<b>PVS<sup>1</sup> KEY TEST</b>	Not used, OEM test.
<b>HEART RATE</b>	Tests the unfiltered, filtered, and pulse heart rate. Grasp the grips to test the hand held heart rate. Use a Polar heart rate simulator to test the wireless heart rate. Press the <b>BACK</b> button to exit this test.
<b>ACTIVE STATUS LIGHT (1)</b>	The current <b>ASL<sup>2</sup></b> status light state (blue, pulsing blue, yellow, & pulsing yellow).
<b>AS LIGHT BRIGHTNESS (1)</b>	Sets the ASL light brightness level and ON/OFF state: HIGH, MED, LOW, and ON/OFF.
<b>MC<sup>3</sup> LIGHT</b>	Shows current state of MC LED-Hold <b>Quick Start</b> to reset.
<b>BELT SPEED TEST</b>	<p>menu: <b>MACHINE TEST &gt; BELT SPEED TEST</b></p> <p>Tests belt operating condition in 0.1 speed increments</p> <p>Test parameters:</p> <ul style="list-style-type: none"> <li>• AMPS IN: Treadmill input Current.</li> <li>• VOLTS IN: Treadmill input Voltage</li> <li>• VBUSS: Treadmill internal buss Voltage</li> <li>• AMPS MTR: Current supplied to the drive motor.</li> </ul>
<b>AUTO STOP TEST</b>	<p>menu: <b>MACHINE TEST &gt; AUTO STOP TEST</b></p> <p>Test parameters;</p> <ul style="list-style-type: none"> <li>• Status - Exerciser detected on or off the running belt.</li> <li>• Step Count - Average # of footplants. Footplant averaging delay reset with each speed change.</li> </ul>
<b>INCLINE TEST</b>	<p>menu: <b>MACHINE TEST &gt; INCLINE TEST</b></p> <p>Test parameters;</p> <ul style="list-style-type: none"> <li>• A/D - lift motor incline position potentiometer A/D number.</li> </ul>

<sup>1</sup>Personal Viewing System display.

<sup>2</sup>Active Status Light: Service and maintenance status light.

<sup>3</sup>Motor controller or motor controller module

DIAGNOSTIC TEST	TEST DESCRIPTION
	<ul style="list-style-type: none"> <li>• SEC - UP/DWN command response delay between the <b>UPCA</b><sup>1</sup> and <b>LPCA</b><sup>2</sup>.</li> <li>• Glitches - Momentary failures in the A/D potentiometer output. If there are more than 50 Glitches, the lift motor should be replaced.</li> </ul>
<p><b>STOP KEY TEST</b></p>	<p>menu: <b>MACHINE TEST &gt; STOP KEY TEST</b> (P10, P30 consoles only) Verifies the Stop Key and E-Stop function Test sequence steps;</p> <ol style="list-style-type: none"> <li>1. StopKey test - Press the Stop Key</li> <li>2. Lanyard ESTOP test- Pull the lanyard to trip the emergency stop function.</li> <li>3. Exit test - Press the Stop button to reset and exit test.</li> </ol>

Notes: (1) Only used on machines that support the Active Status Light feature.

### Club Settings Menu (5651565)

Service Access Code: 5651565 (see "Service Access Codes" on page 12)

menu: **Club Settings (51765761) > DIAGS - CLUB SETTINGS**

CLUB SETTINGS	DESCRIPTION
<p><b>SAFETY CODE</b></p>	<p>Enabled or disabled. When enabled, a user password (xxxx) is required to use the machine. Factory default: disabled.</p>
<p><b>SELECT LANGUAGE</b></p>	<p>Sets the default language for all workouts on this machine. Language for single use workouts can also be set by the user from the workout options. Default: English</p>
<p><b>SET UNITS</b></p>	<p>Sets units of measure to US standard or Metric. Range: U.S, Metric Default: U.S.</p>

<sup>1</sup>Upper PCA board

<sup>2</sup>Lower printed circuit assembly; generally this refers to the lower board. On treadmills, this is the motor controller unit (MCU), and on self-powered units, it is the main board in the lower section.

CLUB SETTINGS	DESCRIPTION
<b>SET MAX WORKOUT TIME</b>	Sets the maximum allowable user workout time per session. Range: 1 to 240 min, NO LIMIT Default: 60 min
<b>SET MAX PAUSE TIME</b>	Sets how long the equipment remains in a paused banner during a workout before resetting. Range: 1 to 120 sec (All except <b>EFX</b> <sup>1</sup> ) Range: 1 to 60 sec (EFX only) Default 30 sec.
<b>SET COOL DOWN TIME</b>	Sets the amount of time that a cool down period will occur at the end of every workout. Factory default is 5 minutes. Settable in 1 minute increments. Range: 1 to 5 min Default: 5 min
<b>SET METRICS DEFAULT</b>	Sets a metric that may be of specific importance to the specific facility or fitness trainer. The selected metric will scroll across the screen at regular intervals during the workout. Default: none
<b>SET SPEED LIMIT</b>	Sets the user maximum speed. Default: 12 mph
<b>SET INCLINE LIMIT</b>	Sets the user maximum speed. Default: 15 %
<b>HIDDEN PROGRAMS</b>	Either enabled or disabled*, the setting allows the unit to access specialized fitness tests designed for police, fire fighters and the military. Default: disabled
<b>REMOTE SPEED CONTROL</b>	Not used.
<b>AUTO STOP CONFIGURE</b>	Sets Auto Stop to On or Off. Default: ON
<b>MAINT CONFIG</b>	(ASL only) Sets the ASL maintenance counter reminder function ON/OFF (ASL pulsing blue light ON/OFF).
<b>SET CUSTOM PROGRAM 1/2</b>	Sets the use of a customized workout program. Range: ON/OFF Default: OFF

<sup>1</sup>Elliptical Fitness CrossTrainer

CLUB SETTINGS	DESCRIPTION
	Note: The Total Body Workout can only be turned on in this Club Settings menu.
	Note: * not available on all models.

## Information Display (65)

Service Access Code: 65 (see "Service Access Codes" on page 12)

Provides the equipment usage, hardware, software, error code, and maintenance information.

INFORMATION DISPLAY	DESCRIPTION
<b>ODOMETER</b>	The total number of accumulated miles on the unit. This value is stored in the upper <b>PCA</b> <sup>1</sup> in the console so if the PCA is replaced the accumulated miles would start again from "0".
<b>HOUR METER</b>	The total number of hours that the unit took to accumulate unit miles. This value is stored in the upper PCA in the console so if that PCA is replaced the hours of use would start again from "0".
<b>BELT RATING<sup>(2)</sup></b>	(Treadmills Only) Displays the belt rating from 10 (best) to 0 (worst). Belt rating ≤ 1 replace the running belt ASL equipped machines: A belt rating of 0 or 1 will cause a blue pulsing ASL light indicating that there is a problem with the running belt/deck and requires servicing or replacement. <b>Important:</b> Reset the Belt Rating after replacing with a new running belt and deck ( hold down <b>QuickStart</b> ).
<b>MAINT COUNTER</b>	Provides machine next maintenance due remaining mileage or hours. Perform preventative maintenance when the maintenance counter reaches 0. Press/Hold the <b>PAUSE/RESET</b> key to reset the counter (treadmills reset to 1000 miles, ellipticals reset to 250)

<sup>1</sup>Printed circuit assembly, generally referred to as either an upper PCA or lower PCA.

INFORMATION DISPLAY	DESCRIPTION
	Hrs).
<b>U-BOOT SW</b>	The console Upper Boot software version information.
<b>U-BASE SW</b>	The console Upper Base software version information.
<b>METRICS BOARD SW</b>	The console Metrics board software version information
<b>SER NUMBER</b>	Displays the model and serial number of the machine. The base serial number can be set using the WinCSAFE computer software. The factory default is NONE.
<b>USAGE LOG</b>	Displays the type of workout programs the users are accessing most frequently.
"Error Log & CPA Event Log" on page 95	Table of stored error event codes. <b>TIP:</b> You can quickly access the Error log by holding down the <b>PAUSE</b> key. Will show the <b>STUCK KEY</b> message when there are no logged error codes.
(1) Only available on ASL equipped models.	
(2) <b>TRM800-14</b> <sup>1</sup> , TRM700-16 models	

<sup>1</sup>TRM800 version 2 treadmills mfg. dates 2014 and later.



## Touchscreen Console Standard Service Menus

Standard service menus for Touchscreen consoles (P62, P80, and P82).

### Touchscreen Console Standard Service Menus

#### Service Menus ( 51765761 )

Service Access Code: 51765761

Standard service menu access code (51765761) opens to the Settings menu which is the top level service menu providing access to all the equipment service submenus.

menu: **Service Access code (51765761) > Settings**

The Settings menu is the top level service menu providing access to all available equipment service information, diagnostic tests, and maintenance submenus.

SETTINGS MENU	DESCRIPTION
"About menu" on the facing page	<p>menu: <b>Settings &gt; About</b></p> <p>General information about the machine (serial number, name, type, location, software versions, internet &amp; <b>Wi-Fi</b><sup>1</sup> connectivity, and the error codes (Event Log or CPA Event Log)</p>
"" on page 29	<p>menu: <b>Settings &gt; Equipment Usage</b></p> <p>Machine workout usage information (total workout time &amp; distance, last work start/stop times).</p>
"" on page 29	<p>menu: <b>Settings &gt; Maintenance</b></p> <p>(ASL equipped machines only) Provides the machine maintenance and operating status information.</p>
"" on page 31	<p>menu: <b>Settings &gt; System Settings</b></p> <p>Provides settings to configure the console and machine. Also includes the service diagnostic tests.</p>
<b>Software Downloads</b>	<p>menu: <b>Settings &gt; Software Downloads</b></p> <p>Settings: ON, OFF</p> <p>Enables automatic operating system software downloads:</p> <ul style="list-style-type: none"> <li>• ON: Enables automatic operating system software downloads.</li> </ul>

<sup>1</sup>Wireless Fidelity - a term defined and Trademarked by the Wi-Fi Open Alliance. Wireless LAN equipment carrying the Wi-Fi logo have been interoperability tested for compatibility with one (or more) 802.11 standards, and certified by the Wi-Fi Alliance to be sold under the Wi-Fi brand.

SETTINGS MENU	DESCRIPTION
	<ul style="list-style-type: none"> <li>• OFF: Disables automatic operating system software downloads.</li> </ul> <p>Note: Must be connected to the internet and register with <b>PBS</b><sup>1</sup> (Preva<sup>®</sup> Business Suite).</p>
<b>Partition Configuration</b>	<p>menu: <b>Settings &gt; Partition Configuration</b></p> <p>OEM use only, contact Precor Customer Service for information.</p>
<b>(No) Available Updates</b>	<p>menu: <b>Settings &gt; No Available Updates</b> or <b>Available Updates</b></p> <ul style="list-style-type: none"> <li>• <b>No Available Updates:</b> No available software updates can be read from the USB flash drive.</li> <li>• <b>Available Updates:</b> List of available software updates read from the USB flash drive.</li> </ul> <p>Used to update the operating system software. The console reads a software update USB flash drive and then changes the menu from <b>No Available Updates</b> to <b>Available Updates</b>. Select <b>Available Updates</b> to view, select, and upload the software, see <a href="#">How to Update the console operating system software</a>.</p>

## About menu

### About menu

menu: **Service menu (51765761) > Settings > About**

General information about the machine (serial number, name, type, location, software versions, internet & Wi-Fi connectivity, and the event and error codes (Event Log or CPA Event Log)).

ABOUT MENU	DESCRIPTION
<b>Event Log</b>	<p>menu: <b>About &gt; Event Log</b></p> <p>The Event Log contains all connectivity errors and service maintenance error codes.</p> <p>.Note: For maintenance service and troubleshooting, use the CPA Event Log and not the Event Log to find the machine maintenance error event codes.</p>
<b>CPA Event Log</b>	<p>menu: <b>About &gt; CPA Event Log</b></p> <p>The CPA Event Log only contains the machine maintenance and</p>

<sup>1</sup>Preva Business Suite

ABOUT MENU	DESCRIPTION
	<p>troubleshooting error event codes that are described in the "<i>Error Code Troubleshooting Guide</i>", see <a href="#">Error Code Troubleshooting Guide</a>.</p> <p>.Note: Use the CPA Event Log and not the Event Log to find the machine maintenance and troubleshooting error event codes.</p>
<p><b>Console Serial Number</b></p>	<p>menu: <b>About &gt; Serial Number</b> Console serial number.</p>
<p><b>Lower Serial Number</b></p>	<p>menu: <b>About &gt; Serial Number</b> Base serial number.</p>
<p><b>Friendly Name</b></p>	<p>menu: <b>About &gt; Friendly Name</b> Friendly name assigned to the equipment by the facility.</p>
<p><b>Location</b></p>	<p>menu: <b>About &gt; Location</b> Facility location code.</p>
<p><b>Release Bundle Version</b></p>	<p>menu: <b>About &gt; Release Bundle Version</b> Console System Operating software version. Select to show the component system software versions including: the CPA Software, LPCA, Qt App, Boot Kernel, and File System software versions.</p>
<p><b>Heartbeat Interval</b></p>	<p>menu: <b>About &gt; Heartbeat Interval</b> OEM use only.</p>
<p><b>Wired MAC Address</b></p>	<p>menu: <b>About &gt; Wired MAC Address</b> Wired LAN<sup>1</sup> MAC address</p>
<p><b>WI-FI MAC Address</b></p>	<p>menu: <b>About &gt; Wi-Fi MAC Address</b> Wireless Wi-Fi MAC address</p>
<p><b>Network Time Server1</b></p>	<p>menu: <b>About &gt; Network Time Server1</b> NTP<sup>2</sup> server address</p>
<p><b>Machine Type</b></p>	<p>menu: <b>About &gt; Machine Type</b></p>

<sup>1</sup>Local Area Network: A communications network that serves users within a local geographical area, typically over distances of around 100m. Wireless LANs use wireless communications to network devices so there is no need for data cabling.

<sup>2</sup>Network Time Protocol (NTP) is a networking protocol for clock synchronization between computer systems over packet-switched, variable-latency data networks.

ABOUT MENU	DESCRIPTION
	Specifies the detected machine type: TRED, <b>AMT</b> <sup>1</sup> , EFX, <b>UBK</b> <sup>2</sup> , <b>RBK</b> <sup>3</sup> .
Legal Notices	menu: <b>About &gt; Legal Notices</b> Specifies the trademarks. trade names, etc.

### Equipment Usage menu

menu: **Service menu (51765761) > Settings > Equipment Usage.**

Machine workout usage information: cumulative hours & distance, number of workout sessions, & last work start/stop times.

EQUIPMENT USAGE MENU	DESCRIPTION
Cumulative Workout Hours	menu: <b>Equipment Usage &gt; Cumulative Workout Distance</b> Machine total workout hours.
Cumulative Workout Distance	menu: <b>Equipment Usage &gt; Cumulative Workout Distance</b> Machine total workout distance.
Cumulative Workout Sessions	menu: <b>Equipment Usage &gt; Cumulative Workout Sessions</b> Machine total number of workout sessions.
Last Workout Start Timestamp	menu: <b>Equipment Usage &gt; Last Workout Start Timestamp</b> The most recent workout start time.
Last Workout End Timestamp	menu: <b>Equipment Usage &gt; Last Workout End Timestamp</b> The most recent workout end time.

### Maintenance menu

Menu: **Service menu (51765761) > Settings > Maintenance**

Provides machine maintenance related information including: routine maintenance due status, machine operating condition, and ASL state.

<sup>1</sup>Adaptive Motion Trainer  
<sup>2</sup>Upright Bike  
<sup>3</sup>Recumbent Bike

MAINTENANCE MENU	DESCRIPTION
<p><b>Recommended Action menu</b></p>	<p>menu: <b>Maintenance &gt; Recommended Action</b>            Range: None, Inspect</p> <ul style="list-style-type: none"> <li>• None: No maintenance required.</li> <li>• Inspect: Maintenance action required.</li> </ul> <p>Used to report that there is a maintenance issue that requires attention; it could indicate routine maintenance is due or that a machine failure (error code) has occurred that required attention.</p>
<p>» <b>Operating Condition</b></p>	<p>menu: <b>Maintenance &gt; Operating Condition</b>            Range: Normal, Inspect</p> <ul style="list-style-type: none"> <li>• Normal: No maintenance required.</li> <li>• Inspect: There is a routine maintenance issue or failure condition (error code) that requires immediate attention.</li> </ul> <p><b>.Important:</b> Reset the ASL light state and Motor Controller (MC) status light after repairs a completed.</p>
<p>» <b>Belt Rating</b></p>	<p>(Treadmills only)            menu: <b>Maintenance &gt; Belt Rating</b>            Range: 10 - 0 (10 - New condition, ≤ 1 - Replace running belt)            On ASL equipped machines: A belt rating of 0 or 1 will cause a blue pulsing ASL light indicating that there is a problem with the running belt/deck and requires servicing or replacement.  <b>.Important:</b> Reset the Belt Rating after replacing with a new running belt and deck (select <b>Replace</b>).</p>
<p>» <b>Next Maintenance Due</b></p>	<p>menu: <b>Maintenance &gt; Next Maintenance Due</b>            Provides machine next maintenance due remaining mileage or hours. Perform preventative maintenance when the maintenance counter reaches 0.  <b>.Important:</b> Reset the maintenance interval after completing routine maintenance service, (select <b>Reset</b>). Treadmills reset to 1000 miles, ellipticals reset to 250 Hrs.</p>
<p><b>Active Status Light (1) (ASL) menu</b></p>	<p>menu: <b>Maintenance &gt; Active Status Light</b>            Indicates the machine operating and maintenance status.</p> <p><b>Blue Solid:</b> Normal operation Indicates that the ASL has not detected any logged error codes.</p> <p><b>Blue Pulsing:</b> Preventative maintenance reminder.</p> <ul style="list-style-type: none"> <li>• Treadmills: A belt rating of 0 or 1 will cause a blue pulsing ASL light indicating that there is a problem with the running belt/deck</li> </ul>

MAINTENANCE MENU	DESCRIPTION
	<p>and is in need of servicing or replacement.</p> <ul style="list-style-type: none"> <li>• ALL: The maintenance counter starts at 1000 hours counting down to active use hours to 0 indicating preventative maintenance is due.</li> </ul> <p><b>Yellow Solid:</b> Indicates an error has occurred, was self-corrected and the machine can be used. The fault can be cleared.</p> <p><b>Yellow Pulsing</b> There is a current non-recoverable fault condition, there is a loss of a major function and the machine is out-of-service. Machine service is required.</p>
» AS light Brightness (1)	<p>menu: <b>Maintenance &gt; AS Light Brightness</b>            Range: Low, Medium, High            Set the ASL brightness level.</p>
» Maintenance Reminder	<p>menu: <b>Maintenance &gt; Maintenance Reminder</b>            Range: OFF, ON (default)            Switch the maintenance reminder function ON or OFF.</p>
<p>Notes: (1) Only used on machines that support the Active Status Light feature.</p>	

### System Settings menu

menu: **Service menu (51765761) > Settings > System Settings.**

Provides settings to configure the console and machine. Also includes the service diagnostic tests.

SYSTEM SETTINGS MENU	DESCRIPTION
System Tests menu	<p>menu: <b>System Settings &gt; System Tests</b>            Machine diagnostics tests to verify system hardware operation, see "<a href="#">System Tests menu</a>" on page 36.</p>
Connectivity menu	<p>menu: <b>System Settings &gt; Connectivity</b>            Connectivity includes Internet network and Preva<sup>®</sup> Server setup and configuration.</p>
» Network Type	<p>menu: <b>System Settings &gt; Connectivity &gt; Network Type</b>            Settings: Wired, Wi-Fi            Default: Wired</p>

SYSTEM SETTINGS MENU	DESCRIPTION
	<p>To connect to a network:</p> <ol style="list-style-type: none"> <li>1. Select <b>Network Type</b> &gt; <b>Wired</b> (or Wi-Fi) &gt; <b>Go</b>.</li> <li>2. Select <b>Configure</b> &gt; <b>Configuration</b> &gt; select a network from the list and enter your credentials to access that network.</li> <li>3. Select <b>Back</b> to save settings and return to the Connectivity screen.</li> </ol>
<p>» <b>Configuration</b></p>	<p>menu: <b>System Settings &gt; Connectivity&gt; Configuration</b>            Settings: Automatic (recommended), Manual            Default: Automatic            Specifies internet connection mode.</p>
<p>» <b>Status</b></p>	<p>menu: <b>System Settings &gt; Connectivity &gt; Status</b>            Range: Connected, Not Connected            Specifies internet connection status.</p>
<p>» <b>IP Address</b></p>	<p>menu: <b>System Settings &gt; Connectivity&gt; IP Address</b>            Specifies console internet IP address.</p>
<p>» <b>Preva® Server</b></p>	<p>menu: <b>System Settings &gt; Connectivity&gt; Preva® Server</b>            Specifies Precor Preva server URL (na.preva.com).</p>
<p><b>Display menu</b></p>	<p>menu: <b>System Settings &gt; Display</b>            Console default display configuration settings: language, units, standby delay, .browser and news reader on/off.</p>
<p>» <b>Default Language</b></p>	<p>menu: <b>System Settings &gt; Display &gt; Default Language</b>            Default: English            Specifies the default language.</p>
<p>» <b>Measurement Units</b></p>	<p>menu: <b>System Settings &gt; Display &gt; Measurement Units</b>            Range: US Standard, Metric            Default: US Standard            Specifies the default measurement units.</p>
<p>» <b>Standby Mode Delay</b></p>	<p>menu: <b>System Settings &gt; Display &gt; Standby Mode Delay</b>            Range: 5, 10, 15, 30, 60 minutes            Default: 15 minutes            Specifies the idle wait time before entering standby mode.</p>
<p>» <b>Browser</b></p>	<p>menu: <b>System Settings &gt; Display &gt; Browser</b>            Range: ON/OFF</p>

SYSTEM SETTINGS MENU	DESCRIPTION
	Default: ON Show (enable) the Browser app.
» News Reader	menu: <b>System Settings &gt; Display &gt; News Reader</b> Range: ON/OFF Default: ON Show (enable) the News Reader app.
TV Settings menu	menu: <b>System Settings &gt; TV Settings</b> Configuration TV settings and channel guide.
» Channel Guide	menu: <b>System Settings &gt; TV Settings &gt; Channel Guide</b> TV channel configuration.
» TV Source	menu: <b>System Settings &gt; TV Settings &gt; TV Source</b> Default: Internal Tuner TV input signal source
» Region	menu: <b>System Settings &gt; TV Settings &gt; Region</b> Specifies the TV input signal modulation format for a particular geographical region.
» Default Channel	menu: <b>System Settings &gt; TV Settings &gt; Default Channel</b> Default: Not set TV default channel.
» Skip Unnamed Channel	menu: <b>System Settings &gt; TV Settings &gt; Skip Unnamed Channels</b> Default: ON Skips over unnamed channels.
» Skip Encrypted Channel	menu: <b>System Settings &gt; TV Settings &gt; Skip Encrypted Channels</b> Default: ON Skips over encrypted channels.
» Analog Channels Aspect Ratio	menu: <b>System Settings &gt; TV Settings &gt; Analog Channels Aspect Ratio</b> Range: 4:3, 16:9 Select the analog channel aspect ratio.
» Extensive Scan	menu: <b>System Settings &gt; TV Settings &gt; Extensive Scan</b> Default: OFF



SYSTEM SETTINGS MENU	DESCRIPTION
	Searches all available channel sources.
» Closed Captioning	menu: <b>System Settings &gt; TV Settings &gt; Closed Captioning</b> Default: On Switches close caption feature ON/OFF.
» Export/Import Channels	menu: <b>TV Settings &gt; Export/Import Channels</b> Export/Import channel mapping using a USB .flash drive.
Audio Settings menu	menu: <b>System Settings &gt; Audio Settings</b> Specify the workout duration and equipment Limits for your facility.
» Default Wired Headphone Volume	menu: <b>System Settings &gt; Audio Settings &gt; Default Wired Headphone Volume</b> Range: 1 to 15 Default: 6 Sets the default wired headphone jack volume level.
» Default Bluetooth <sup>1</sup> Headphone Volume	menu: <b>System Settings &gt; Audio Settings &gt; Default Bluetooth Headphone Volume</b> Range: 1 to 15 Default: 11 Sets the default bluetooth headphone jack volume level.
Workout Limits menu	menu: <b>System Settings &gt; Workout Limits</b> Specify the workout duration and equipment Limits for your facility.
» Maximum Workout Duration	menu: <b>System Settings &gt; Workout Limits &gt; Maximum Workout Duration</b> Range: 1 to 240 min, NO LIMIT Default: 60 min Sets the maximum allowable user workout time per session.
» Maximum Pause	menu: <b>System Settings &gt; Workout Limits &gt; Maximum Pause</b> Range: 1 to 300 sec Default: 30 sec

<sup>1</sup>Bluetooth is a wireless technology standard for exchanging data over short distances (using short-wavelength UHF radio waves in the ISM band from 2.4 to 2.485 GHz from fixed and mobile devices, and building personal area networks (PANs).

SYSTEM SETTINGS MENU	DESCRIPTION
	Sets how long the equipment remains in a paused banner during a workout before resetting.
» Summary Time Out	menu: <b>System Settings &gt; Workout Limits &gt; Summary Time Out</b> Sets the time to view the Workout Summary data. Range: 1 to 120 sec Default: 60 sec
» Maximum Speed	menu: <b>System Settings &gt; Workout Limits &gt; Maximum Speed</b> Default: 12 mph Sets the user maximum speed.
» Maximum Incline	menu: <b>System Settings &gt; Workout Limits &gt; Maximum Incline</b> Default: 15 %
» Auto Stop <sup>(1)</sup>	menu: <b>System Settings &gt; Workout Limits &gt; Auto Stop</b> Default: ON Sets Auto Stop to On or Off.
Register Equipment menu	menu: <b>System Settings &gt; Register Equipment</b> Register console and equipment with Precor Preva <sup>®</sup> Business Suite "PBS". Required information to register the equipment: <ul style="list-style-type: none"> <li>• Location code</li> <li>• Precor technician account name and password</li> <li>• Serial number from the base</li> <li>• Friendly name assigned to the equipment by the facility (Example: Equipment Type-Floor-Row-Number)</li> </ul> To complete registration for Preva-networked facilities: <ol style="list-style-type: none"> <li>1. Enter the Preva server name (na.preva.com for all sites).</li> <li>2. Enter the assigned account name and password.</li> <li>3. Follow the onscreen instructions to register the product.</li> </ol>
Manage Settings	menu: <b>System Settings &gt; Manage Settings</b> Save and restore the Connectivity, Display, Media, and Workout Limits settings.

(1) Not available on all models.

## System Tests menu

### System Tests menu

menu: **Service menu (51765761) > System Settings > System Tests.**

Machine diagnostics tests to verify system hardware operation.

SYSTEM TESTS MENU	TEST DESCRIPTION
<b>Auto Stop Test</b>	menu: <b>System Tests &gt; Auto Stop Test</b> Test parameters; <ul style="list-style-type: none"> <li>• Status - User detected on running belt</li> <li>• Step Count - Average # of footplants. Footplant averaging delay reset with each speed change.</li> </ul>
<b>Belt Speed Test</b>	menu: <b>System Tests &gt; Belt Speed Test</b> Tests belt operating condition in 0.1 speed increments Test parameters: <ul style="list-style-type: none"> <li>• AMPS IN: Treadmill input Current.</li> <li>• VOLTS IN: Treadmill input Voltage</li> <li>• VBUSS: Treadmill internal buss Voltage</li> <li>• AMPS MTR: Current supplied to the drive motor.</li> </ul>
<b>Incline Test</b>	menu: <b>System Tests &gt; Incline Test</b> Test parameters; <ul style="list-style-type: none"> <li>• A/D - lift motor incline position potentiometer A/D number.</li> <li>• SEC - UP/DWN command response delay between the UPCA and LPCA.</li> <li>• Glitches - Momentary failures in the A/D potentiometer output. If there are more than 50 Glitches, the lift motor should be replaced.</li> </ul>
<b>USB Test</b>	menu: <b>System Tests &gt; USB Test</b> List the active USB ports.
<b>Touchscreen Test</b>	menu: <b>System Tests &gt; Touchscreen Test</b> Verify touchscreen display.
<b>Touchscreen Calibration</b>	menu: <b>System Tests &gt; Touchscreen Calibration</b> Calibrates touchscreen finger press operation.
<b>Backlight Test</b>	menu: <b>System Tests &gt; Backlight Test</b> Tests the display backlight performance.
<b>RGB Test</b>	menu: <b>System Tests &gt; RGB Test</b>

SYSTEM TESTS MENU	TEST DESCRIPTION
	Tests the display color performance.
<b>Numeric Backlight Test</b>	menu: <b>System Tests &gt; Numeric Backlight Test</b> Tests the movement controls LCD numeric displays backlight brightness level.
<b>Numeric Display Test</b>	menu: <b>System Tests &gt; Numeric Display Test</b> Tests the movement controls LCD numeric displays.
<b>Heart Rate Test</b>	menu: <b>System Tests &gt; Heart Rate Test</b> Tests the handlebar unfiltered, filtered, and pulse heart rate. Grasp the grips to test the hand held heart rate. Use a Polar heart rate simulator to test the wireless heart rate. Press the back button to exit this test.

## Club Settings (5651565)

Service Access Code: 5651565

On P62, P80, and P82 touchscreen consoles, Club Settings menu is used by club operators to configure the equipment workouts and to help manage equipment service.

### Club Settings Menus

- **About menu**, see "[About menu](#)" on page 27.
- **Equipment Usage menu**, see "" on page 29.
- **Maintenance menu**, see "" on page 29.
- **System Settings menu**, see "" on page 31.
- **(No) Available Updates**, see "[\(No\) Available Updates](#)" on page 27.

## Information Display (65)

**Information Display (65):** Not supported

The Information Display (65) service menu found on LED consoles (P10, P30, P30i and P31) is **NOT** supported on touchscreen consoles (P62, P80, and P82).

Refer to the following touchscreen console service menus for similar equipment information:

- **About menu**, see "[About menu](#)" on page 27.
- **Equipment Usage**, menu see "" on page 29.

- Maintenance menu, see "" on page 29.
- 
-

## Adjustment Procedures

Adjustment procedures provide you with the step-by-step adjustment instructions to bring systems and components into specification. Perform the adjustment procedures whenever a trouble symptom points to a particular component and after a major component is removed/replaced.

### Available Adjustment Procedures

"Drive Belt Tension & Alignment Adjustment" on the next page

"Running Belt Tension and Tracking Adjustment" on page 45

"Lift Motor Calibration" on page 43

## Drive Belt Tension & Alignment Adjustment

### About

This procedure provides instruction to verify and make adjustments to the Drive Belt tension. The Drive Belt tension should be verified anytime the drive belt is removed or replaced.



**NOTE:** This procedure assumes that the drive belt has been installed and seated onto the drive roller and drive motor pulleys.

### Procedure

Review entire procedure before starting.

#### *Drive Belt Tension Verification*


2. Switch the input power **OFF** and **unplug**<sup>1</sup> the power cord.
3. Remove the front hood.

#### *Drive Belt Alignment*

4. Verify the drive belt alignment. Make sure that the drive belt is aligned parallel to the frame rail. Measure the belt to frame rail distance at the drive roller pulley and at the drive motor pulley. If the measurements are not the same, adjust the belt position on the drive motor pulley to match the drive roller belt distance.



**CAUTION:** Improper drive belt alignment will cause damage and/or break the drive belt.



2. Place the belt tension gauge onto the drive belt.

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



3. Verify that the tension measurement is within the **Range Limit** specification, see *Drive Belt Tension Specification* table. Note that there is a separate **Range Limit** specification for New and Used belt installations.
  - a. If the belt tension is not within the **Range Limit** specification; Re-tension to the OEM specification, go to [Drive Belt Tension Adjustment](#) procedure below.
  - b. If the belt tension is within the **Range Limit** specification; Reinstall all covers, verify treadmill operation (see [Operation Verification](#)), and return to service.

Drive Belt Tension Specification

Belt Condition	Tension	Range Limit
New	105 lbs +/- 10 (48 kgs +/- 4.5)	95-115 lbs (43-52 kgs)
Used	85 lbs +/- 5 (39 kgs +/- 2)	80-90 lbs (36-41 kgs)

***Drive Belt Tension Adjustment***

Belt tension is adjusted by moving the drive motor position (forward or rearward) in an iterative process until the belt tension meets specification.

4. Remove the drive belt. It is recommended that you walk the belt off the smaller drive motor pulley.
5. Loosen the drive motor mount bolts, slightly move the drive motor either forward or rearward as required to increase or decrease the belt tension. Re-tighten the bolts.
6. Re-install the drive belt. It is recommended that you walk the drive belt onto the larger drive roller pulley.
7. Measure and verify that the belt tension meets the **Tension** specification, see *Drive Belt Tension Specification* table. Note that there is a separate specification for New and



Used belt installations:

- a. If the tension is not within specification, repeat the adjustment process.
  - b. If the tension is within specification, continue procedure.
8. **Torque**<sup>1</sup> the drive motor mount bolts to 204 in-lbs (17 ft-lbs, 23 N-m).
  9. **Plug**<sup>2</sup> in the power cord and switch the input power ON.
  10. Run the treadmill speed at 3 mph for 1 minute.
  11. Switch the power OFF and disconnect power.
  12. Measure and verify that the tension measurement is within the **Range Limit** specification, see *Drive Belt Tension Specification* table. Note that there is a separate **Range Limit** specification for New and Used belt installations.
    - a. If the belt tension is not within the **Range Limit** specification, repeat the tension adjustment procedure.
    - b. If the belt tension is within the **Range Limit** specification, continue procedure.
  13. Re-install hood.
  14. Connect and Switch the input power ON.
  15. Verify operation and return to service.

### .See Also

["Adjustment Procedures" on page 39](#)

["Drive Motor Replacement" on page 59](#)

["Drive Belt Replacement" on page 55](#)

---

<sup>1</sup>Torque is a measure of the force that can cause an object to rotate about an axis. Bolt/nut example: 5 nM torque is equivalent to 5 newtons of force applied one meter from the center of the bolt, 6 ft-lb is equivalent to 6 lb of force applied 1 foot away from the center of the bolt.

<sup>2</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

## Lift Motor Calibration

### About

This procedure provides instruction to verify and calibrate the Lift Motor and incline system. The Lift Motor calibration should be verified anytime the Lift Motor circuit breaker fails or is replaced or any incline system component is replaced.

### Procedure

Review entire procedure before starting.

1. Toggle the treadmill circuit breaker from **OFF** to **ON**. The treadmill will begin to auto-reset the running deck incline to the 0% incline level "Home" position (This is the Lift Motor calibration reference position).




**WARNING:** Be aware that switching power **ON** will cause the Lift Motor actuator to auto-reset moving the incline actuator and platform. Keep clear of incline system components.

2. Set the treadmill circuit breaker to **OFF** and disconnect the power cord.
3. Access the Lift Motor actuator tube in one of the following methods:
  - a. From the bottom by carefully laying the treadmill on its side
  - b. From the front by connecting power and raising the treadmill to maximum incline and resting the frame base onto blocks securely placed under the front corners of the frame (removes weight from the incline platform and Lift Motor actuator tube). Switch power **OFF** and **unplug**<sup>1</sup> the power cord.
4. Disconnect the actuator tube from the incline platform mounting bracket by removing the hitch pin and clevis pin.
5. Set the actuator reference gap (distance between the top of the actuator tube (or nut) to the bottom of the Lift Motor housing) to [[[Undefined variable General.TRM10ActuatorRefGap]]]. Firmly hold the jack screw from turning and rotate the actuator tube to adjust the reference distance.

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



6. Re-Install the actuator tube into the incline platform mounting bracket. It may be necessary to slightly rotate the actuator tube to align the clevis pin mounting holes. Choose the adjustment direction that will minimize the change to the actuator tube reference distance. Hold the jack screw from turning while adjusting the actuator tube.
7. Return the treadmill to the upright position or remove support blocks.
8. Level the Treadmill.
9. Install the hood.
10. Connect the power cord and set the treadmill circuit breaker to **ON**.
11. Verify the treadmill incline operation through the full range of motion. Do the - **INCLINE TEST** diagnostic test.
12. Verify treadmill operation (see ) and return to service.

### .See Also

"Replacement Procedures" on page 48

"Incline Lift Motor Replacement" on page 68

## Running Belt Tension and Tracking Adjustment

### About

This procedure provides instructions to verify and make adjustments to the running belt tension and tracking alignment. The running belt tension and tracking should be verified anytime the running belt alignment is not centered or the running belt is replaced.



**NOTE:** Proper tensioning of the belt requires the use of two tensioning gauges, Precor part number PPP000000020007101....

### Procedure

Review entire procedure before starting.


#### *Running Belt Tension adjustment*

1. Remove the front hood, and left/right side step covers.
2. Remove the drive motor belt from the drive roller pulley. . If is recommended that you walk the belt off the smaller drive motor pulley.



**NOTE:** The drive motor belt must be removed to properly adjust the running belt tension.

3. Remove tension from the rear take-up roller. Alternately loosen the left and right bolts to equally remove the belt tension.
4. Center the running belt and make sure that it is squarely positioned from the front Drive roller to the rear Take-Up roller.
5. Move the running belt so that the seam is positioned underneath the treadmill.
6. Attach a running belt tension gauge on each side of the running belt opposite each other.



7. Slide the gauge head to set the dial needle to a coarse setting of 3. You can then rotate the gauge dial face to fine tune the needle to precisely 3.



**NOTE:** Setting the gauge to a 3 reference value centers the gauge head travel allowing +/- movement without impeding travel.

8. Alternately tighten the right and left take-up roller mounting bolts in increments of 0.2% so that the roller is evenly tensioned to the final 0.55% (dial 3.55) specification as follows:
  - a. Tighten the right bolt to dial setting 3.2, then the left bolt to 3.2.
  - b. Tighten the right bolt to dial setting 3.4, then the left bolt to 3.4
  - c. Tighten the right bolt to dial setting 3.55 (0.55%), then the left bolt to 3.55 (0.55%)



9. Remove the tension gauges.
10. Re-install the drive belt .Install by walking the belt onto the larger drive roller pulley. Make sure that the belt alignment is parallel to the frame rail, see "" on page 42.

***Running Belt Tracking Adjustment***

11. Start the treadmill and set the speed to 3 mph (5 kph).
12. Observe and verify that the running belt tracking remains centered, adjust as required:
  - a. If the belt starts to drift toward the right, slowly turn the right side Take-Up roller mounting bolt clockwise in ¼ turn increments until the drifting stops.
  - b. If the belt starts to drift toward the left, slowly turn the right side Take-Up roller bolt counterclockwise in ¼ turn increments until the drifting stops.



**NOTE:** 1) The tracking adjustments should only be done in 1/4 turn increments.  
 2) ONLY use the right side Take-Up roller mounting bolt to adjust tracking.  
 3) ONLY use hand tools to adjust tracking.



2. Increase the speed to 9 mph (14 kph) and then 12 mph (19 KPH) making sure that the tracking remains centered, make small adjustments as needed.
3. Verify that the treadmill is level, adjust as necessary.
4. Verify the running belt/deck surfaces are clean.
5. Replace all covers.
6. Verify treadmill operation (see ) and return to service.

### .See Also

"Adjustment Procedures" on page 39

"Running Belt and Deck Replacement" on page 81

## Replacement Procedures

Replacement procedures provide you with the step-by-step instructions to remove and replace system components.

### Available Replacement Procedures

"Auto Stop Magnet Replacement" on the facing page

"Auto Stop Sensor Replacement" on page 51

"Circuit Breaker Replacement" on page 53

"Drive Belt Replacement" on page 55

"Drive Motor Replacement" on page 59

"Drive Roller Replacement" on page 62

"End Cap & Belt Guard Cover Replacement" on page 66

"Input Module Replacement" on page 73

"Incline Lift Motor Replacement" on page 68

"Incline Lift Platform Replacement" on page 71

"Input Module Replacement" on page 73

"Line Filter Replacement" on page 75

"Power Control Module Replacement" on page 77

"Power Cord Replacement" on page 79

"Running Belt and Deck Replacement" on page 81

"Take-Up roller Replacement" on page 86

## Auto Stop Magnet Replacement

### About

This procedure provides instruction to remove and replace the Auto Stop Magnet.


### Procedure

Review entire procedure before starting.



**CAUTION:** Do not place the Auto Stop Magnet on or near a steel structure. If the magnet assembly comes in contact with a steel structure and then pulled away from the steel structure, the magnet can become dislodged from the magnet assembly housing. Contact PRECOR customer service for repair or replacement.

1. Set the treadmill circuit breaker to OFF and **unplug**<sup>1</sup> the treadmill's power cord.
2. Remove the front hood.
3. Remove the left and right trim strips from the treadmill deck.
4. Remove the four mounting bolts and two top plates that fasten the running deck to the pivot bracket at the back of the treadmill. Keep fasteners for installation.
5. Pull the running deck out from the right side of the treadmill just far enough to expose the front right edge of the running deck, see "" on page 5.




6. Pry out the two push fasteners from the deck using a flat head screw driver and remove the Auto Stop Magnet. Keep fasteners for installation.

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.





7. Align the replacement magnet on the running deck and then secure the magnet to the running deck using the two push fasteners.
8. Slide the running deck back into position over the running deck pivot bracket. Align the bottom plate and pivot bracket holes with the running deck bolt holes. Insert and tighten deck mounting bolts.
9. Check the alignment of the magnet and the auto stop assembly, see "[Auto Stop Sensor Replacement](#)" on the facing page.
10. Replace the trim strips and front hood.
11. Connect the power cord and Switch the input power **ON**.
12. Verify the Auto Stop function by doing the Auto Stop diagnostics test, see .
13. Verify treadmill operation per "" and return to service.

### .See Also

["Replacement Procedures"](#) on page 48

["Running Belt and Deck Replacement"](#) on page 81

## Auto Stop Sensor Replacement

### About

This procedure provides instruction to remove and replace the Auto Stop Sensor.


### Procedure

Review entire procedure before starting.



**CAUTION:** Do not place the Auto Stop Magnet on or near a steel structure. If the magnet assembly comes in contact with a steel structure and then pulled away from the steel structure, the magnet can become dislodged from the magnet assembly housing. Contact PRECOR customer service for repair or replacement.

1. Set the treadmill circuit breaker to OFF and **unplug**<sup>1</sup> the treadmill's power cord.
2. Remove the front hood and right side step cover.
3. Unplug the Auto Stop Cable from the Auto Stop assembly.
4. The Auto Stop Sensor assembly has round alignment tabs that match the holes of the treadmill frame support. With one hand grasp the side of the Auto Stop Sensor assembly that is closest to the outside of the treadmill and apply pressure toward the running deck. With your other hand push on each alignment tab from the inside of the frame mounting holes. The Auto Stop Assembly should disengage from the frame.




5. Position the replacement Auto Stop assembly with the cable connector facing to the right side of the treadmill. Slide the Auto Stop assembly over the treadmill frame support and push down until the round tabs align with the holes in the support. The round tabs will snap into the treadmill frame mounting holes securing the Auto Stop assembly in place.
6. Check the alignment of the magnet and the Auto Stop assembly. The magnet and the Auto Stop assembly each have an alignment mark on the top of their housings. The magnet mark and the Auto Stop mark should align and the gap should be approximately 3/16 of an inch between the housings. A 3/16 hex key can be used as a feeler gauge to

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.

set the correct gap. If the gap or alignment are off adjust the running deck until the magnet and auto housing are properly aligned, see "Auto Stop Magnet Replacement" on page 49.



7. Reconnect the Auto Stop Cable to the Auto Stop Sensor Assembly.
8. Replace front hood and side step cover.
9. Connect power cord and Switch the input power **ON**.
10. Verify the Auto Stop function by doing the Auto Stop diagnostics test, see .
11. Verify treadmill operation per "" and return to service.

### .See Also

"Replacement Procedures" on page 48

## Circuit Breaker Replacement


### About

This procedure provides instruction to remove and replace the ON/OFF Circuit Breaker.


### Procedure

Review entire procedure before starting.

1. Set the treadmill circuit breaker to **OFF** and **unplug**<sup>1</sup> the treadmill's power cord from the **AC**<sup>2</sup> outlet.
2. Remove the treadmill's hood.
3. Remove the two screws that fasten the AC input panel to the frame. Keep fasteners for replacement installation.
4. Disconnect the wiring from the circuit breaker (2 blue wires on 120 Vac treadmills or 2 blue and 2 brown wires on 240 Vac treadmills) Note: The figure below is showing a 240 volt configuration.



5. Incline the AC input panel from the frame and rotate it to expose the AC input circuit breaker screws.



<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.

<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

6. Remove the two screws and remove the circuit breaker. Keep fasteners for replacement installation.
7. Reference the label on the replacement circuit breaker and install the circuit breaker in its mounting position with the **LINE** side of the breaker facing the input module and the **LOAD** side of the circuit breaker facing the AC line filter. Install the circuit breaker using the previously removed fasteners.
8. Install wire connections as follows for the 120 **VAC**<sup>1</sup> and 240 VAC models:
  - a. **120 VAC:** On 120 Vac treadmills connect the blue wire from the input module to the LINE terminal on the circuit breaker and the blue wire from the AC line filter to the LOAD terminal on the circuit breaker.
  - b. **240 VAC:** On 240 Vac treadmills connect the blue wire from the input module to the upper LINE terminal on the circuit breaker and the blue wire from the AC line filter to the upper LOAD terminal on the circuit breaker. Connect the brown wire from the input module to the lower LINE terminal on the circuit breaker and the brown wire from the AC line filter to the lower LOAD terminal on the circuit breaker.
9. Set the AC input panel in its mounting position and install using the previously removed fasteners.
10. **Plug**<sup>2</sup> in the power cord and Switch the input power **ON**.
11. Verify treadmill operation per " and return to service.

### .See Also

"Replacement Procedures" on page 48

---

<sup>1</sup>voltage in an alternating current circuit

<sup>2</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

## Drive Belt Replacement

### About

This procedure provides instruction to remove and replace the Drive Belt.



**CAUTION:** Two running belt gauges, Precor part number 20007-101, are required. It is important that this procedure be followed to maintain correct drive belt and running belt tension. Improper tensioning of the belt will lead to premature running belt wear, premature driver roller bearing failure and premature Take-Up roller bearing failure.

### Procedure

Review entire procedure before starting.

#### *Drive Belt Removal*


2. Switch the input power **OFF** and **unplug**<sup>1</sup> the power cord.
3. Remove the front hood.
4. Remove running belt tension by alternately loosening the left and right Take-Up roller mounting/adjustment bolts, but do not remove the mounting bolts, see "[Running Belt Tension and Tracking Adjustment](#)" on page 45.
5. Walk the drive belt off the smaller drive motor pulley. Remove pulley off the drive roller pulley.
6. Alternately loosen and remove the left and right drive roller mounting bolts.



**TIP:** You can put a reference mark on the right drive roller mounting bracket to identify the current drive roller shaft position for re installation.

---



<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



7. Use the drive belt to help lift the roller out of the mounting bracket and then remove the belt off the drive roller pulley, Remove the belt from the treadmill.

#### ***Drive Belt Installation***

8. Place the replacement drive belt onto the drive roller pulley and use the drive belt to help lower and slide the drive roller into the roller mounting bracket. Hand tighten the left and right drive roller mounting bolts.
9. Position the running belt on the rollers so that it is centered and sets square on the deck from the front drive roller to the rear Take-Up roller.
10. Alternately tighten the left and right drive roller mounting bolts to evenly tighten the roller until the left mounting bolt reaches the left mount stop. The left mounting bracket stop sets the roller reference position and the right bolt is used to make final position adjustments. Fully tighten the left mounting bolt against the bracket stop position.
11. Using a measuring tape, measure the distance from the front of the left drive roller shaft to the front of the frame cross beam. Record this reference distance.



12. Adjust the right drive roller mounting bolt so that the right drive roller shaft to frame cross beam distance equals the left side reference distance. This adjustment will make sure that the drive roller is positioned parallel and square to the front of the frame.
13. Install the drive belt onto the drive motor pulley and walk the drive belt onto the larger drive roller pulley.
14. Verify the drive belt alignment and set tension to specification, see "[Drive Belt Tension & Alignment Adjustment](#)" on page 40 procedure.
15. Set the running belt tension to specification and verify tracking, see "[Running Belt](#)



Tension and Tracking Adjustment" on page 45 procedure.

16. Replace the belt guard cover ensuring the tabs are firmly locked into position on the Take-Up roller shaft, see "End Cap & Belt Guard Cover Replacement" on page 66.
17. Replace the end cap, see "End Cap & Belt Guard Cover Replacement" on page 66.
18. Replace the hood cover.
19. Verify treadmill operation per "Operation Verification" and return to service.

### .See Also

"Replacement Procedures" on page 48

"Adjustment Procedures" on page 39

## Drive Motor Replacement

### About

This procedure provides instruction to remove and replace the Drive Motor.

### Procedure

Review entire procedure before starting.

1. Switch the input power **OFF** and **unplug**<sup>1</sup> the power cord.
2. Remove the front hood.
3. Disconnect the drive motor power cable connector from the **OUTPUT** connector on the power control module.



**TIP:** Remove the **MC**<sup>2</sup> fasteners so that the MC module can be raised to allow easy access to disconnect and connect the **I/O**<sup>3</sup> connectors.


4. Remove the drive belt. It is recommended that you walk the belt off the smaller drive motor pulley.

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.

<sup>2</sup>Motor controller or motor controller module

<sup>3</sup>Input and Output Interface.



5. Mark the outline of the current motor mounting plate which will be used as a reference position when you install the replacement motor.
6. Remove the four drive motor mounting bolts. Keep bolts for replacement installation.
7. Set the replacement drive motor onto the frame. Align the motor mount plate to the reference position marks, insert and tighten the four mounting bolts to the torque 204 in-lbs (17 ft-lbs, 23 N-m).
8. Re-install the drive belt. It is recommended that you walk the drive belt onto the larger drive roller pulley.
9. Connect the drive motor connector from the **OUTPUT** connector on the power control module.
10. Verify that the drive belt is properly seated and aligned, see "" on page 42 procedure.
11. Verify the drive belt tension is within specification and adjust as necessary, see "[Drive Belt Tension & Alignment Adjustment](#)" on page 40
12. Re-install hood.
13. **Plug**<sup>1</sup> in the power cord and Switch the input power **ON**.
14. Verify treadmill operation per "" and return to service.

### .See Also

<sup>1</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

"Replacement Procedures" on page 48

"Drive Belt Tension & Alignment Adjustment" on page 40

## Drive Roller Replacement

### About

This procedure provides instruction to remove and replace the Drive Roller.



**CAUTION:** Two running belt gauges, Precor part number 20007-101, are required. It is important that this procedure be followed to maintain correct drive belt and running belt tension. Improper tensioning of the belt will lead to premature running belt wear, premature driver roller bearing failure and premature Take-Up roller bearing failure.

### Procedure

Review entire procedure before starting.


1. Switch the input power **OFF** and **unplug**<sup>1</sup> the power cord.
2. Remove the front hood.
3. Relax the running belt tension by alternately loosening the left and right Take-Up roller mounting/adjustment bolts, but do not remove the mounting bolts.
4. Walk the drive belt off the smaller drive motor pulley. Remove pulley off the drive roller pulley.
5. Alternately loosen and remove the left and right drive roller mounting bolts.



**TIP:** Before loosening the mounting bolts, you can put a reference mark on the right drive roller mounting bracket to identify the current drive roller shaft position used later for re installation.

---



<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



6. Use the drive belt to help lift the roller out of the mounting bracket and then remove the belt off the drive roller pulley,
7. Remove the drive roller.

*Installing the drive roller*

8. Insert the replacement drive roller through the running belt. Use running belt to help lower and slide the drive roller into the mounting bracket.
9. Insert the replacement drive roller through the running belt. Place the drive belt onto the drive roller pulley and use the drive belt to help lower and slide the drive roller into the roller mounting bracket. Hand tighten the left and right drive roller mounting bolts.
10. Position the running belt on the rollers so that it is centered and sets square on the deck from the front drive roller to the rear Take-Up roller.
11. Alternately tighten the left and right drive roller mounting bolts to evenly tighten the roller until the left mounting bolt reaches the left mount stop. The left mounting bracket stop sets the roller reference position and the right bolt is used to make final position adjustments. Fully tighten the left mounting bolt against the bracket stop position.
12. Using a measuring tape, measure the distance from the front of the left drive roller shaft to the front of the frame cross beam. Record this reference distance.



13. Adjust the right drive roller mounting bolt so that the right drive roller shaft to frame cross beam distance equals the left side reference distance. This adjustment will make sure that the drive roller is positioned parallel and square to the front of the frame.
14. Install the drive belt onto the drive motor pulley and walk the drive belt onto the larger drive roller pulley.
15. Verify the drive belt alignment and set tension to specification, see "[Drive Belt Tension & Alignment Adjustment](#)" on page 40 procedure.
16. Set the running belt tension to specification and verify tracking, see "[Running Belt](#)

Tension and Tracking Adjustment" on page 45 procedure.

17. Replace the belt guard cover ensuring the tabs are firmly locked into position on the Take-Up roller shaft (see "End Cap & Belt Guard Cover Replacement" on the next page).
18. Replace the end cap (see "End Cap & Belt Guard Cover Replacement" on the next page).
19. Replace the hood cover.
20. Verify treadmill operation (see ) and return to service.

### .See Also

"Replacement Procedures" on page 48

"Adjustment Procedures" on page 39

"Running Belt and Deck Replacement" on page 81



## End Cap & Belt Guard Cover Replacement


### About

This procedure provides instruction to remove and replace the End Cap and belt guard covers.

### Procedure

Review entire procedure before starting.


1. Switch the input power **OFF** and **unplug**<sup>1</sup> power cord.
2. Remove the four screws (2 lower screws, each side) that retain the end cap. Keep fasteners for installation. **DO NOT** loosen or move the Take-Up roller mounting/adjustment bolts. Doing so will change the running belt's tension and alignment.



3. To remove the end cap, slide the end cap off of the treadmill.

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



4. To remove the belt guard, press inwards on the belt guard to remove the belt guard tabs from the Take-Up roller mounts. Slide the belt guard off of the treadmill.
5. To install the belt guard, slide the replacement belt guard into place so that the tabs on the belt guard engage in both Take-Up roller mounts.
6. To install the rear guard, slide the end cap into place so that the tabs on the end cap engage in the notches in the running belt trim strips.
7. Secure end cap with fasteners.

### **See Also**

"Replacement Procedures" on page 48

"Running Belt and Deck Replacement" on page 81

"Take-Up roller Replacement" on page 86

## Incline Lift Motor Replacement

### About

This procedure provides instruction to remove and replace the Lift Motor.

### Procedure

Review entire procedure before starting.

*Calibrate the replacement Lift Motor prior to installation*

2. Switch the input power **OFF**.
3. Remove the front hood.
4. Lay the replacement Lift Motor in front of the treadmill allowing room for the actuator/ jack screw to freely move up and down.
5. Disconnect the Lift Motor power cable connector from the Power Control Module **INCLINE** connector and connect the replacement Lift Motor power cable.



**TIP:** Remove the **MC**<sup>1</sup> fasteners so that the MC module can be raised to allow easy access to disconnect and connect the **I/O**<sup>2</sup> connectors.

6. Toggle the treadmill circuit breaker from **OFF** to **ON**. The treadmill will begin to auto-reset the actuator to the 0% incline level "Home" position (This is the Lift Motor calibration reference position).



**WARNING:** Be aware that the Lift Motor actuator will begin to auto-calibrate causing movement to the Lift Motor actuator when power is applied to the treadmill.


7. Switch the treadmill power to **OFF** and **unplug**<sup>3</sup> the power cord.
8. Set the actuator 0% incline reference gap (distance between the top of the actuator tube (or nut) to the bottom of the Lift Motor housing). Firmly hold the jack screw from turning and rotate the actuator tube to adjust the reference distance.

---

<sup>1</sup>Motor controller or motor controller module

<sup>2</sup>Input and Output Interface.

<sup>3</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



9. Switch the input power OFF and unplug the power cord.

*Remove the Lift Motor.*

10. Access the Lift Motor from the bottom by carefully laying the treadmill on its side.



**TIP:** If the Lift Motor will raise the treadmill to maximum, you can access the Lift Motor from the front. Connect power and raise the treadmill to maximum incline and resting the frame base onto blocks securely placed under the front corners of the frame (removes weight from the incline platform and Lift Motor actuator tube). Switch power OFF and unplug the power cord.

11. Disconnect the ground wire (green with yellow stripe) from the I frame. Keep screw for motor installable.
12. Remove the lift actuator tube from the lift platform, remove the hitch pin and clevis pin.
13. Remove the Lift Motor actuator housing from the frame mounting bracket. Grasp the Lift Motor and remove the Lift Motor housing mount hitch pin and clevis pin. Remove the Lift Motor from the treadmill

*Install the Lift Motor.*



**NOTE:** Be careful to not allow the actuator tube nut to turn during the installation process. This will cause the actuator reference gap to change.

14. Set the calibrated Lift Motor housing into the frame mounting bracket, replace the upper clevis pin and secure with the hitch pin. Be careful to not turn the actuator tube or jack screw while installing the motor.
15. Install the actuator tube into the incline platform mounting bracket. It may be necessary to slightly rotate the actuator tube to align the clevis pin mounting holes. Choose the adjustment direction that will minimize the change to the actuator tube reference distance. Hold the jack screw from turning while adjusting the actuator tube.

16. Connect the frame ground wire to the treadmill frame, Make sure to route the cable using the frame cable clips to secure the cable in position. Securely tighten the mounting screw to ensure very good electrical connectivity.
17. Connect the Lift Motor connector to the **INCLINE** connector on the power control module. Make sure to route and use the frame cable clips to safely secure the cable away from the jack screw.
18. Connect the Lift Motor connector to the **LIFT** connector on the motor control module. Make sure to route and use the frame cable clips to safely secure the cable away from the jack screw.
19. Return the treadmill to the upright position.
20. Level the Treadmill.
21. Install the hood.
22. **Plug**<sup>1</sup> in the power cord and Switch the input power to **ON**.
23. Verify the treadmill incline operation through the full range of motion. Do the - **INCLINE TEST** diagnostic test.
24. Verify treadmill operation (see ) and return to service.

## See Also

---

"Replacement Procedures" on page 48

"Lift Motor Calibration" on page 43

---

<sup>1</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

## Incline Lift Platform Replacement

### About

This procedure provides instruction to remove and replace the Incline Platform.

### Procedure


Review entire procedure before starting.

1. Switch the treadmill power to **OFF** and **unplug**<sup>1</sup> the power cord.
2. Remove the front hood.
3. Access the incline platform by carefully laying the treadmill on its side.
4. Disconnect the Lift Motor actuator tube from the incline platform mounting bracket by removing the hitch pin and clevis pin. Keep fasteners for installation.



**NOTE:** Be careful to not allow the actuator tube to turn during the removal/installation process. This will cause the actuator reference gap to change and will require recalibration of the Lift Motor, see "[Lift Motor Calibration](#)" on page 43.


5. Remove the left and right incline platform hitch pins from the frame mounting brackets and removal the platform. Keep fasteners for installation.



6. Remove the wheels from the old incline platform and reinstall them on the replacement incline platform.
7. Set the replacement incline platform in its mounting position. Align the key in the incline mounting pin with the key way in the frame and slide the incline mounting pins into place. Secure mounting pins with the hitch pins.

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



8. Install the actuator tube into the incline platform mounting bracket. Hold the jack screw from turning while inserting the actuator tube into the mounting bracket. Secure with clevis and hitch pins.
9. If the Lift Motor actuator tube has turned during the installation process (which changes the incline reference gap distance) re-calibrate the Lift Motor, see "[Lift Motor Calibration](#)" on page 43.
10. Return the treadmill to the upright position.
11. Level the treadmill.
12. Install hood and all removed covers and trim.
13. Connect the power cord and Switch the input power to **ON**.
14. Verify the treadmill incline operation through the full range of motion. Do the - **INCLINE TEST** diagnostic test.
15. Verify treadmill operation (see ) and return to service.

### **See Also**

---

"Replacement Procedures" on page 48

"Lift Motor Calibration" on page 43

## Input Module Replacement


### About

This procedure provides instruction to remove and replace the **AC<sup>1</sup>** Input Module.

### Procedure


Review entire procedure before starting.

1. Set the treadmill circuit breaker to **OFF** and **unplug<sup>2</sup>** the treadmill's power cord from the AC outlet.
2. Remove the treadmill's hood.
3. Remove the two screws that fasten the AC input panel to the frame. Keep fasteners for replacement installation.



AC Input Panel (240 VAC option)

4. Incline the AC input panel from the frame and rotate it to expose the AC line cord clamp screws and input module screws
5. .Remove the mounting screws and remove the AC power cord clamp. Keep fasteners for replacement installation



AC Input Panel Hardware


6. Disconnect the AC line cord from the input module.

<sup>1</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

<sup>2</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



7. Disconnect the wiring from the AC input module (1 blue wire, 1 brown wire and 1 green/yellow wire).
8. Remove the mounting screws and remove the AC input module. Keep fasteners for replacement installation:
9. Set the AC input module in its mounting position with the side with two terminals facing the circuit breaker and install using the previously removed fasteners.
10. Re-connect the AC input module blue wire to terminal **N**, the brown wire to terminal **L** and the green/yellow wire to terminal **E**.



11. Insert the AC line cord firmly into the input module. Set the AC line cord clamp in its mounting position and fasten it with the previously removed fasteners.
12. Reinstall hood.
13. **Plug**<sup>1</sup> in the power cord and Switch the input power **ON**.
14. Verify treadmill operation per "" and return to service.

### .See Also

"Replacement Procedures" on page 48

---

<sup>1</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

## Line Filter Replacement


### About

This procedure provides instruction to remove and replace the **AC**<sup>1</sup> Line Filter.

### Procedure


Review entire procedure before starting.

1. Set the treadmill circuit breaker to **OFF** and **unplug**<sup>2</sup> the treadmill's power cord from the AC outlet.
2. Remove the treadmill's hood.
3. Remove the two screws that fasten the AC input panel to the frame. Keep fasteners for replacement installation.



AC Input Panel (240 VAC option)

4. Disconnect the wiring from the circuit breaker (2 blue wires on 120 Vac treadmills or 2 blue and 2 brown wires on 240 Vac treadmills) Note: The figure below is showing a 240 volt configuration.
5. Lift the AC input panel from the frame and rotate it to expose the AC input circuit breaker screws.



AC Input Panel Hardware

<sup>1</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

<sup>2</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.

6. Remove the two screws and remove the circuit breaker. Keep fasteners for replacement installation.
7. Set the replacement AC line filter in its mounting position with the three terminals facing the circuit breaker and secure with previously removed screws.
8. Re-attach wire connections as follows for the 120 **VAC**<sup>1</sup> and 240 VAC models:
  - a. On 120 Vac and 240 Vac treadmills, connect the blue wire from the power control module to the L1 terminal on the LOAD side of the AC line filter and the brown wire from the power control module to the L2 terminal on the LOAD side of the AC line filter.
  - b. On 120 Vac treadmills, connect the blue wire from the input module to the L1 terminal on the LINE side of the AC line filter, the brown wire from the circuit breaker to the L2 terminal on the LINE side of the AC line filter and the green/yellow wire to the (non-insulated) terminal mounted directly on the line filter case.
  - c. On 240 Vac treadmills, connect the blue wire from the circuit breaker to the L1 terminal on the LINE side of the AC line filter, the brown wire from the circuit breaker to the L2 terminal on the LINE side of the AC line filter and the green/yellow wire to the (non-insulated) terminal mounted directly on the line filter case.
9. Set the AC input panel in its mounting position and install using the previously removed fasteners.
10. **Plug**<sup>2</sup> in the power cord and Switch the input power **ON**.
11. Verify treadmill operation per "" and return to service.

### .See Also

"Replacement Procedures" on page 48

---

<sup>1</sup>voltage in an alternating current circuit

<sup>2</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

## Power Control Module Replacement


### About

This procedure provides instruction to remove and replace the Power Control Module (IFT<sup>1</sup> Drive).

### Procedure

Review entire procedure before starting


1. Switch the input power **OFF** and remove power cord.
2. Remove the front hood.
3. Disconnect the **COMM**, **INCLINE**, **INPUT**, **DB<sup>2</sup>** and **OUTPUT** connectors from the power control module.



4. Remove the four screws that mount the power control module. Keep fasteners for installation.

<sup>1</sup>Integrated Footplant Technology: IFT recognize this change in speed when your foot strikes the belt and adjust to match every stride, resulting in a smooth, fluid feel that enhances the workout experience.

<sup>2</sup>1) DB or DBR: treadmill dynamic break resistor 2) Decibel (dB): In electronic systems, the decibel (dB) is a logarithmic unit of measurement used to express the system power gain (+dB) or loss (-dB) in decibels (dB).  $dB(\text{power}) = 10\text{Log } P_{\text{out}}/P_{\text{in}}$  or, in terms of voltage,  $dB(\text{power}) = 20\text{Log } (V_{\text{out}}/V_{\text{in}})$ .



5. Set the replacement power control module in its mounting position.
6. Install and tighten the four mounting screws.
7. Reconnect the **COMM**, **INCLINE**, **INPUT**, **DB** and **OUTPUT** connectors. The mating connectors are keyed to insure proper contact pin alignment and fit.
8. Reinstall the hood.
9. Plug in the power cord and Switch the input power **ON**.
10. Verify treadmill operation (see [Operation Verification](#)) and return to service.

### See Also

---

"Replacement Procedures" on page 48

## Power Cord Replacement

### About

This procedure provides instruction to remove and replace the power cord.



**CAUTION:** Use only Precor OEM power cords. Do not remove or otherwise bypass the 3-prong plug with an adapter to use a non-grounded outlet. Do not plug the unit into a power transformer in an attempt to adjust the voltage requirements. Failure to follow these instructions might damage the unit and void the Precor Limited Warranty.




**CAUTION:** The treadmill requires a 20-amp individual branch circuit grounded per NEC (National Electric Code) guidelines or local region electric code.

### Procedure

Review entire procedure before starting.


1. Set the treadmill circuit breaker to **OFF** and **unplug**<sup>1</sup> the treadmill's power cord from the **AC**<sup>2</sup> outlet.
2. Remove the treadmill's hood.
3. Remove the two screws that fasten the AC input panel to the frame. Keep fasteners for replacement installation.



4. Lift the AC input panel from the frame and rotate it to expose the AC power cord clamp screws.

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.

<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.



5. Remove the fasteners that retain the AC power cord clamp and remove the clamp. Keep fasteners for replacement installation.
6. Disconnect the AC power cord from the input module.
7. Feed the end of the replacement AC power cord that mates with the input module through its hole in the frame and firmly insert it into the input module.
8. Set the AC power cord clamp in its mounting position and install using the previously removed fasteners.
9. Set the AC input panel in its mounting position and install using the previously removed fasteners.
10. **Plug**<sup>1</sup> in the power cord and Switch the input power **ON**.
11. Verify treadmill operation per "" and return to service.

### .See Also

"Replacement Procedures" on page 48

---

<sup>1</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

## Running Belt and Deck Replacement

### About

This procedure provides instruction to remove and replace the Running Belt.




**CAUTION:** Two running belt gauges, Precor part number 20007-101, are required. It is important that this procedure be followed to maintain correct drive belt and running belt tension. Improper tensioning of the belt will lead to premature running belt wear, premature driver roller bearing failure and premature Take-Up roller bearing failure.

### Procedure

Review entire procedure before starting.

1. Switch the input power **OFF** and **unplug**<sup>1</sup> the power cord.
2. Remove the front hood.
3. Remove the end cap and belt guard covers (see "End Cap & Belt Guard Cover Replacement" on page 66).
4. Remove the left and right deck trim covers
5. Remove the Take-Up roller, see "Take-Up roller Replacement" on page 86.
6. Remove the Drive Roller, see "Drive Roller Replacement" on page 62.
7. Remove the four mounting bolts and the roller guard that hold the deck to the frame.




<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



8. Lift the deck and running belt up and away from the treadmill.
9. If installed, remove the Auto Stop magnet from the deck, see "[Auto Stop Magnet Replacement](#)" on page 49.
10. Slide the running belt off the deck and discard. Remove and keep the deck mounting inserts.
11. If the deck has already been flipped (flipped surface is used), discard and replace with new deck. Re-install the deck mounting inserts.
12. If the deck has not be flipped (flipped surface is new), flip deck and re-install the deck mounting inserts into the used side of the deck surface.
13. The new running belt will have a directional arrow placed on the inside of the belt. The arrow indicates the correct direction of travel. Slip the running belt onto the deck with the arrow pointing in the direction of travel.



**CAUTION:** Incorrectly installed running belt direction will cause the belt to wear prematurely.



14. Carefully place the deck with running belt onto the deck.
15. Reinstall the Auto Stop Magnet on the right front corner of the deck, see "[Auto Stop Magnet Replacement](#)" on page 49.
16. Slide the take up roller through the running belt and install in the frame mounting bracket. Hand tighten the mounting bolts into the take up roller shaft.

17. Align the bottom plate and pivot bracket holes with the running deck bolt holes. Replace the roller guard, install and hand tighten the deck mounting bolts.
18. Verify that the spacing on all four corners is the same, adjust as necessary.
19. Check the alignment of the magnet and the auto stop assembly, see "[Auto Stop Sensor Replacement](#)" on page 51.
20. Tighten and torque the Deck mounting bolts to 150 in-lbs (17 N-m).
21. Reinstall the Drive Roller and Drive Belt, see "[Drive Roller Replacement](#)" on page 62.
22. Reinstall the Take-Up roller, see "[Take-Up roller Replacement](#)" on page 86.
23. Tension and verify the running belt tracking, see "[Running Belt Tension and Tracking Adjustment](#)" on page 45.
24. Replace the belt guard cover ensuring the tabs are firmly locked into position on the Take-Up roller shaft, see "[End Cap & Belt Guard Cover Replacement](#)" on page 66.
25. Replace the end cap, see "[End Cap & Belt Guard Cover Replacement](#)" on page 66.

*New Deck break-in*

26. Straddle the running belt and set the speed to 3 mph (5 kph). While holding the treadmill handles, walk onto the middle of the running belt starting from the back walking to the front and returning to the back. Repeat walking process 4 times.



27. Repeat the process on walking on the right side of the belt.

28. Repeat the process walking on the left side of the belt.




**NOTE:** It may be necessary to override the treadmill auto-stop function.

29. Stop the treadmill and step off the belt.

30. Set the treadmill to the maximum speed and run for 3 minutes.

**NOTE:** This process helps to remove excess wax from the belt.

31. Clean up any loose wax from the deck sides and frame.



32. Verify treadmill operation (see ) and return to service.

### .See Also

"Adjustment Procedures" on page 39

"Running Belt Tension and Tracking Adjustment" on page 45

## Take-Up roller Replacement

### About

This procedure provides instruction to remove and replace the Take-Up roller.



**CAUTION:** Two running belt gauges, Precor part number 20007-101, are required. It is important that this procedure be followed to maintain correct drive belt and running belt tension. Improper tensioning of the belt will lead to premature running belt wear, premature driver roller bearing failure and premature Take-Up roller bearing failure.


### Procedure

Review entire procedure before starting.

1. Switch the input power **OFF** and **unplug**<sup>1</sup> the power cord.
2. Remove the front hood.
3. Remove the end cap and belt guard covers (see "End Cap & Belt Guard Cover Replacement" on page 66).
4. Remove the left and right deck trim covers.

#### *Removal Instructions*

5. Remove running belt tension by alternately loosening the left and right Take-Up roller mounting/adjustment bolts. Remove the mounting bolts, lift and slide the Take-Up roller out of the running belt.



#### *Installation Instructions*

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.

6. Slide the new Take-Up roller through the running belt and slide into position. Evenly hand tighten the left and right Take-Up roller mounting bolts a few turns only.
7. Tension the running belt to specification and verify tracking, see ["Running Belt Tension and Tracking Adjustment"](#) on page 45.
8. Replace the belt guard cover ensuring the tabs are firmly locked into position on the Take-Up roller shaft, see ["End Cap & Belt Guard Cover Replacement"](#) on page 66.
9. Replace the end cap (see ["End Cap & Belt Guard Cover Replacement"](#) on page 66).
10. Replace the hood cover.
11. Verify treadmill operation (see [Operation Verification](#)) and return to service.

### .See Also

["Replacement Procedures"](#) on page 48

["Running Belt Tension and Tracking Adjustment"](#) on page 45

["Running Belt and Deck Replacement"](#) on page 81

# Troubleshooting

## About

This section contains troubleshooting information to help you identify, isolate, and resolve component and system issues.

Review the *Introduction To Troubleshooting* section below to learn about the troubleshooting process, troubleshooting best practices, and other pertinent information that will help you efficiently troubleshoot issues and return the equipment to service.

Information that will help you troubleshoot:

- Review the "[Introduction To Troubleshooting](#)" below section below.
- Review the Error Log for active error codes, see the "[Error Log & CPA Event Log](#)" on [page 95](#) and "[Standard Error Codes](#)" on [page 92](#) topics.
- Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting repair information.
- If the machine supports the Active Status Light feature, review the [ASL<sup>1</sup>](#) topic (see [Active Status Light \(ASL\)](#)).
- Review the System Troubleshooting Procedures topic for possible related issue fixes or repairs, see "[System Troubleshooting Procedures](#)" on [page 99](#).

## Introduction To Troubleshooting

Troubleshooting issues is an investigative process best implemented utilizing a systematic approach that efficiently targets the issue cause allowing correct equipment repairs and return to service. The following information will help you to systematically troubleshoot and resolve issues.

## Basic Steps

### Validate the customer reported issue:

The failure that is reported may differ from your observations as a trained technician. Many reported failure are not true failures and can be fixed without a customer visit.

- (powered units only) Always ask the customer if the unit power is connected and switched ON.
- Further interrogate the customer to determine if this is the real issue requiring an on-site visit or possibly a different issue that can be simply resolved over the phone.

---

<sup>1</sup>Active Status Light: Service and maintenance status light.

## Verify the Input Power (Powered units only)

Always begin by verifying the input power cord is connected and the equipment power is switched "ON".

If the unit does not power up or runs poorly, verify the following conditions:

- Make sure there is power at the outlet receptacle and that the power is within the specified voltage and current Limits. If not:
  - The power outlet circuit wire run from the outlet to the circuit panel may be too long causing a large voltage drop.
  - The outlet circuit wire gauge may be too small to carry the required machine load current.
- Make sure that the outlet receptacle power is good quality (the input power is NOT intermittent or has fluctuating voltage levels or frequency). Poor quality input power can cause operational failures.
- Make sure that only one machine is plugged into the outlet receptacle (only one receptacle per outlet receptacle).



**IMPORTANT:** Always make sure the input power is good quality before troubleshooting the machine. A poor quality input power signal may be the cause of the machine issue or operating failure.

## Verify that the console is operating correctly

1. On LED consoles (P10, P30, P30i and P31) make sure the console powers up and is working correctly, perform the following verification tests:
  - a. If the console does not power up, make sure the Data COMM cable is properly connected at the console and **LPCA**<sup>1</sup> and in good condition.
  - b. Run the console Display, and Keypad diagnostic tests (see "[Hardware Validation Diagnostics Tests Menu \(51765761\)](#)" on page 20). Resolve any failures.
2. On Touchscreen consoles (P62, P80, and P82) make sure the console powers up and is working correctly, perform the following verification tests:
  - a. If the console does not power up, make sure the external **AC<sup>2</sup>/DC<sup>3</sup>** power adapter is plugged in and connected to the console. Also make sure the AC/DC adapter brick is in good condition.

---

<sup>1</sup>Lower printed circuit assembly; generally this refers to the lower board. On treadmills, this is the motor controller unit (MCU), and on self-powered units, it is the main board in the lower section.

<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

<sup>3</sup>Direct Current: electrical current that only flows in one direction.



b. Run the following console System Tests (see [System Tests](#)):

- Touchscreen Test
- Touchscreen Calibration
- Backlight Test
- RGB Test
- Numeric Backlight Test
- Numeric Display Test



**Note:** Keep in mind that if a key on the console keypad does not function, the LPCA will not receive a user initiated request for action. For failed console key problems, the machine failure is not caused by a problem with the LPCA or the machine base, In these types of console failures, no error codes will be triggered and logged.

## Review the Error Log or CPA Event Log for any active error codes

Always review the Error Log or CPA Event Log when troubleshooting an issue. The error logs will contain any triggered error code events and related information. You can then refer to the [Error Code Troubleshooting Guide](#) for information to help resolve the issue. Also, when calling Precor customer service for assistance, refer to the Error Log or CPA Event Log for additional information to help the representative resolve the issue.

Refer to [Error Code Troubleshooting Guide](#) the for error code descriptions and repair information.



**IMPORTANT:** Error code descriptions and troubleshooting information can be found in the *Error Code Troubleshooting Guide*, see [Error Code Guide Troubleshooting Guide](#).



**Note:** Not all failures trigger an error event code. Many issues are purely mechanical in nature and therefore cannot trigger an error event code.

## Verify (reproduce) the issue.

Operate the unit in normal user mode and attempt to reproduce the reported failure Determine if the error is a repeatable or intermittent type failure Make note of any additional observations (noises, vibrations, etc.) that occur at the time of the failure which may then be used to help resolve the issue.



**Note:** It is important to keep in mind that some issues are weight (load) related. You may need to test the unit at minimum and maximum load Limits to reproduce the failure.

## Perform hardware validation diagnostic tests

Perform the equipment [Hardware Validation Tests](#) (LED consoles) or [System Tests](#) (Touchscreen consoles) to help isolate the cause of the issue. These tests will help identify failed system components. Resolve any resulting failures.

## Verify Club Settings

Verify that one of the workout limit settings are not causing a failure, see [Club Settings](#) (LED consoles) or [System Settings Workout Limits](#) (Touchscreen consoles). If a failure is observed while using the machine but passes the hardware validation system tests, this could be an indication that one of the club parameters Limits settings is causing the issue.

## Verify that there are no new error codes

After correcting the issue, reopen the Error Log and verify that there are no remaining active error codes. This will verify that the original error codes are not reoccurring and that there are no new error code issues. If the error code is reoccurring, the issue may be mileage related, review the error code odometer history to verify if the error event is related to mileage intervals.

On P10, P30, P30i and P31 consoles, clear the error log by pressing and holding the "Quick Start" key.



**Note:** If there is no logged error codes and the issue persists, you will need to use observable and audible indicators to identify the source of the failure. Also make sure that there are no related service bulletins that may resolve the issue. Browse the list of available Troubleshooting procedures for related Troubleshooting information.

## Verify service bulletins

Review the list of machine service bulletins and tech-tips and verify that there are no current bulletins that may fix the issue.


## Standard Error Codes

### About

There is a set of standard error codes implemented across Precor cardio exercise equipment. Error codes are system generated codes that identify specific machine fault conditions. The maintenance software monitors error code event conditions, when a fault is detected, the error code is generated and stored in the Error Log (or CPA<sup>1</sup> Event Log) along with related machine metrics, such as, the machine mileage (or hours), the time, drive motor current, etc.

Error code numbers range from 01 to 99. There are also a small number of alpha and alpha-numeric codes. Most, but not all error codes are grouped into numeric ranges to help easily identify common system issues. Refer to the [Error Code Troubleshooting Guide](#) for a complete list of error codes and troubleshooting information.

**IMPORTANT:** Error code descriptions and troubleshooting information can be found in the *Error Code Troubleshooting Guide*, see [Error Code Guide Troubleshooting Guide](#).



<sup>1</sup>Touchscreen console Control Processing Assembly.

## Viewing Error Codes (Error Log & Event Log)

Error event codes are logged, stored, and viewed in either the **Error Log** on LED consoles (P10, P30, P30i and P31) or the **CPA Event Log** on touchscreen consoles (P62, P80, and P82), see [Error Log & CPA Event Log](#).

How to access the Error Log:

- On LED consoles (P10, P30, P30i and P31): access the **Information Display (65)** > select **Error Log**.
- On touchscreen consoles (P62, P80, and P82): access the **Service Settings menu (51765761)** > select **About > CPA Event Log**



**TIP:** Error codes can be deleted from the Error Log on LED consoles (P10, P30, P30i and P31). Press and hold the **PAUSE/RESET** key for a minimum of 6 seconds to open the Error Log and view all logged error codes. If there are no logged error codes, the "Stuck Key" message will show. To remove error codes, select the error code and press/hold the **QUICK START** key until the "NO ERRORS" message shows.



**Note:** On touchscreen consoles (P62, P80, and P82), error codes cannot be deleted from the CPA Event Log (or Error Log).

## Error Code and Troubleshooting Guide

Use the *Error Code Troubleshooting Guide* to learn about the error code and to help troubleshoot and repair the machine. The *Error Code Troubleshooting Guide* provides a complete list of all supported error codes and information about the error code including the code description, related issues and symptoms associated with the error, troubleshooting steps, and repair procedures, see [Error Code Troubleshooting Guide](#).

- The error code description.
- The affected system components.
- The Issues and Symptoms associated with the fault condition.
- Troubleshooting steps and repair instructions.

## Troubleshooting with Error Codes

### Getting Started

You will need a copy of the "*Error Code Troubleshooting Guide*" to learn Information about the error codes including the code description, related issues/symptoms, troubleshooting and repair information, click [Error Code Troubleshooting Guide](#).

### Using Error Codes to troubleshoot

1. Review the equipment Error Log (or CPA Event Log) to identify any current active error codes. Also review the error code history for any past error codes that may provide

insight to the current active error code issue.

2. Next go to the error code topic in the *Error Code Troubleshooting Guide* and review the error code troubleshooting and repair information.



**Note:** Be aware that not all machine failures will cause an error code event. Use physical observation and mechanical troubleshooting skills to resolve non error code issues.

## Error Log & CPA Event Log

### About

The Error Log is a service maintenance display used to store "log" and view detected error codes. On LED consoles (P10, P30, P30i and P31) you use the "Error Log" to view error codes. However, on touchscreen consoles (P62, P80, and P82) you use the "CPA<sup>1</sup> Event Log" and not the "Event Log" to view error codes.



**IMPORTANT:** On touchscreen consoles (P62, P80, and P82), use the **CPA Event Log** and not the **Event Log** to view the Error Code Troubleshooting Guide service error codes. The Event Log includes additional communication and OEM non-service error codes.

The maintenance software monitors error code event conditions, when a fault is detected, the error code is generated and stored in the Error Log (or CPA Event Log) along with related machine metrics, such as, the machine mileage (or hours), the time, the drive motor current when applicable, etc.

Error event codes are sequentially stored as a table in memory on a First-In Last-Out basis, the newest error code is stored in the number one position pushing any stored error codes down one position. When the memory is full, the next code is stored pushing the oldest error code from the table removing it from memory.

Special circumstances (repeating errors)

When an error event is detected, the error code information will be stored into the error log. However, when multiple instances of the same error code event occur within the same hour or odometer reading, only the first occurrence will be logged. One of the following conditions must occur to cause a repeating error code to be subsequently logged:

- the elapsed time must exceed one hour from the first occurrence
- or the odometer mileage must change from the first occurrence
- or a different intervening error code is logged



**Note:** Multiple repeating instances of the same error code event occurring during the same hour or odometer reading will only be logged as a single error code event.

### *Troubleshooting*

Always review the Error Log or CPA Event Log when troubleshooting an issue. The error logs will contain any triggered error code events. You can then refer to the *Error Code Troubleshooting Guide* ([Error Code Troubleshooting Guide](#)) to learn about the error code and information to help resolve the issue.

---

<sup>1</sup>Touchscreen console Control Processing Assembly.



**Note:** Be aware that not all machine failures will cause an error code event. Use physical observation and mechanical troubleshooting skills to resolve non error code issues.

## LED Console (P10, P30, P30i and P31) Error Log

menu: **Information Display (65) > Error Log.**

On LED consoles (P10, P30, P30i and P31), error codes are viewed on the **Error Log**.

### *Understanding Error Codes*

Each logged error event code will be shown on the console message display. The individual data parameters will scroll across the display. Use the Up/Down keys to scroll thru and view the individual error codes.

Typical Error Log data:

- Error Log sequential line item number, 1 thru "n" (1 is the newest error code and "n" is the oldest)
- [Error Code](#) Number
- [Error Code](#) Description
- Odometer
- Hours
- Motor Current\*
- .Input Line Current\*
- Input line voltage\*
- Buss Voltage\*

Note: \* machine dependent parameter.

### *Removing Error Event Codes:*

To remove an error code, select the error code to be removed and press/hold the **QUICK START** key for a minimum of 6 secs until the ."NO ERRORS" message shows.



**TIP:** Error code delete shortcut: Press and hold the **PAUSE/RESET** key for a minimum of 6 seconds to open the Error Log and view all logged error codes. If there are no logged error codes, the "Stuck Key" message will show. To remove error codes, select the error code and press/hold the **QUICK START** key until the "NO ERRORS" message shows.


## Touchscreen Console (P62, P80, and P82) CPA Event Log

menu: **Service menu (51765761) > About > CPA Event Log**

On touchscreen consoles (P62, P80, and P82) you will use the **CPA Event Log** to view the relevant error codes and not the **Event Log**. The CPA Event Log only include machine error codes included in the *Error Code Troubleshooting Guide*.

*Understanding the error code data result*

The touchscreen console (P62, P80, and P82) CPA Event Log provides the same error code data found in the LED console (P10, P30, P30i and P31) Error Log plus the event occurrence date & time information. The error code "CPA ERROR" identifier indicates that this is a machine fault error code that can be used along with the *Error Code Troubleshooting Guide* to help resolve the issue.



CPA Event Log - Error Code Data Result

Typical CPA Event Log data:

- Error Code Data
  - Event Time & Date Stamp
  - [Error Code](#) Number
  - [Error Code](#) Description
  - Odometer
  - Hours
  - Motor Current\*
  - .Input Line Current\*
  - Input line voltage\*
  - Buss Voltage\*
  - OEM Factory only data

Note: \* machine dependent parameter.

*Removing Error Codes*

Unlike the Error Log used on LED consoles (P10, P30, P30i and P31), you cannot manually delete (clear) error codes from the touchscreen console (P62, P80, and P82) CPA Event Log or the Event Log.



**Note:** On touchscreen consoles (P62, P80, and P82), error codes cannot be deleted from the CPA Event Log or the Event log.





## System Troubleshooting Procedures

System troubleshooting procedures provide information and procedures to help you troubleshoot and repair treadmill issues.

### Available Troubleshooting Procedures

- "Auto Stop Troubleshooting " on the next page
- "Tripped Circuit Breaker" on page 119
- "Communications Error Troubleshooting" on page 106
- "No Power to the Console Troubleshooting" on page 107
- "Drive Motor System Troubleshooting" on page 108
- "E-Stop Not Communicating" on page 111
- "Heart Rate Monitor Troubleshooting" on page 112
- "Incline System Troubleshooting" on page 115
- "Input Power and Machine Controls Troubleshooting" on page 116
- "Running Belt and Deck Troubleshooting" on page 117

### See Also

"Troubleshooting" on page 88

## Auto Stop Troubleshooting

This procedure will provide troubleshooting steps for the Auto Stop feature

### Related Error Codes

Auto Stop error codes: 60, 61.


Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting information.

### Procedure:

1. If the Console message is "Temporarily Out of Order" on the P80 console or "Please use another Treadmill" on the P10, P20, or P30 console go *Run Hardware Validation Tests* below.
2. Check the treadmill to ensure the Auto Stop hardware is installed.
  - If the Auto Stop hardware is not installed, contact Precor customer support to see if your treadmill is compatible for the Auto Stop or arrange the installation of the Auto Stop hardware.
3. Verify that the Auto Stop cable is plugged into the correct port in the console. The connector for the Auto Stop is the same number of pins as the connector for the heart rate grips, and you need to make sure that they were not reversed.
  - a. If the cables were reversed, swap the connectors and re-test.
  - b. If the cables were correctly connected, continue
4. If the Auto Stop hardware is installed, access the club settings and check if the Auto Stop feature is enabled. If it is not enabled, enable the feature, see .


#### *Run Hardware Validation Tests*

5. Access the service access software Hardware Validation Tests (see and select the **Auto Stop** test. If the feature is enabled the P80 **Auto Stop** sensor test will count the number of times the magnet crosses the sensor. The P10, P20, or P30 consoles will display **USER DETECTED** if motion is detected from the running deck or **NO USER DETECTED** if no motion is detected from the running deck. If the unit passes this test or a **USER DETECTED** message is displayed and the **Auto Stop** feature does not function contact Precor Customer Support. If the **Auto Stop** did not pass the test continue troubleshooting.



**CAUTION:** Do not place the Auto Stop Magnet on or near a steel structure. If the magnet assembly comes in contact with a steel structure and then pulled away from the steel structure, the magnet can become dislodged from the magnet assembly housing. Contact PRECOR customer service for repair or replacement.

6. The Auto Stop system consists of a magnet holder mounted to the right front corner of the deck and a Hall Effect sensor mounted to the drive roller bracket of the frame. Check the alignment and gap (3/16") between the Auto Stop magnet holder and the Auto Stop sensor. If the alignment and gap are not correct, it may be necessary to loosen the deck and adjust so that the magnet is gaped and positioned properly relative to the sensor. Reference Procedure, Replacing the Auto Stop Magnet. If the alignment and the gap between the Auto Stop magnet holder and the Auto Stop sensor are correct continue with step 9.
7. The Auto Stop sensor will display a green blinking LED visible next to the connector, indicating that power is being applied to the sensor board. The LED does not tell you if the voltage is correct, just that it is present. If the LED is not lit or if LED is lit continue with the next step.



8. The connector has 3 wires (red, black, and green), which can be metered for troubleshooting. Unplug the Auto Stop connector from the Auto Stop Sensor.
9. Place the meter red lead to the red wire and black lead to the black wire of the Auto Stop connector. The meter should indicate 5 volts +/- 0.1 volt. If 5 volts is present continue with the next step.
10. If the 5 volts is not present or significantly low temporarily replace the Auto Stop cable with a known good cable and repeat step 10. If the 5 volts is not present or the voltage is still significantly low replace the console or upper PCA<sup>1</sup>. If 5 volts is present permanently replace the Auto Stop cable.



**NOTE:** The running belt does not need to be moving for this test.

11. With the Auto Stop connector plugged into the Auto Stop sensor place the meter red lead to the green wire and black lead to the black wire. The meter should indicate 5 volts +/- 0.1 volt. While monitoring this voltage, have someone step onto the deck and bounce up and down. The voltage between the black and green wires should fluctuate between bounces. If the voltage does not change, replace the Auto Stop Sensor.
12. If you have completed all the previous steps and Auto Stop will still not function correctly, contact Precor Customer Support.

## See Also

"System Troubleshooting Procedures" on page 99

<sup>1</sup>Printed circuit assembly, generally referred to as either an upper PCA or lower PCA.

## Tripped Circuit Breaker

Troubleshooting a tripped treadmill ON/OFF circuit breaker or facility outlet circuit breaker. Review the electrical requirements, see "[General Information](#)" on page 5.

It is extremely important to know whether it is the treadmill circuit breaker or the facility wall outlet circuit breaker that trips. It is also extremely important to know when the breaker trip occurs, choose one of the following trip events:

- Immediately on power up
- After the belt starts but before the exerciser walks onto the belt
- After the exerciser walks onto the belt.

### If the facility outlet circuit breaker trips

- Measure the facility wall outlet voltage. If the is approximately 0 VAC<sup>1</sup>, the wall breaker has tripped.
- Inspect the power cord, if damaged, replace the line cord. If the line cord is not damaged continue with the following steps.
- Verify whether there is more than one treadmill on the same outlet circuit breaker. This will be especially evident if two or more treadmills shutdown at the same time. To verify if multiple treadmills are sharing the same wall breaker, manually switched OFF the wall breaker. If more than one treadmill loses power, the treadmills are on the same breaker.
  - If YES, advise the customer to have their facility wiring upgraded per Precor specifications.
  - If NO, continue troubleshooting.



**IMPORTANT:** If the AC<sup>2</sup> circuit feeding a treadmill is found to be a non-dedicated branch circuit or a circuit equipped with a capacity of less than 20 amps, the AC circuit must be corrected before any reliable Troubleshooting can be performed. More importantly, a non-dedicated branch circuit may constitute a safety hazard to the treadmill operator.

- Verify the wall outlets do not share neutral wiring and that each wall outlet is on an individual branch circuit. An individual branch circuit will have its own load line, neutral line and ground line. To verify that the treadmill is not on an individual branch circuit use an AC voltmeter measure from the hot contact of one AC receptacle to the neutral contact of another AC receptacle. If AC line voltage is present then the treadmills are sharing neutral lines.
  - If YES, advise customer to have their facility wiring upgraded per Precor specifications, and then continue to step 5.
  - If NO, continue troubleshooting

---

<sup>1</sup>voltage in an alternating current circuit

<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.



**CAUTION:** The treadmill requires a 20-amp individual branch circuit grounded per NEC (National Electric Code) guidelines or local region electric code.

- Measure the AC input voltage with the treadmill unloaded (running belt moving, with no one walking on the running belt) and then again while loaded (someone walking/running on the belt). The difference between the two states should be no more than about 6 volts RMS, and ideally less.
  - If the voltage variance is more than 6 volts RMS, the distance the branch circuit wire are runs maybe very long or may have used smaller diameter wire. Recommend to the club that they should consult with an electrician if this is suspected.
  - If NO, continue troubleshooting.
- Weight overloading is the most frequent cause of treadmill shutting down. Overloading is most often caused by excess deck/belt friction, but can be made worse by line voltage conditions. This condition happens more often with heavier runners, but never walkers. In high exerciser clubs (10 hours or more of use per day), the decks/belts will wear out much faster than at other locations, sometimes in months rather than years. It is often accompanied by error codes 27, 28, or 29, see "Troubleshooting the 3 Phase AC Drive Motor System."

#### If the Treadmill ON/OFF circuit breaker is tripped:

- Verify the wall outlets do not share neutral wiring and that each wall outlet is on an individual branch circuit. An individual branch circuit will have its own load line, neutral line and ground line. To verify that the treadmill is not on an individual branch circuit use an AC voltmeter measure from the hot contact of one AC receptacle to the neutral contact of another AC receptacle. If AC line voltage is present then the treadmills are sharing neutral lines.
  - If YES, advise customer to have their facility wiring upgraded per Precor specifications, and then continue with step 2.
  - If NO, continue troubleshooting.



**CAUTION:** The treadmill requires a 20-amp individual branch circuit grounded per NEC (National Electric Code) guidelines or local region electric code.

- Verified that a long distance branch run has inadequate gauge wire.
  - If YES, advise customer to have their facility wiring upgraded per Precor specifications.
  - If NO, continue troubleshooting.
- Verify the input line voltage; Low line voltage for the U.S. is any voltage below 108 VAC, measured while the treadmill circuit breaker is switched "ON" and the running belt is stopped. For international, low line voltage is anything below 200 VAC while the treadmill circuit breaker is switched "ON" and the running belt is stopped. Measure the line voltage with the treadmill circuit breaker is switched "ON", and the running belt is stopped. Record the voltage. Then measure the voltage again using the instantaneous voltage drop using the min/max function on your volt meter while someone is running on the treadmill at 7.0 MPH or higher.

- If any measurement is below 108 VAC (US) or 200 VAC (International), advise the customer to have their facility wiring inspected by an electrician.
- If the measurements are at or above 108 VAC (US) or 200 VAC (International), continue troubleshooting.
- Does the treadmill trip its breaker immediately on power up?
  - If YES, it is likely that there is a shorted component (line filter, lower control module) or faulty/shorted wiring.
  - If NO, continue with the following steps.
- Does the treadmill power up, but trips the breaker after the motor is started?
  - If YES, it is likely that there is a bad roller or bad drive motor.
  - If NO, continue with the following steps.
- Does the drive motor start up fine, but trips the breaker after an exerciser walks/runs on the running belt?
  - If YES, Overloading is the most frequent cause of treadmill shutting down. Overloading is most often caused by excess deck/belt friction, but can be made worse by line voltage conditions. The overloading condition happens more often with heavier runners, but never walkers. In high exerciser clubs (10 hours or more of use per day), the decks/belts will wear much faster than at other locations, sometimes in months rather than years. It is often accompanied by error codes 27, 28, or 29. Perform an amp draw test in the "[Running Belt and Deck Troubleshooting](#)" on page 117 procedure.

## See Also

---

"[System Troubleshooting Procedures](#)" on page 99



## Communications Error Troubleshooting

Go to the error log and note any occurrences of the error codes related to communications issues.

### Related Error Codes

Communications error codes: 30 through 33.

Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting information.

### Procedure

Refer to the [Error Code Troubleshooting Guide](#).

### See Also

---

"System Troubleshooting Procedures" on page 99

## No Power to the Console Troubleshooting

**Applies To:** P10, P20, or P30 consoles only.

This procedure only applies to treadmill powered consoles.

1. Verify that the treadmill input power is correct, see "[Tripped Circuit Breaker](#)" on [page 119](#).
2. Remove the treadmill hood and measure the **AC**<sup>1</sup> voltage at the input side of the line filter. Verify that line voltage is present when the breaker switch is turned on.
  - a. If NO, replace the breaker switch.
  - b. If YES, continue troubleshooting.
3. Measure the AC voltage at the output side of the line filter. Verify that line voltage is present when the breaker switch is turned on.
  - a. If NO, Replace the line filter.
  - b. If YES, continue troubleshooting.
4. Use a known good console and communication cable. **Plug**<sup>2</sup> the test console and test communications cable into the suspect treadmill lower control module (**IFT**<sup>3</sup> drive). Does the test console power up?
  - a. If NO, replace the lower control module (IFT drive).
  - b. If YES, continue troubleshooting.
4. If the test console powered up, re-connect the test communications cable from the test console to the original console. Does the original console power up?
  - a. If YES, replace the Communications Cable.
  - b. If NO, replace the upper **PCA**<sup>4</sup>.



**CAUTION:** Swapping a lower control module from a good unit into a bad unit could damage the lower control module from the good unit. If the control module that is being swapped may have a defect and could damage components in the good unit.

### See Also

---

["System Troubleshooting Procedures" on page 99](#)

---

<sup>1</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

<sup>2</sup>Device power cord connector or electrical cable male connector that is inserted into an electrical receptacle "outlet" (also called the plug-in).

<sup>3</sup>Integrated Footplant Technology: IFT recognize this change in speed when your foot strikes the belt and adjust to match every stride, resulting in a smooth, fluid feel that enhances the workout experience.

<sup>4</sup>Printed circuit assembly, generally referred to as either an upper PCA or lower PCA.

## Drive Motor System Troubleshooting

### About

Occasionally, there may be issues with the proper operation of the drive system that do not generate error codes. This troubleshooting procedure is intended to troubleshoot the 3-phase Drive Motor System.

If there is a drive motor system Error code from 20 through 29 in the error log, go to the [Error Code Troubleshooting Guide](#) for troubleshooting information.

If there are no errors in the error log, yet the drive system appears to have an issue (such as jittery motion) then continue the troubleshooting procedure.

### Related Error Codes

Drive system error codes: 20 through 29.

Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting information.

### Procedure

#### *Lower Control Module OUTPUT power Check*



**NOTE:** When taking voltage readings of the AC<sup>1</sup> drive motor, the readings may not seem accurate because of the frequencies being used, however, they are indicative of the presence of drive motor voltage and relative frequency changes.

1. If the drive motor starts when you force the running belt to move and the drive motor runs rough, jump to the *Drive Motor Winding Check* procedure below. If the drive motor will not start, continue with the next step.
2. If the drive motor does not start, the lower control module will only apply voltage for a couple of seconds before it shuts down. Therefore the voltage readings in the following step must be taken within the first couple of seconds after the treadmill is instructed to start the running belt. (A multimeter with a peak hold feature is recommended)
3. Connect an AC voltmeter between terminals 4 (red) & 5 (white) of the OUTPUT connector on the lower control module. Set the treadmill ON/OFF switch to the ON position. Press the **QUICK START** key. If the lower control module is supplying output, you will momentarily read some value of AC voltage. Make a note of the voltage and set the treadmill ON/OFF switch to the OFF position.
4. Set the treadmill ON/OFF switch to the OFF position. Repeat the previous AC voltage measurement between terminals 4 (red) & 6 (black) of the OUTPUT connector as the previous step. Voltage should read the same value as the OUTPUT pins 4 and 5. Set the treadmill ON/OFF switch to the OFF position.

---

<sup>1</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.


5. Set the treadmill ON/OFF switch to the OFF repeat the previous AC voltage measurement between terminals 5 (white) & 6 (black) of the OUTPUT connector on the lower control module. The voltage should read the same value as the OUTPUT pins 4 and 5. Set the treadmill's ON/OFF switch to the OFF position.
6. If one or more of the previous OUTPUT voltage readings are not present, replace the lower control module. If the voltage readings are present, continue with the next step.


*Drive Motor Winding Check*



**CAUTION:** All resistance measurements must be performed with power removed from the machine. Performing the resistance measurements with voltage applied to the circuit can damage the multimeter.

7. Set the treadmill's ON/OFF switch to the OFF position. Disconnect the drive motor connector from the OUTPUT connector on the power control module. With an ohmmeter, measure between terminals 4 (red) & 5 (white), 4 (red) & 6 (black) and 5 (white) & 6 (black) of the drive motor connector. Each reading should be approximately 2.5 ohms. If any of the readings are significantly high or open, replace the drive motor.
8. If the ohm readings are correct, inspect the female terminals of the drive motor connector. Verify that they are not spread beyond the point of making good connection with the male pins on the OUTPUT connector on the power control module. If proper connection is not being achieved, replace the drive motor connector.
9. If you have performed all of the procedures above and have been unable to correct the problem, call Precor customer support.





**See Also**

"System Troubleshooting Procedures" on page 99

## E-Stop Not Communicating

The error 37 is generated by the upper **PCA**<sup>1</sup> in the console when the lower control module gets into an E-Stop state and the upper PCA in the console did not know about it. The system uses pin 8 of the data cable to communicate E-Stop states between the console and the lower control module.

### Related Error Codes

E-Stop error code: 37.

Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting information.

### Procedure

Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting information.

### See Also

---

"System Troubleshooting Procedures" on page 99

---

<sup>1</sup>Printed circuit assembly, generally referred to as either an upper PCA or lower PCA.

## Heart Rate Monitor Troubleshooting

### Hand Held Heart Rate Does Not Work


1. Place your hands on the **HHHR**<sup>1</sup> (Hand Held Heart Rate) contacts, making full contact with both top and bottom contacts for at least 15 seconds.
  - a. If the unit displays a heart rate, no problem exists.
  - b. If the unit does not display a heart rate value within this time, continue with next step.
2. Set the ON/OFF switch to the OFF position, wait 10 seconds, then set the ON/OFF switch to the on position and repeat step 1.
  - a. If the HHHR functions correctly, then the processor on the **HR**<sup>2</sup> board was in a "latched-up" condition, and cycling the power cleared the condition.
  - b. If the HHHR does not function correctly, continue with step 3.
3. Verify that the HHHR board has the correct operating voltage. Connect a voltmeter to VCC and Ground on the Power/Signal connector. The voltage should read between 4.5 and 5 Vdc.
4. Verify the wiring of the HHHR contacts (top left, bottom left, top right, bottom right) go to the proper pin on the Grip/Contact connector, that none of the lines are shorted,
  - a. If NO, Correct the wiring error.
  - b. If YES, Continue.
5. Verify that the grip connections are free of corrosion.
  - a. If NO, replace the corroded HHHR grips.
  - b. If YES, continue.
6. Verify that there is a ferrite bead around the cable from the HHHR board to the upper **PCA**<sup>3</sup>. (GEN-06 treadmill only)
7. Verify that the unit does not display a heart rate with only one hand on a grip. This would indicate static damage, and require replacement of the heart rate board.
8. If the above procedures do not correct the problem, replace the heart rate board.

---

<sup>1</sup>Hand Held Heart Rate

<sup>2</sup>Heart Rate

<sup>3</sup>Printed circuit assembly, generally referred to as either an upper PCA or lower PCA.



### Wireless Heart Rate Does Not Work

1. Verify wireless heart rate with a known good chest strap transmitter or test transmitter. If the heart rate reading is erratic, incorrect, or absent, continue.



**NOTE:** It may be necessary to lean in closer to the console at first to allow receiver to begin to acquire a heart rate signal.

2. Verify that the HHR board has the correct operating voltage. Connect a voltmeter to VCC and Ground on the Power/Signal connector. The voltage should read between 4.5 and 5.5 Vdc.
3. Identify other sources of wireless interference signals in close proximity to the unit (such as **Wi-Fi**<sup>1</sup> networks, cordless phones, etc.).



**NOTE:** Wi-Fi network is transmitting in close proximity to the treadmill the heart rate system MAY pick it up. Using an ohmmeter, verify that upper and lower PCAs have a good electrical path to chassis ground.

4. If the preceding procedures do not correct the problem, replace the heart rate board.
5. Possible sources of interference signals include, but not limited to:
  - Wi-Fi Network Routers
  - Cordless Telephones
  - Cell Phones
  - Electronic Dog Fences
  - Garage Door Remotes
  - Noisy **AC**<sup>2</sup> feeds
  - Florescent light ballasts

<sup>1</sup>Wireless Fidelity - a term defined and Trademarked by the Wi-Fi Open Alliance. Wireless LAN equipment carrying the Wi-Fi logo have been interoperability tested for compatibility with one (or more) 802.11 standards, and certified by the Wi-Fi Alliance to be sold under the Wi-Fi brand.

<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.



## See Also

---

"System Troubleshooting Procedures" on page 99

## Incline System Troubleshooting

The incline system consists of an **AC**<sup>1</sup> line voltage driven lift motor (120 **VAC**<sup>2</sup> or 240 VAC), and an internal 1 K W (Ohms) potentiometer for lift position monitoring. It is important when you start to troubleshoot the lift system to determine if the problem is due to an inability to move the lift, or an inability to monitor the lift position.

### Related Error Codes

Incline system error codes: 40 through 45.

Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting information.

### Procedure

Determine whether you need to troubleshoot the AC voltages going to the motor windings, or if you need to troubleshoot the **DC**<sup>3</sup> voltages and/or ohm readings from the potentiometer. The error log will help determine which is causing the issue.

Check the error log for INCLINE system error codes, press and hold the reset key for at least 6 seconds to access the error log.

If there is an error code for a lift system error logged (Error 40 through 45), go to the [Error Code Troubleshooting Guide](#) and follow the troubleshooting information.



**CAUTION:** All resistance measurements must be performed with power removed from the machine. Performing the resistance measurements with voltage applied to the circuit can damage the multimeter.

### *Operation of lift motor for testing:*

Most Precor treadmills require the running belt to be moving to operate the lift. For this reason it is recommended that the servicer use the "Hardware Validation" - Machine Tests (see ) to verify lift operation.

## See Also

---

"System Troubleshooting Procedures" on page 99

---

<sup>1</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

<sup>2</sup>voltage in an alternating current circuit

<sup>3</sup>Direct Current: electrical current that only flows in one direction.

## Input Power and Machine Controls Troubleshooting

Errors in this section cover either input power (error 15 & 16) conditions, Console controls (error 5 & 80-83), or processor/memory (error 9 & 11) conditions. These are errors that although they are valid to the proper function of the machine, are not part of a specific treadmill base system (lift system, drive system, deck & belt system, etc.).

### Related Error Codes

- Input Power: 15,16,
- Machine Controls: 5, 80-85.
- Processor Memory; 9:11.

Refer to the [Error Code Troubleshooting Guide](#) for error code description and troubleshooting information.

### Procedure

Refer to the [Error Code Troubleshooting Guide](#).

### See Also

---

"System Troubleshooting Procedures" on page 99

## Running Belt and Deck Troubleshooting

This procedure is to be used to determine the condition of the running belt and running deck combination.


A clamp-on ammeter will be used to measure the treadmill's **AC**<sup>1</sup> input current under load. The AC input current is a direct indication of the load being placed on the treadmill. Treadmill loading consists of several factors, the user's weight, treadmill speed and condition of the running belt and running deck.

The AC input current measurements should be performed at 7-8 mph. and 0% incline. Because the loading varies with the user's weight, you should perform the AC input current measurement test on a new running belt and deck combination. That will provide you with a benchmark reading to account for your individual weight.

Because the AC input current reading will pulse between a high value (during foot plant) and a low reading (between foot plants) we suggest the use of an analog clamp-on ammeter. An analog ammeter makes it very easy to see the AC current pulses. The refresh rate on digital ammeters may make it difficult to see the rapid current peaks unless the digital ammeter is equipped with a peak hold feature.

### Procedure

1. Remove the treadmill's motor cover and place the AC clamp-on ammeter on the brown wire from the AC. input module (or AC. power cord) to the circuit breaker (ON/OFF switch). See the illustration below.



2. Set the treadmill's speed at 7-8 mph and the incline at 0%. Walk on the treadmill and observe the average AC. current reading. Typical average AC. current reading on a

---

<sup>1</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

new running belt and deck should average between 8 to 12 amperes. Note that a digital meter could measure peak amps as high as 20 amps, even on a new belt and deck.

3. If the average current reading approaches 20 amperes, the running belt should be replaced. The running deck should be flipped or replaced if the running deck has been previously flipped. See Procedure, Running Belt and/or Deck Replacement (on page 101) for running belt and running deck replacement.
4. If the average AC current readings are greater than on a new running belt and deck combination but not approaching 20 amperes, the reading will give you an indication of the running belt and deck combination's general condition.



**NOTE:** Repeat the amp draw test after replacing a running belt and deck. Damage to the lower control module can occur if the unit had been run in an overload/high current condition for prolonged periods of time. This type of damage would not generate an error code, but would cause the breaker to trip intermittently. An amp draw test will catch this condition.

### See Also

---

"System Troubleshooting Procedures" on page 99

## Tripped Circuit Breaker

Troubleshooting a tripped treadmill ON/OFF circuit breaker or facility outlet circuit breaker. Review the electrical requirements, see "General Information" on page 5.

It is extremely important to know whether it is the treadmill circuit breaker or the facility wall outlet circuit breaker that trips. It is also extremely important to know when the breaker trip occurs, choose one of the following trip events:

- Immediately on power up
- After the belt starts but before the exerciser walks onto the belt
- After the exerciser walks onto the belt.

### If the facility outlet circuit breaker trips

- Measure the facility wall outlet voltage. If the is approximately 0 VAC<sup>1</sup>, the wall breaker has tripped.
- Inspect the power cord, if damaged, replace the line cord. If the line cord is not damaged continue with the following steps.
- Verify whether there is more than one treadmill on the same outlet circuit breaker. This will be especially evident if two or more treadmills shutdown at the same time. To verify if multiple treadmills are sharing the same wall breaker, manually switched OFF the wall breaker. If more than one treadmill loses power, the treadmills are on the same breaker.
  - If YES, advise the customer to have their facility wiring upgraded per Precor specifications.
  - If NO, continue troubleshooting.



**IMPORTANT:** If the AC<sup>2</sup> circuit feeding a treadmill is found to be a non-dedicated branch circuit or a circuit equipped with a capacity of less than 20 amps, the AC circuit must be corrected before any reliable Troubleshooting can be performed. More importantly, a non-dedicated branch circuit may constitute a safety hazard to the treadmill operator.

- Verify the wall outlets do not share neutral wiring and that each wall outlet is on an individual branch circuit. An individual branch circuit will have its own load line, neutral line and ground line. To verify that the treadmill is not on an individual branch circuit use an AC voltmeter measure from the hot contact of one AC receptacle to the neutral contact of another AC receptacle. If AC line voltage is present then the treadmills are sharing neutral lines.
  - If YES, advise customer to have their facility wiring upgraded per Precor specifications, and then continue to step 5.
  - If NO, continue troubleshooting

---

<sup>1</sup>voltage in an alternating current circuit

<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.



**CAUTION:** The treadmill requires a 20-amp individual branch circuit grounded per NEC (National Electric Code) guidelines or local region electric code.

- Measure the AC input voltage with the treadmill unloaded (running belt moving, with no one walking on the running belt) and then again while loaded (someone walking/running on the belt). The difference between the two states should be no more than about 6 volts RMS, and ideally less.
  - If the voltage variance is more than 6 volts RMS, the distance the branch circuit wire are runs maybe very long or may have used smaller diameter wire. Recommend to the club that they should consult with an electrician if this is suspected.
  - If NO, continue troubleshooting.
- Weight overloading is the most frequent cause of treadmill shutting down. Overloading is most often caused by excess deck/belt friction, but can be made worse by line voltage conditions. This condition happens more often with heavier runners, but never walkers. In high exerciser clubs (10 hours or more of use per day), the decks/belts will wear out much faster than at other locations, sometimes in months rather than years. It is often accompanied by error codes 27, 28, or 29, see "Troubleshooting the 3 Phase AC Drive Motor System."

#### **If the Treadmill ON/OFF circuit breaker is tripped:**

- Verify the wall outlets do not share neutral wiring and that each wall outlet is on an individual branch circuit. An individual branch circuit will have its own load line, neutral line and ground line. To verify that the treadmill is not on an individual branch circuit use an AC voltmeter measure from the hot contact of one AC receptacle to the neutral contact of another AC receptacle. If AC line voltage is present then the treadmills are sharing neutral lines.
  - If YES, advise customer to have their facility wiring upgraded per Precor specifications, and then continue with step 2.
  - If NO, continue troubleshooting.



**CAUTION:** The treadmill requires a 20-amp individual branch circuit grounded per NEC (National Electric Code) guidelines or local region electric code.

- Verified that a long distance branch run has inadequate gauge wire.
  - If YES, advise customer to have their facility wiring upgraded per Precor specifications.
  - If NO, continue troubleshooting.
- Verify the input line voltage; Low line voltage for the U.S. is any voltage below 108 VAC, measured while the treadmill circuit breaker is switched "ON" and the running belt is stopped. For international, low line voltage is anything below 200 VAC while the treadmill circuit breaker is switched "ON" and the running belt is stopped. Measure the line voltage with the treadmill circuit breaker is switched "ON", and the running belt is stopped. Record the voltage. Then measure the voltage again using the instantaneous voltage drop using the min/max function on your volt meter while someone is running on the treadmill at 7.0 MPH or higher.

- If any measurement is below 108 VAC (US) or 200 VAC (International), advise the customer to have their facility wiring inspected by an electrician.
- If the measurements are at or above 108 VAC (US) or 200 VAC (International), continue troubleshooting.
- Does the treadmill trip its breaker immediately on power up?
  - If YES, it is likely that there is a shorted component (line filter, lower control module) or faulty/shorted wiring.
  - If NO, continue with the following steps.
- Does the treadmill power up, but trips the breaker after the motor is started?
  - If YES, it is likely that there is a bad roller or bad drive motor.
  - If NO, continue with the following steps.
- Does the drive motor start up fine, but trips the breaker after an exerciser walks/runs on the running belt?
  - If YES, Overloading is the most frequent cause of treadmill shutting down. Overloading is most often caused by excess deck/belt friction, but can be made worse by line voltage conditions. The overloading condition happens more often with heavier runners, but never walkers. In high exerciser clubs (10 hours or more of use per day), the decks/belts will wear much faster than at other locations, sometimes in months rather than years. It is often accompanied by error codes 27, 28, or 29. Perform an amp draw test in the "[Running Belt and Deck Troubleshooting](#)" on page 117 procedure.

## See Also

---

"[System Troubleshooting Procedures](#)" on page 99



# Preventive Maintenance

## About

Preventative maintenance is proven to extend the life of the equipment, improve the user experience, and keep maintenance problems and service calls to a minimum.



**IMPORTANT:** It is the responsibility of the owner to maintain equipment in accordance with the Precor recommended preventative maintenance schedule. Following the preventative maintenance schedule is required to maintain warranty coverage.

## Maintenance Schedule

Preventative maintenance tasks are grouped into Daily, Weekly, Monthly, Quarterly, and Semi-annual scheduled maintenance tasks (scheduled maintenance tasks are equipment model specific). Refer to the equipment maintenance guide for schedule and maintenance task information:

- Cardio equipment, see [Cardio Equipment Maintenance Guide](#)
- Consoles and PVS<sup>1</sup> displays: [Console and PVS Maintenance Guide](#)



**TIP:** You can also download the Preventative Maintenance Guide from the [Precor.com](#) equipment home page.



**IMPORTANT:** If you determine that the equipment needs service, disconnect all power connections (television, Ethernet, and power) and move the equipment away from the exercise area. Place an OUT OF SERVICE sign on the equipment and make it clear to all patrons and other users that they must not use it.

## Precor Preventative Maintenance Plan

Precor offers a Preventative Maintenance Service Plan that uses Precor-certified technicians to perform the equipment regularly scheduled weekly, monthly, quarterly, and semi-annual maintenance tasks. For more information and to sign up, visit the [Preventative Maintenance Program](#) web site.

---

<sup>1</sup>Personal Viewing System display.

## Running Belt and Deck Cleaning Procedure

Review the entire procedure before beginning.

1. First, check for proper operation of the safety **Stop** key.
  - a. Stand to one side of the treadmill - Do not stand or allow others to stand on the treadmill running belt during this procedure. Ensure that the stop key tether is hanging straight down and is not wrapped around the handle bars.
  - b. Select **Quick Start** and wait for the running belt to begin moving
  - c. Once the running belt is moving, push the **SAFETY STOP** key.
  - d. Ensure the running belt stops moving, then reset the **SAFETY STOP** key.
  - e. Turn the power switch to **OFF**. The **ON/OFF** switch is located at the front of the treadmill.



**WARNING:** If the running belt does not stop, turn off the power using the ON/OFF switch at the front of the treadmill and **unplug**<sup>1</sup> the power cord. The treadmill must remain out of service until the stop switch is repaired.

2. Get a clean, dry cotton towel that is at least 36 inches (1 meter) in length and fold it in half lengthwise.
  - a. Lift the running belt and push the towel through to the other side so that both ends of the towel extend an equal distance over the deck trim on both sides.
  - b. Push the towel forward to the front of the machine so it is located beneath the **SAFETY STOP** key.
  - c. Turn the power switch to **ON**.
3. Mount the machine by standing on the side rails and attach the stop key tether. Do not stand on the running belt at any time. Stand firmly on both ends of the towel keeping your feet off of the treadmill running belt. Brace yourself using the handlebars or side hand rails. Push the **Quick Start** button once in position.

---

<sup>1</sup>Disconnect a device power cord plug or cable connector from the power receptacle or outlet.



**CAUTION:** You have approximately 3 seconds before the treadmill running belt begins to move after pressing Quick Start. Ensure you are in the proper position.



**WARNING:** Press the safety stop key if the towel becomes loose to prevent it from being pulled into the treadmill's rollers.

4. The treadmill will begin to run at 1 mph. Allow the treadmill to run for one minute while keeping the towel firmly in place.



**WARNING:** Do not adjust the treadmill's speed or run it higher than 1 mph.

5. After one minute, stop the treadmill by pressing the **STOP** button.
6. When the belt has fully stopped moving, remove the **STOP** key tether, exit the treadmill, and turn the power switch to **OFF**.

7. Grasp both sides of the towel and run it up and down the length of the belt several times to clean the top of the deck.
8. Remove the towel from beneath the belt.
9. Turn the power switch to **ON**.
10. Verify operation and return to service.

# Theory of Operation

## About

The treadmill is comprised of two basic system blocks, the console provides the user interface and operational controls. It contains the **Upper PCA**<sup>1</sup> board which sends the control input information to the base. The base contains and uses the **Lower PCA**<sup>2</sup> board to execute received operational commands. The Lower **PCA**<sup>3</sup> returns status and error code information to the Upper PCA for display and diagnostics.

## Console Operation

### Basic operation

This section will explain basic operation and functions that apply to all models of consoles. For specific details about a particular model of console (Standard, P10, P20, P30, P80), refer to the applicable console service manual.

The supported console models include the P10, P20, P30, P80, and P82 models.

### Controls

All consoles provide user input (keypad functions), user display (LED display / user feedback), automated control (heart rate program, interval program) and service software routines (tests, settings, and information).

The keypad functions can vary between different console models, however the basic functions that all consoles have include the Quick Start, Incline (up or down) and Speed (up or down) functions.

### Features

Different console models provide a different set of user features but the basic operation and servicing software is the same.

The service software functions exactly the same for all console models. Each console uses the same service software standard access codes to access the Hardware Validation Tests, Club Parameter settings, or Information Display modes, see .

The service software also utilizes the same Standard Error Codes in all console models, see .

---

<sup>1</sup>Upper printed circuit assembly; generally refers to the console.

<sup>2</sup>Lower printed circuit assembly; generally this refers to the lower board. On treadmills, this is the motor controller unit (MCU), and on self-powered units, it is the main board in the lower section.

<sup>3</sup>Printed circuit assembly, generally referred to as either an upper PCA or lower PCA.

## Console to Base Interface

The console processor (upper PCA board "UPCA<sup>1</sup>") provides user input, user display and automated control to the system. The console processor communicates with the base processor (Lower PCA "LPCA<sup>2</sup>") which then performs the actual machine function.

The two processors communicate via a serial data stream. When the user makes a request via a machine control or the keypad, the console processor communicates the command to the processor in the lower electronics module.

When the lower processor receives a command the lower control module performs the machine function. The console processor continues to monitor machine controls, keypad entry, lower board status, and provide user feedback information.

The lower board base processor also provides machine operation and error status (error log codes) to the console processor.


---

---

<sup>1</sup>Upper PCA board

<sup>2</sup>Lower printed circuit assembly; generally this refers to the lower board. On treadmills, this is the motor controller unit (MCU), and on self-powered units, it is the main board in the lower section.

# AC Drive Treadmill System




## Treadmill Base Operation

### Input Power

The GEN-06 / **TRM10**<sup>1</sup> base is equipped with a removable line cord plugged into a power entry socket. This is designed to accommodate either 120 **VAC**<sup>2</sup> or 240 VAC NEMA compatible line cords, as well as line cords for other countries. The diagram below shows a NEMA 20A plug for both 120 VAC and 240 VAC configurations in the United States.

<sup>1</sup>TRM800 version 1 treadmills mfg. dates 2010 thru 2014.

<sup>2</sup>voltage in an alternating current circuit



**CAUTION:** The treadmill requires a 20-amp individual branch circuit grounded per NEC (National Electric Code) guidelines or local region electric code.

120 VAC power, when measured from hot to neutral, should read between 90 and 110's. 240 VAC power, when measured from hot to neutral should read between 180 and 264 VAC. This input voltage is applied through the power entry plug and wired to the breaker switch. The 120 VAC breaker switch only interrupts the hot line and the 240 VAC breaker switch interrupts both the hot and neutral lines. The power is then fed through a line filter which removes high frequency noise from the line voltage. After the power is cleaned by the line filter it can be applied to the lower electronics module (IFT<sup>1</sup> drive).

Review electrical requirements, see "General Information" on page 5.

### Lower Electronics Module (IFT module)

The lower control module consists of an AC<sup>2</sup> drive motor controller, an AC lift motor controller and a +8.5 Vdc power supply to power the console.

The electronic circuits in the console operate on +5 Vdc, however the lower control module sends +8.5 Vdc due to the optional external equipment such as Fitlinxx products connected to the CSAFE<sup>3</sup> (communication standard for all fitness equipment) port. Sending a higher voltage (+8.5 Vdc) and regulating the voltage down to +5 Vdc ensures enough supply power to support both the console and the optional external equipment.

It is important to note that the lower control module (IFT module) has different part numbers for the 120 Vac unit the 240 Vac treadmill.

<sup>1</sup>Integrated Footplant Technology: IFT recognize this change in speed when your foot strikes the belt and adjust to match every stride, resulting in a smooth, fluid feel that enhances the workout experience.


<sup>2</sup>Alternating Current: electric current which periodically reverses direction between positive and negative polarity.

<sup>3</sup>Communication Specification for Fitness Equipment protocol.



### AC Drive Motor Controller

The AC drive system controls the three phase AC drive motor. In an AC motor, speed is controlled by frequency independent of voltage or current, torque is controlled by the voltage/-current applied to the motor 3 phase windings. The windings (stator) and rotor core of the motor are designed to spin at a specific speed at the design frequency. The lower control module generates the correct frequency to drive the motor at the command speed. Since the speed of an AC motor is controlled by frequency, there is no need for a speed sensor.




The 3 phase AC motor generates enough torque to provide continuous duty run time. The 3 phase voltage amplitude of all three input AC sine waves is the same at any given time which allows the torque to be applied smoothly throughout the rotation of the motor. Increasing the input voltage/current amplitude increases the torque and decreasing the input amplitude decreases the torque.

The lower electronics module (IFT drive) is responsible for sending the proper frequency to control speed and the amplitude (same on all 3 phases) to control torque. The motor must then be balanced both mechanically and electrically in order to translate the frequency and amplitude into fluid motion. Mechanical balance is achieved by balancing the weight of the fly-wheel, and electrical balance is achieved by having the same winding resistance on all 3 phase windings.

Other AC drive motor controller features include "Dynamic Braking" and "Power Factor Correction". Dynamic Braking addresses an issue where an over-speed condition could occur. If a

heavy user runs at a high incline, the weight of the user has the potential to push the running belt to go faster than the commanded motor controller speed (generates excess current). The dynamic brake circuit senses the load variations and applies a braking force within the motor. The system utilizes an external power resistor (Dynamic Brake resistor) to absorb the excess generated current and determine applied braking force. Power Factor Correction is a feature that attempts to reduce power consumption. The system monitors that this power factor is held within certain parameters. If it falls outside those parameters (the system is using more current than expected), the system will flag an ERROR 29.



## Auto Stop

The Auto Stop feature monitors up and down movement of the deck. The deck motion indicates a user is present. The lack of motion indicates that a user is not present. If the running belt is moving and the Auto Stop does not detect motion from the running deck, the Auto Stop feature will stop the motion of the running belt.

GEN 06 treadmills (Mfg. date: April 2006 to April 2011) do not support the auto-stop feature. TRM10 treadmills (Mfg. date: April 2011 and later) do support the auto-stop feature.

The auto-stop feature consists of a magnet mounted on the edge of the deck, the sensor mounted on the roller mounting bracket and a cable connecting Auto-stop to the console. When a user is running on the deck, it causes the magnet to be in motion relative to the sensor. When a program is entered, Quick Start is pressed or the treadmill has been resumed after being paused, the treadmill starts at 1 mph. The user will then have 60 seconds to enter any remaining workout settings before motion detection begins. Once motion detection has commenced and if no or very little motion is detected, the Auto Stop feature interprets that the treadmill is no longer in use. The Auto Stop feature will continue to monitor the treadmill for motion for 30 seconds; if motion is still not detected a 10 second count down will be displayed on the console. After the 10 second count down has elapsed and motion has not been detected, the Auto Stop feature will stop the motion of the running belt and go into pause mode. If motion is detected within the 10 second count down cycles the shutdown feature will be aborted.

The Auto Stop feature can be enabled or disabled within the service software Club Parameters, see .




**NOTE:** When Auto Stop is enabled, running belt adjustment and tracking procedures should be performed in the Hardware Validation - Belt Speed Test because the Auto-Stop feature is not active during the Belt Speed Test, see

## AC Incline System

### Motion Control

The motor used in the incline system is a "Permanent Split Capacitance", single phase AC motor. The motor incorporates the use of a capacitor to provide the required lift torque. Power to the lift motor is provided directly from the treadmill AC input power.

In order to turn the motor in forward and reverse directions, the AC motor has 2 separate windings, one for up and one for down direction. The AC-1 input has a continuous connection to the center / common connection of the motor winding.



The system has a 2A fuse to protect the components from over-current failure.

When a control signal is applied to the "UP" input, TRIAC-1 control line is active and turns on the up triac. This directs the AC-2 connection to the up winding of the motor, causing the motor to spin in the up direction.

When a control signal is applied to the "DOWN" input, TRIAC-2 control line is active, turns on the down triac. This directs the AC2 connection to the down winding of the motor, causing the motor to spin in the down direction.

Since the lift motor runs directly on the AC input voltage, it is important to note that there is a different part number for a 120 Vac unit and a 240 Vac unit.

### Position Monitoring

The unit also requires an absolute measurement of lift position. This is achieved through the use of a potentiometer. The potentiometer resistance wiper is turned by gears in the lift motor.

With +3.3 Vdc is applied across the potentiometer, the center wiper connection will create a variable voltage between 0 and +3.3 Vdc representing the position of the lift or incline. This variable voltage is applied to the input of a 16-bit A/D converter which converts the analog voltage into a 16-bit binary numeric representation that the processor can understand.

As the potentiometer voltage changes between 0 and 3.3 Vdc, the corresponding A/D values change between 0 and 65507. The processor uses the A/D number to track the lift position.

It is important to note that since the potentiometer is mechanically connected to the internal gearing of the motor, it would be highly unlikely for a lift motor to go out of calibration without having physical damage to the potentiometer mechanism.

---


### See Also

---

"System Diagrams" on page 134

## System Diagrams

### System Block Diagram - 120 VAC



### See Also


"Theory of Operation" on page 126.

## Parts

The following copies of the equipment "*Exploded View Diagram*" and "*Parts Identification List*" are provided for you to use as a quick reference.

However, it is recommended that you go to the servicer partners [Precor Connect](#) (or [Precor Connection](#)) website to view the most current parts information including the *Exploded View Diagram* and *Parts Identification List*.

- [Precor Connect Partner](#) website




**IMPORTANT:** Always purchase OEM replacement parts and hardware from Precor. If you use parts not approved by Precor, you could void the Precor Limited Warranty. Use of parts not approved by Precor may cause injury.


"Exploded View Diagram" on the next page

"Parts Identification List" on page 141


## Exploded View Diagram


Page 1 of 5














PAGE OF	DWG. NO.	SUBREV
5 5	300828-101	M

## Parts Identification List

### Parts List

**TRM10, Base, (8X5) (8X3), 120V (Serial Code A837)**

Part Number	Description	Number
PPP00000058093101	DECK W/SHIPPER, PRE-WAX, TRM10	2
PPP00000036355138	RUNNING BELT, SIEGLING 132.75 X 20	3
PPP000000300814104	ASSEMBLY, CABLE, MOD 8P8C 1-1, W/FE	7
PPP000000058125101	KIT, BOXED, MODULE,MOTOR DRIVE,120V	9
PPP000000058066101	KIT, BOXED, ASSY, DRIVE MOTOR, AC I	10
PPP000000044257107	MOTOR, LIFT ACTUATOR, 120V, ROHS	16
PPP000000058131101	KIT, BOXED, ASSEMBLY, ROLLER DRIVE,	19
PPP000000058130101	KIT, BOXED, ASSEMBLY, ROLLER TAKEUP	20
PPP000000300380103	ASSEMBLY, OVERMOLD, LEFT	21
PPP000000300380104	ASSEMBLY, OVERMOLD, RIGHT	22
PPP000000047429144	PWR CORD,125VAC,20A,NEMA 5-20RA45/I	23
PPP000000041168144	PWR CORD,250VAC,16A,NBR 14136 - IEC	23.02
PPP000000011462143	CKT BRKR,250V,MAGNETIC,ROCKER,1 PO	24
PPP000000011224104	FILTER, POWER LINE, 250VAC, 16A, GE	25
PPP000000035700102	GRIP, HHR, TOP 9.3X-07, BLACK	33
PPP000000035701102	GRIP, HHR, BOTTOM 9.3X-07, BLACK	34
PPP000000048668101	TARGA, LEFT,PAINTED	50
PPP000000048668102	TARGA, RIGHT,PAINTED	51
PPP000000048685101	DUST GUARD	52
PPP000000010401106	PIN,CLEVIS, 3/8 X 1.75, ZINC	53
PPP000000010400103	PIN, HITCH, .093 DIA, ZINC, #203	54
PPP000000045669107	PIN, LIFT PIVOT, 3.34, MUSHROOM HEA	55
PPP000000048659101	WELDMENT, LIFT PLATFORM	56
PPP000000044270101	WHEEL, LIFT	57
PPP00000PKCN019075	SCREW,S/T,#10X.75,WSHHXHD,ZN	58
PPP000000045669109	PIN, LIFT PIVOT, 3.27, MUSHROOM HEA	59
PPP000000010400106	PIN, HITCH, .125 DIA, ZINC, #216	60
PPP00000WBCN031007	WASHER,FLT,5/16X.688X.065, ZN	61
PPP00000CARB031100	SCREW, SKHD, 5/16-18 X 1.00, ZNCOAT	62
PPP000000048684101	ASSEMBLY, REAR FOOT	63
PPP000000010043136	BEARING,FLANGE .875ODX.750IDX.50L	64
PPP000000036192101	BUSHING, SPANNER	65
PPP00000HCTN050250	SCREW,HEX,GR 5,1/2-13X2-1/2,BLK SHA	66
PPP00000WBCN050010	WASHER, FLT, 1/2, ID=.531,	67
PPP00000KACN050019	LOCKNUT,HALF,1/2-13,ZN	68
PPP000000010043113	BEARING,FLANGE,OD=.62 ID=.5	69
PPP000000010178112	BUSHING, SNAP	70
PPP000000010214102	BELT, DRIVE, 320J10 POLY V, TEM	71
PPP000000011278101	CABLE CLAMP,INSERT	72
PPP000000033984101	LABEL, SAFETY, GROUND SYMBOL	73
PPP000000044074106	STRAP, GFX TIE DOWN	74
PPP000000044234101	DECK PIVOT	75

PPP00000044236101	GFX CUSHION	76
PPP00000044263101	PLATE, SPACER, DECK	77
PPP00000048968105	ASSEMBLY, TRIM STRIP, C966I,PACIFIC	78
PPP000000300833101	BRACKET, REAR ROLLER GUARD, LEFT, P	79
PPP000000300833102	BRACKET, REAR ROLLER GUARD, RIGHT,	80
PPP00000048694102	END CAP, PACIFIC BLUE, NEW LOGO	81
PPP00000048695104	BELT GUARD, END CAP, PACIFIC BLUE	82
PPP000000300172101	SIDE TRIM, LEFT, PLASTIC	84
PPP000000300172102	SIDE TRIM, RIGHT, PLASTIC	85
PPP000000CKRB038250	SHCS,3/8-24 X 2.50,STL,ZNCOAT, NUTL	87
PPP000000HCCN031075	SCREW, HEX HD, GRADE 5, 5/16-18 X .	88
PPP000000HCCN038150	SCREW,HEX,GR 5,3/8-16X1 1/2,ZN	89
PPP000000MGCN019050	SCREW, MACHINE, 10-24X1/2, PANHD, P	90
PPP000000CATN025150	SCREW, SKHD,1/4-20X1.50,BLK SHARPER	91
PPP000000PKCN019075	SCREW,S/T,#10X.75,WSHHXHD,ZN	92
PPP000000WAMCN019002	WASHER, LOCK, EXT TOOTH, #10	94
PPP000000WAVCN038015	WASHER, FLAT, 3/8 X .875 X .150	95
PPP000000WBCN031007	WASHER,FLT,5/16X.688X.065, ZN	96
PPP000000WNCN026006	WASHER,FLT,1/4X.625X.063,ZN	97
PPP000000012000030	GASKET,EMI,FABRIC OVER FOAM W/PSA,1	98
PPP0000000300075016	ASSY, CABLE, 2C, 16 AWG, BROWN, QK	99
PPP000000012248101	RES,WW,100 OHM,50W,10%,METAL CASE,.	100
PPP0000000300826017	ASSY,CABLE, FILTER TO DRIVE MODULE,	101
PPP000000037436101	LABEL, CHASIS NEUTRAL	102
PPP000000040193006	ASSY,CBL,1C,12AWG,250X032 QD RECP(X	103
PPP000000044528006	ASSY,CBL,1 COND,14AWG,QK DISC,6",BR	103
PPP000000040731009	CBL,1C,14AWG,#10 RING/250X032 QD RE	104
PPP000000045381101	IEC 16/20A POWER CORD INLET	105
PPP000000040194007	ASSY,CBL,1C,12AWG,250X032 QD RECP/2	106
PPP000000045383009	CBL,1C,14AWG,250X032 QD RECP/250X03	106
PPP000000048760101	PLATE, POWER ENTRY	107
PPP000000048761101	CLAMP, POWER CORD	108
PPP000000MGCN013038	SCREW,MCH,6-32X3/8,PANHD,PHIL,	109
PPP000000KGCN013011	LOCKNUT, STARWASHER 6-32, #6	110
PPP000000MGCN019050	SCREW, MACHINE, 10-24X1/2, PANHD, P	111
PPP000000044021104	CLIP ASSEMBLY	120
PPP000000012259102	SWITCH,MICRO,PLUNGER,SPNC	121
PPP000000040137024	ASSY,CABLE W/JACKET,E-STOP PLUS SOF	122
PPP000000047342045	ASSY, CABLE, HHR PCA TO GRIP, W/SH	137
PPP000000TCNN016075	SCREW, BTHD, 8-32X.75,SS	138
PPP000000010123101	CABLE TIE,11 LONG,WHITE,NYL	139
PPP000000WALCN025006	WASHER, SPLIT LOCK, 1/4 MED,	141

---

PPP0000PANTN025050	SCREW,S/T,#1/4-20X1/2,PANHD,PHIL,TR	142
PPP000000300361103	COVER, CONDUIT, REAR, TREADMILL	143
PPP000000300362101	COVER, CONDUIT, UPPER TREADMILL	145
PPP000000300363101	COVER, CONDUIT, LOWER TREADMILL	146
PPP000000300367101	DASH, BACK, TREADMILL	147
PPP000000300366101	ASSY,DASH,TREADMILL	148
PPP000000300374101	TRANSITION,DASH,TARGA,LEFT	149
PPP000000300374102	TRANSITION,DASH,TARGA,RIGHT	150
PPP000000300369103	ASSY,STOP SWITCH,CONSOLE	151
PPP00000MGCN016038	SCREW,MCH,8-32X3/8,PANHD,PHIL,	152
PPP000000300980102	CBL, 4P3C-3P3C,22AWG, W/RAMP & RIBS	153
PPP000000048747105	ASSEMBLY, HOOD, PACIFIC BLUE, NEW L	160
PPP000000012865003	CABLE P-CLIP,OPEN ENDED,0.375" BUND	213
PPP000000300993101	ASSY,AUTO-STOP, PCA & PLASTIC HOUSI	214
PPP000000301101101	FASTENER, SNAP-IN, PANEL (CHRISTMAS	215
PPP000000301102101	ASSEMBLY, MAGNET HOLDER, AUTO STOP	216
PPP000000011075105	FUSE,2.00A,250VAC,SLO,RAD,UL248-14	250
PPP000000300678101	LABEL, HOOD ALUMINUM, NEW LOGO	251
PPP000000302148101	PLATE, CONNECTOR COVER, BLANK	252
PPP000000012414101	CABLE CLAMP INSERT,SNAP IN	903
PPP00000CATN031075	SCREW,SKHD,5/16-18X0.75,BLK SHARPER	904
PPP00000TCNN031075	SCREW,BTHD,5/16-18X.75,SS	905
PPP00000WEGN031007	WASHER, FLT, 5/16X.688X.065,SS, BLK	906
PPP00000WENN031007	WASHER, FLT, 5/16X.688X.065,SS	907
PPP00000TATN031075	SCREW,BTHD,5/16-18X3/4,BLK SHARPERI	908
PPP00000KGCN031027	LOCKNUT,STARWASHER,5/16-18,1/2	909
PPP0000MACCN025062	MACHINE SCREW, 1/4-20, [FLAT HEAD,	910
PPP0000WALCN031008	WASHER, 5/16 SPLIT LOCK, ZINC	917
PPP000000300491301	LITERATURE KIT, TREAD,ATLAS, EN	999

---

## Appendix A : Edition Information

### Edition

Title: **TRM10**<sup>1</sup>/GEN06 Treadmill Base Service Manual  
P/N: 20039-165 rev A06

### Additional Documentation

You can also view the service manual online at [Online Service Manual](#)

### Copyright

Copyright 2010 Precor Incorporated

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Precor Incorporated as governed by United States and international copyright laws.

Precor Incorporated  
20031 142nd Ave. NE  
P.O.Box 7202  
Woodinville, WA. 98072-4002  
Ph: 1-800-347-4404

---

<sup>1</sup>TRM800 version 1 treadmills mfg. dates 2010 thru 2014.

---

## Appendix B : Notices and Safety

### Trademarks

Precor, **AMT**<sup>1</sup>, **EFX**<sup>2</sup>, and Preva are registered trademarks of Precor Incorporated. Other names in this document may be the trademarks or registered trademarks of their respective owners.

The Spinner Family of bikes—Spin®, Spinner®, Spinning®, Spin Fitness®, and the Spinning logo® are registered trademarks owned by Mad Dogg Athletics, Inc., a California corporation.

SPD is a registered trademark of Shimano American Corporation.

### Intellectual Property

All rights, title, and interests in and to the software of the Preva Business Suite, the accompanying printed materials, any copies of such software, and all data collected via the Preva Business Suite, are exclusively owned by Precor or its suppliers, as the case may be.

Precor is widely recognized for its innovative, award-winning designs of exercise equipment. Precor aggressively seeks U.S. and foreign patents for both the mechanical construction and the visual aspects of its product design. Any party contemplating the use of Precor product designs is hereby forewarned that Precor considers the unauthorized appropriation of its proprietary rights to be a very serious matter. Precor will vigorously pursue all unauthorized appropriation of its proprietary rights.

### Warranty

The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Precor disclaims all warranties, either expressed or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Precor shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Precor and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

### Safety Notices

Warning and Caution notices indicate an activity that could be dangerous and cause personal injury and/or equipment damage if not adhered to. Always follow Warning and Caution instructions.

---

<sup>1</sup>Adaptive Motion Trainer

<sup>2</sup>Elliptical Fitness CrossTrainer



**Warning**

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood.

**Caution**

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood.

**Service Safety Guidelines**

Prior to doing any machine service, review the Service Safety Guidelines, see [Service Safety Guidelines](#).