



Cakcity watch

# Introduction

LIGHT(A 键)

MODE(B 键)



(D 键)START

(C 键)RESET

## A.Features

- ◆ Six-digit timing function, display hour minute, second, day, month, week
- ◆ Alarm and hourly chime
- ◆ Snooze function
- ◆ 12/24 hour system selection, automatic calendar
- ◆ 1/100 seconds stopwatch
- ◆ EL backlight
- ◆ 36mm diameter, CR2025 battery

## B.Product function modes


At any mode, press A key then EL backlight will last for 3s.

In normal Mode, Press D key to check Month and Date


In normal Mode, Press C key to check Alarm time

In normal Mode, Press C+D to turn on/off alarm.

When  displayed, the alarm is on.

In normal Mode, Press C+B to turn on/off hourly chime. When all  displays, the hourly time signal is turned on, and when the week symbols are all off, the hourly hour signal is turned off.

Press B key to convert mode:



Normal Mode

Chronograph Mode

Alarm Mode

Time Setting Mode

## C.Mode description

### 1)About Chronograph Mode

Press D key to start, press C key enter into split function and get the first group record ,but the second group is still processing in the back ground, press C key again to run the third group record, press C again to stop the running of the second group and read the second record; but the third group is still processing in the back ground.....when the final group finished, Press D key to stop the SPL function, press C key to read the final group(SUM) record, press C key again to clear the record to 0:00:00.

### 2)About Alarm Mode

Press B key twice enter into Alarm Mode, and Alarm Hour is flashing,Press D key to adjust the correct hour for your Alarm time. Press C key and the Alarm Minutes is flashing. Press D key to adjust the correct minute for your alarm. Press B key to exit. In Normal Mode, press D&C at same time to turn on/off Alarm

### 3)Time Setting Mode

In normal display Mode, press B key three times to enter time setting mode and the Seconds will be flashing. Press D key to reset the Seconds to zero. Press C key the Minute will flash. Press D key to adjust the correct Minutes. Press C key the Hours will flash. Press D key to adjust correct Hours(Pay Attention:A/P means AM/P-M,H means 24H format) Press C key the Date will flash. Press D key to adjust correct date Press C key the Month will flash. Press D key to adjust correct Month Press C key the week will flash. Press D key to adjust the correct week. Press B key to exit.