


PACKAGE CONTENTS

- 1. 1 x Light Fitting
- 2. 1 x Solar Panel Head
- 3. 1 x Solar Panel Bracket Pole
- 4. 1 x Ground Mount Spike

FEATURES



- 2. Double Sided Tape
- 3. Anti UV and Waterproof epoxy
- 4. 8 Hours Charging Time
- 5. 10-12 hours Working Time

SLDSTRIP-WW

- 4 flashing or steady modes to choose from
- 5m cable from solar panel to strip
- Option to charge panel via 5v USB port
- Panel indicator lights;
 Red Charging
 Green Fully Charged

SLDSTRIP-RGB

- 8 flashing or steady modes to choose from
- 3m cable from solar panel to strip

INSTALLATION METHOD


1. Remove contents from packaging

NOTE: Before continuing, it is recommended that your solar panel is exposed to direct sunlight (with the button in the **"OFF"** position) for 2 days prior to installation

(*Please Note:* The light is packed and transported with the button in the "OFF" position)

- 2. Decide where to install your Solar Panel (where it will receive maximum direct sunlight to charge)
- 3. Press power button on the solar panel to activate your battery pack **"ON"** (Press once)
- 4. Insert Spike into the bottom of the Bracket Pole (As seen in **FIGURE 1**)
- 5. Slide the Solar Panel into the bracket on top of the pole (As seen In **FIGURE 2**)
- Press the MODE Button to toggle between the pre-set operating modes (As seen in FIGURE 3)





MODE Button



"ON/OFF"
 Power Button

FIGURE 3

INSTRUCTION GUIDE Residential Strip Light

Model No. SLDSTRIP-WW, SLDSTRIP-RGB

IMPORTANT NOTES

- Please ensure you place your Solar Panel in a location where it can achieve a minimum of 6HRS DIRECT SUNLIGHT
- Be aware that on overcast/cloudy days, the solar panel will still charge. However, not as efficiently as a sunny day, so the battery may not reach full capacity. Therefore, your light may turn off earlier than specified.
- It's best not to install the fitting underneath a street light, porch light etc. because this may stop the automatic daynight sensor triggering and result in your lights not turning on

TROUBLE SHOOTING

Phenome non	Cause	Inspection Method	Solution
	Switch hasn't been	Determine what position the	Turn the switch on
	turned on	switch is in	
Light won't turn on	Battery has run flat	Period of rainy or cloudy weather or installation site doesn't provide enough direct sunlight	 Charge the light in direct sunlight for 1-2 days then check again Charge light via USB port (SLDSTRIP-WW)
The light only stays on for a short amount of time	Low Battery	 Bad installation site for the solar panel Dust or leaves are covering the panel Long period of overcast weather 	 Charge the battery in direct sunlight for 1- 2 days with the switch off, then check again 2. Clean the solar panel 3. Charge light via USB port (SLDSTRIP-WW)
	Battery Failure	 Access the light and & replace battery Battery has matured 	Contact SLD Customer Service to buy new batteries

FIGURE 1



