



# Banjo Brothers Pannier Instructions

For Grocery Pannier (#01080) and Waterproof Pannier (#01110)

## Installation



1. The pannier comes with an optional dropout hook, if you have a rack without an integral hook. Attach this dropout hook where the lower rack strut is attached to the bike frame.

2. Rest the pannier on the rack. Adjust the lower strap so that there is at least a 1.5" gap to the rack before the elastic is stretched.

3. Attach lower strap hook to the rack or dropout hook

4. Pull up on handle and secure the upper hooks on the rack. Adjust forward or back as needed for heel clearance

## General comments

- The Waterproof Pannier is made for cycling. It is not a kayak or canoe "dry bag", and we promise that it will leak if you attempt to use it underwater. Roll the top over 360 degrees like a lunch bag and cinch the strap snug to keep wind-driven rain out of the bag. The sealed seams on the liner do the rest.
- The waterproof liner is both removable (for those lucky enough to experience "dry seasons"), and replaceable if damaged. Just contact customer service for a low-cost replacement. The elastic is also replaceable for either pannier in the event of damage or loss of strength.
- The maximum capacity for either pannier is about 20 pounds. They are designed for commuting and recreational use, not cross-country touring. You don't have to baby it, but they aren't designed for epic tours. Your can be used in rain or shine. If it gets dirty, clean it with soap and water and air dry. Do not put it in the dryer unless you want it to melt. Solvents can deteriorate the synthetic fibers. Sustained exposure to sunlight will also cause some fading and deterioration to all fabrics. We can't defeat the laws of chemistry and physics, but we do our best to resist them.