



INSTRUCTIONS MANUAL

TYL-IM2200GS

AUTOMATIC ICEMAKER

Perfect for home or office use



www.tylrhome.com

Table of Contents

IMPORTANT SAFEGUARDS	2
PARTS AND FEATURES	5
PREPARING YOUR ICE MAKER	7
OPERATING YOUR ICE MAKER	8
CLEANING AND MAINTENANCE	10
TROUBLESHOOTING	11

IMPORTANT SAFEGUARDS

To reduce the risk of fire, explosion, electric shock, or injury when using your ice maker, follow these important safety instructions:

1. Before using the appliance, check that the voltage power corresponds to the one shown on the appliance nameplate.
2. Do not remove any safety, warning, or product information labels from your ice maker.
3. Plug the ice maker into an exclusive grounded power outlet. No other appliance should be plugged into the same outlet. Be sure that the plug is fully inserted into the receptacle.
4. This appliance must be grounded. It is equipped with a power cord with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.
5. Avoid the use of an extension cord as it may overheat and cause a risk of fire. If it is necessary to use an extension cord:
 - a. Use only extension cord with grounding plug.
 - b. The marked rating of an extension cord must be equal to or greater than the rating of this appliance.
6. Ice maker should be positioned such that it does not hang over the edge of a counter or tabletop where it can be pulled by children intentionally.
7. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service center for examination, repair or adjustment.
8. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.



9. Do not place on or near a hot gas or electric burner, or in a heated oven.
10. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
11. Do not touch the evaporator when using the ice maker or making ice to avoid injury.
12. Do not immerse any part of the appliance in water.
13. To disconnect, turn any control to "OFF," then remove plug from wall outlet.
14. Do not plug or unplug product with wet hands.
15. Unplug the product before cleaning, and when not in use.
16. Only use potable water with the ice maker.
17. Do not clean your ice maker with any flammable fluid. The fumes may create a fire hazard or explosion.
18. Do not overturn the ice maker. If the ice maker is overturned accidentally, let it rest upright for 2 hours before turning on again.
19. Never put flammable, explosive and corrosive objects into the ice maker.
20. Never store or use gas and other flammable articles near the ice maker, to avoid any fire hazard.
21. Unplug the ice maker before moving or transporting, to avoid damaging the refrigerating system.
22. Do not attempt to disassemble, repair, modify, or replace any part of your appliance.
23. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have

been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.


24. Cleaning and user maintenance shall not be made by children without supervision.
25. Close supervision is necessary when any appliance is used by or near children.
26. Do not leave the appliance unattended while in use.
27. Do not use outdoors.
28. Do not use the appliance for other than intended use.

SAVE THESE INSTRUCTIONS!

PARTS AND FEATURES



Control Panel



- A LARGE ICE SIZE indicator – lights up green when selected.
- B SMALL ICE SIZE indicator – lights up green when selected.
- C Cleaning alert indicator – lights up green when appliance needs to be cleaned.
- D On/Off button
- E Ice size selector button
- F Ice-making indicator – lights up green when ice-making is in operation.
- G ADD WATER indicator – lights up red when water reservoir needs to be filled.
- H ICE BASKET FULL indicator – lights up red when ice basket is full.

PREPARING YOUR ICE MAKER

1. Unpack the appliance, then check and make sure that all the accessories including ice basket and ice scoop are complete.
2. Place the ice maker on a level and stable surface.
3. The incline angle of the ice maker cabinet should not exceed 45° during transportation or use. Do not turn the ice maker upside down. Doing so could cause the compressor or refrigerating system to operate incorrectly. Please allow time for the fluids in the compressor to settle after the ice maker is moved or transported.
4. Before using the ice maker for the first time, please wait for 2 hours after the unit has been positioned, unmoved, in a stable and level place.
5. The appliance must be placed on a dry and level surface with sufficient ventilation, far from heat sources such as ovens, heaters and corrosive gases. Leave an 8-inch (20cm) clearance on all sides of the ice maker for proper ventilation.
6. Do not fill the water reservoir with hot water. This may damage the ice maker. It is best to fill the water reservoir with water of room temperature or lower.
7. For optimal results, operate the ice maker at an environment with an ambient temperature between 10°C and 25°C.
8. Before first use, clean the appliance by following steps in the Cleaning and Maintenance section of the manual.



OPERATING YOUR ICE MAKER

1. Ensure that the drain plug at the bottom of water reservoir is properly closed.
2. Plug the ice maker into a wall outlet, and the Ice-making indicator (F) blinks.



NOTE: Please make sure the ice maker has been unmoved before plugging in.

3. Open the top cover and remove the ice basket.
4. Fill the water reservoir with potable water only.


NOTE: Do not fill above the MAX water level mark. Avoid using distilled water.

5. Replace the ice basket and close the cover.
6. Press  button to select ice size.
7. Press  button to start the operation. The Ice-making indicator (F) lights up solid.
8. The ice-making cycle will last approximately 7-15 minutes, depending on the ambient temperature and water temperature.

The ice-making cycle starts with water being pumped into the ice tray situated below the evaporator. Over the next 7-15 minutes, ice forms on the evaporator. Once this has completed, the ice tray will tilt backwards and the remaining water in the ice tray is drained back into the water reservoir. The ice cubes are then dropped from the evaporator and pushed forward into the ice basket by the ice shovel. The ice tray will automatically move back into position under the evaporator and start the next cycle.

9. The ICE BASKET FULL indicator (F) will light up when the ice basket is full, and then the ice maker will automatically stop the ice-making cycle. Gently remove the ice from the ice basket using the ice scoop. About 5 seconds later, the ice maker will restart its ice-making function.
10. The ADD WATER indicator (G) will light up when the water reservoir runs out of water, and the ice-making cycle will stop automatically. At this time, remove the ice basket and add water to the water reservoir, then press  button again to restart the ice-making cycle.
11. When you have the desired amount of ice, stop the ice making cycle by pressing the  button and unplug the unit from the wall outlet.
12. Open the top cover and transfer the ice to freezer.
NOTE: The ice will last inside the ice maker for up to 18 hours, depending on the ambient temperature.
13. Allow the ice maker to warm up to room temperature.
14. It is suggested to replace the water every week. Please empty the water reservoir if the ice maker is not used for a long time.

CLEANING AND MAINTENANCE

1. Stop the ice-making cycle by pressing the  button. Unplug the ice maker from the wall outlet and allow to warm up to room temperature.
2. If residual water is found in the ice tray, gently push the ice tray back so that all water drains into the water reservoir.
3. Locate the drain and drain cap underneath the unit on the front right-hand side.
4. Place the unit on a ledge or counter-top and allow the front of the unit to overhang above the sink, bucket, or outdoor area that you intend to drain the water into.
5. Remove the drain cap to allow all the water to flow out. Replace the drain cap securely into the drain.
6. Fill the water reservoir with clean water, then hold and press the button for 10 seconds. The pump will begin to pump water and keep running for 15 minutes, then the unit will enter standby mode. At this time, open the drain plug and empty the water.
7. Wash the ice basket and ice scoop in warm soapy water. Rinse and dry thoroughly.
8. Clean the exterior of the ice maker with a soft, damp cloth. Use mild dishwashing soap if necessary.

NOTE: Never use harsh chemicals or abrasive cleaners. DO NOT immerse the unit in water.


9. Empty the water reservoir and thoroughly dry for storage if the ice maker will not be used for a long time.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSES	SOLUTION
ICE-MAKING indicator is not turning on.	<ol style="list-style-type: none"> 1. Ice Maker is unplugged. 2. The fuse is blown/circuit breaker is tripped. 3. Internal components are damaged. 	<ol style="list-style-type: none"> 1. Push plug completely into outlet. 2a. Replace fuse or reset circuit breaker. 2b. If too many items are plugged into a single circuit, move some items to a different plug. 3. Call Customer Service.
ICE BASKET FULL indicator light is on.	<ol style="list-style-type: none"> 1. Ice basket is full. 2. Sensor is blocked. 3. Sensor is not functioning. 4. Sensor is defective. 	<ol style="list-style-type: none"> 1. Remove ice from Ice basket. 2. Remove obstruction (e.g. ice, scoop) blocking the sensor. 3. Wipe sensor clean. 4. Contact Service Center.

<p>ICE BASKET FULL indicator light blinks.</p>	<ol style="list-style-type: none"> 1. Ice shovel is blocked. 	<ol style="list-style-type: none"> 1. Remove ice blocking the ice shovel. 2. Contact Service Center.
<p>ADD WATER indicator light is on.</p>	<ol style="list-style-type: none"> 1. Water reservoir is low or empty. 2. Filter at the bottom of water reservoir is blocked. 3. Pump has malfunctioned. 	<ol style="list-style-type: none"> 1. Add clean water to reservoir. 2. Clean filter. 3. Contact Service Center.
<p>Ice basket is full but ICE BASKET FULL indicator does not light up.</p>	<ol style="list-style-type: none"> 1. Ice basket full cannot be detected as sensor is interfered by sunlight. 	<ol style="list-style-type: none"> 1. Unplug unit, move to an area away from sunlight, then plug the unit to resume operation.
<p>Ice making performance is poor (e.g. ice too small, no ice produced).</p>	<ol style="list-style-type: none"> 1. Air Inlet/Outlet is blocked 2. Water temperature is too high. 3. Ambient temperature is too high. 	<ol style="list-style-type: none"> 1. Leave an 8-inch (20cm) clearance on all sides for proper ventilation. 2. Fill water reservoir with water temperature ranging from 8°C to 28°C. 3. Move the Ice Maker to a cooler place, where the ambient

	4. Refrigerant is leaking and/or refrigerating system is damaged.	temperature is 25°C or lower. 4. Call Customer Service.
Ice Maker is noisy.	1. Fan or pump is damaged.	1. Call Customer Service.



You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipment to an appropriate waste disposal center.