

## Smart Pillar Setup Instructions

### WiFi Mode

1. Download the Stellé App from the Apple App store (iOS devices) or the Google Play Store (Android devices)
2. *Press and hold* the **Power/Action Button** until the four buttons on top will illuminate **White**, indicating that the unit has been turned on
3. Once the unit is turned on, look at the WiFi/BT (Bluetooth) Mode Indicator LED to determine whether the Pillar is in WiFi or Bluetooth (BT) Mode
  - A. If the Pillar's WiFi/BT Mode indicator LED is **Green** and the LED ring is **illuminated**: The Pillar is already in **WiFi Mode**. Skip to step 5
  - B. If the Pillar's WiFi/BT Mode indicator LED is **Blue** and the LED ring is **not illuminated**: The Pillar is in **Bluetooth Mode** and must be switched to **WiFi Mode**. Continue to step 4
4. *Short press* the **Power/Action button**. The WiFi/BT indicator LED will change from **Blue** to **Green** and the LED ring will illuminate
5. Wait until the Pillar's LED ring changes from a slow pulsing Blue to a fast circling Light Blue (**Cyan**), indicating that the Pillar is ready to enter setup mode
7. To enter setup mode, *press and hold* the **Network Connection Button** until both the LED ring turns **Orange** and starts spinning, and the **Power/Action Button** starts to blink **Red**
8. Open the Stellé App, create a user account and login
9. Follow the instructions within the Stellé App to complete setup

