

PROTOCOL®

NEO-DRONE WIFI™

DRONE WITH LIVE STREAMING CAMERA

INSTRUCTION MANUAL



THANK YOU.

Thank you for your purchase of Protocol's **Neo-Drone Wifi with Live Streaming Camera**. You are about to experience the best of what remote control flight has to offer. We strongly recommend that you take the time to read this manual thoroughly. It contains many tips and instructions on how to get the most out of this aircraft and maintain it for a long life.

As with any aircraft, this is a precision flying machine. Treat it well and enjoy all the fun it has to offer, flight after flight.

TABLE OF CONTENTS

01	Safety & Precautions
02	Parts
04	Remote Batteries & Phone Installation
05	Charging the Drone
06	Start-Up Procedure
08	Operation
10	Performance Modes
11	Trim Adjustment
12	Troubleshooting
14	Flying Outdoors
15	Replacement Parts & Limited Warranty

SAFETY WARNINGS


HAVE FUN, BUT SAFETY FIRST!

- Read and follow instructions on how to synchronize electronics before each flight.
- To prevent damage to people or property, always avoid contact with other objects while in flight.
- Inspect aircraft prior to each flight and do not fly if damaged.
- Never expose product or any of its electronic parts to moisture, water, or heat sources.
- To prevent overheating, allow battery a cool-down period before recharging.
- To prolong engine life, allow a cool-down period between flights.
- Use only the charger and/or charging cable that is supplied with this item.
- Do not strike, cut, or pierce the internal battery or subject it to hard impacts.
- Do not mix old and new batteries or mix different types of batteries.
- Never attempt to modify function of vehicle or controller or attempt repairs using parts other than those supplied by Protocol. Spare parts are available at **www.ProtocolNY.com**

**THIS DEVICE USES COMPONENTS THAT OPERATE AT HIGH SPEEDS.
AS WITH ANY SUCH DEVICE, USE CAUTION TO OPERATE SAFELY.**

**FAILURE TO FOLLOW ANY OF THESE GUIDELINES MAY RESULT IN BODILY
INJURY OR DAMAGE TO PERSONAL OR PUBLIC PROPERTY.**



PARTS



DRONE

1. Canopy
2. Blade
3. Battery Compartment
4. Camera (manually adjusts up & down 90°)
5. On/Off Switch

PARTS



REMOTE

1. Power Switch
2. Forward/Backward
3. Bank Left/Right
4. Throttle
5. Turn Left/Right
6. Take Off/Landing
7. Compass Mode
8. Photo
9. Video
10. Performance Mode Selector
(push in)
11. Trimmer (push in)
12. Battery Cover
13. Phone Mount Slot

SPARE PARTS INCLUDED


- Replacement Blades
- Screwdriver

REMOTE BATTERIES & PHONE INSTALLATION

INSTALLING THE BATTERIES


Remove battery cover from controller. Insert 4 x 'AA' batteries according to indicated polarities. Replace battery cover.

1. Install batteries carefully.
2. Do not mix old and new batteries.
3. Do not mix different types of batteries.



INSTALLING THE PHONE


1. Insert the base of the mount into the slot until it clicks.
2. Pull the clamp open and insert the phone.
3. To remove, squeeze and push out.



CHARGING THE DRONE BATTERY

1. Make sure the drone is turned off.
2. Pull out the cartridge battery from the drone.
3. Connect the USB charging cable to the battery.
4. Plug the charger into a USB port. The battery light will glow red while charging and will turn green once fully charged.
5. Plug the battery back into the drone.

Charging time: 80 minutes --- Flying time: approximately 7 minutes



DO NOT CHARGE OVERNIGHT OR BEYOND THE CHARGING TIME STATED. DO NOT LEAVE BATTERY UNATTENDED.

*Battery: Li-Po, 3.7V, 500mAh

If you purchased extra batteries, allow the engines to cool between flights in order to prolong engine life.


CAUTION WHEN CHARGING

1. When charging, place product on a dry, well-ventilated surface and keep away from heat sources.
2. Always use adult supervision while charging.
3. In order to increase battery longevity, avoid repeat charging and excessive discharging.
4. As battery temperature is high immediately after flight, charge after cooling down for higher efficiency.
5. Do not strike or subject battery to hard impacts or sharp surfaces.
6. Do not use any other charger than that which is supplied with this item.
7. Do not use or leave battery near a heat source such as fire or space heater; exposure to heat may result in reduced performance or in some cases dangerous conditions.
8. If battery is left in charging state for an extended period of time after being fully charged, the battery may automatically discharge.
9. Never leave the battery unattended during charging.
10. Do not disassemble battery.
11. Do not submerge battery in water.

START-UP PROCEDURE

Before flying, the drone and transmitter must be turned on in sequence and synchronized.

1. Turn on the drone. The light on the drone will flash to indicate it's on. Place it on an even surface with the drone facing away from you.
2. Turn on the remote control.
3. Push the throttle the down and then release. The remote will beep two times and the flashing lights on the drone and remote will turn steady to indicate it has synced.
4. Your drone is now synchronized, and in stand-by mode awaiting Engine Idle command.




NOTE:

1. If after 30 seconds, it has not recognized the drone, turn off the controller and repeat Start-Up procedure.

STARTING THE ENGINE; ENGINE IDLE

After synchronizing the drone, move the throttle and direction sticks in to the lower center corners (silver lines) and release to go into Idle mode. The blades will rotate but the drone will not lift.



START-UP PROCEDURE



COMPASS MODE

Users have the option to exit the default orientation. In Compass Mode, users can operate the drone without orientation. Regardless of where the drone is pointing, it will turn left or right according to the remote's command.

Compass Mode is good for beginners and is useful for drones that fly too far away for the user to be able to tell the orientation.

Follow the below instructions to change to Compass Mode:

1. It is easiest to set up Compass Mode before flight. Sync and turn on the engines.
2. Make sure your drone is aligned with the remote as indicated in the picture.
3. Press down on the Compass Mode button once. The drone's back LED will start to flash and the remote will beep twice. This indicates that the drone is now in Compass Mode.
4. Press the Compass Mode button again to leave Compass Mode. The drone's LED will go steady and the remote will beep 3 times.



OPERATION: FLYING THE DRONE

TAKE-OFF:

1. Press the take off button. The remote will beep and the drone will hover a few feet off the ground. Then gently advance the throttle to a desired height and release. The drone will hover at that height.*

OR



2. From Idle mode, gently advance the throttle up to a desired height and release. The drone will hover at that height.*

LANDING:

1. Press the landing button to lower the drone to the ground.

OR


2. Push down on the throttle until the drone is on the ground.



NOTE:

- * The drone may drift a bit, especially in the first 30 seconds until the altitude sensor gets a good fix on the position. Some drift is normal.



- **EMERGENCY STOP:** Press and hold the take-off key for at least 1 second. The motors will stop and the drone will fall to the ground.





OPERATION: FLYING THE DRONE

FIRST TIME FLYERS!!! TAKE YOUR TIME! GO SLOW!



Practice hovering until you are comfortable with flight before attempting any other maneuvers. Make small movements letting the stick return to the center. If you start to lose control, don't panic. Just press land.



Pull the throttle left or right,
the drone turns to the left or right.




Push the direction lever up or down,
the drone flies forward or backward.



Pull the direction lever to the left or right,
the drone banks to the left or right.


PERFORMANCE MODES

The Neo-Drone Wifi features multiple performance or 'speed' modes. Choose the mode based on flight experience and level of comfort. At higher speeds, the drone will pitch more than at lower speeds. Neo-Drone Wifi is quite fast at its highest speed and requires more piloting skills to fly competently. For safety take time to develop advanced skills by practicing at lower speeds first. Press the Mode button in to change the performance mode. The remote control indicator will beep once at slowest speed and multiple times as speed is increased.




TRIM ADJUSTMENT

*The remote will emit a short beep for each adjustment and 1 long beep to indicate that it is even.




SIDEWAYS TRIM

When the drone drifts to the left or right side unintentionally, you can correct it by pushing in the trim button and pushing the direction stick in the opposite direction until it evens out.



FORWARD/BACKWARD TRIM

When the drone drifts forward/backward unintentionally, you can correct it by pushing in the trim button and pushing the direction stick in the opposite direction until it evens out.



LEFT/RIGHT TURN TRIM

When the drone spins left/right unintentionally, you can correct it by pushing in the trim button and pushing the throttle in the opposite direction until it evens out.

*NOTE: Trim adjustments are designed to counter drifts not caused by wind.

TROUBLESHOOTING

LOW BATTERY ALARM

The remote will start to beep in flight and the lights will flash when the battery is low. Land the drone as soon as possible and recharge the drone.


OUT OF RANGE ALARM

When the drone is close to flying out of range, the remote will beep rapidly. Fly the drone back into range immediately or you may lose control of the drone.

RE-CALIBRATING THE DRONE

If the drone crashes and after re-starting and trimming, it still is unstable, you have the option to re-calibrate the drone.

1. Turn on the drone and then the remote and sync.
2. Push and hold the direction stick to the lower right corner.
3. The lights will flash to indicate that the drone has re-calibrated.





TROUBLESHOOTING

*Allow 15 minutes to pass between full flights as this will give the motors a chance to cool down. Failure to do so could wear out and shorten the life of the motors.

SYMPTOM	POSSIBLE CAUSE	POTENTIAL SOLUTION
Neo-Drone Wifi does not respond	<ol style="list-style-type: none"> 1. Communication between controller and aircraft was not synchronized during set up 2. Battery power depleted on aircraft, controller or both. 	<ol style="list-style-type: none"> 1. To synchronize, turn on aircraft first, place it on level ground, and then turn on controller. 2. Charge aircraft and/or replace batteries in controller.
Response to control inputs intermittent or erratic	<ol style="list-style-type: none"> 1. Controller battery power nearly depleted. 	<ol style="list-style-type: none"> 1. Replace batteries in controller.
Neo-Drone Wifi will not hover or strafe correctly	<ol style="list-style-type: none"> 1. The aircraft was not on level ground during synchronization. 2. Trim settings are incorrect. 	<ol style="list-style-type: none"> 1. Re-synchronize aircraft and controller. 2. Re-calibrate the drone.
The motors stop running	<ol style="list-style-type: none"> 1. If a propeller is stuck, the motors will automatically stop running. 	<ol style="list-style-type: none"> 1. Pull the throttle down and release to start the engines.

HOW TO CHANGE THE BLADES

- To remove broken blades, hold the motor with one hand. Hold the broken blade with the other and then pull.
- All drones have two rotors that spin clockwise and two rotors that spin counter-clockwise.
- Make sure to place the blades on the correct axis or they will not spin correctly and the drone will not lift.
- Each blade is marked with A or B. There may be a number after the letter but you can ignore the number.
- Make sure to follow the graphic below to see where to place the blades.



FLYING OUTDOORS

HOW TO PREVENT FLY AWAYS

To prevent “fly-away” situations (where drones seem to fly away out of control) it is important to first test and practice within close range before letting the drone fly too far away.

Each drone is designed to turn off the engines if the radio signal is lost. It is important to know and test the range of your drone before flying. We recommend turning on and syncing the drone and walking away while testing the engines. Keep walking and testing until it is obvious when you reach the point where the signal is not controlling the drone. This will be the control limit for the conditions in which you are flying. Distance does vary somewhat based on environmental and weather conditions, so testing the limit is advised. Fly in a range that is good for easy visual operation of the drone.

IF YOU CAN'T SEE YOUR DRONE, THEN YOU CAN'T CONTROL YOUR DRONE.

* Fly-aways are not covered by warranty as they are overwhelmingly caused by pilot error.

REPLACEMENT PARTS

Thank you for your purchase of Protocol's **Neo-Drone Wifi**. We know that accidents can sometimes happen and that is why we offer spare parts kits on our website: **www.ProtocolNY.com**.

LIMITED WARRANTY

At Protocol, we're dedicated to bringing you innovative and well-designed products that make living fun and easy. We stand behind all of our products and warrant this to be free from defects in workmanship and materials for 30 days from the date of purchase. The warranty does not cover transportation damage, misuse, accident, or similar events. Specific legal rights pertaining to this warranty may vary by state.

For service claims or questions please consult our website **www.ProtocolNY.com**.

