



# G2G Vest

USER MANUAL



# Putting the vest on

- 1 Use the straps on each side and on each shoulder to put the vest on. Please see pictures below to see the orientation for the G2G Vest.
- 2 Adjust the length of the center poles in the front and in the back so that the belt sits on your hips.



FRONT



BACK

For more information please visit our website: [www.glidegear.net](http://www.glidegear.net)



# Assembly

The G2G Vest's arm can be set in 4 different configurations:

- Arm in the front or in the back of the vest
- Arm on the right or on the left

1 Loosen the screw on each side of the plate holding the poles at the bottom of the vest in the front or in the back depending on the configuration you would like. See Fig. 1.

2 Remove the poles from the holder. See Fig. 2.

3 Slide the arm holder on the poles.  
Make sure to orientate the holder so that the arm will be on the side you want.

For instance, Fig. 3 shows the holder positioned for the arm to be on the left.

4 Slide the arm in the holder and secure it using the 2 set screws.



Fig. 1.



Fig. 2.



Fig. 3.





# Front Configurations



**Configuration:**

Arm in the front

Arm on the right



**Configuration:**

Arm in the front

Arm on the left

For more information please visit our website: [www.glidegear.net](http://www.glidegear.net)



# Back Configurations

Having the arm in the back distributes more of the load on the hips which most people find more comfortable and easier to do for extended periods of time.



**Configuration:**

Arm in the back

Arm on the left



**Configuration:**

Arm in the back

Arm on the right

For more information please visit our website: [www.glidegear.net](http://www.glidegear.net)