



MARATHON



## HOTEL COLLECTION

BY MARATHON | 88  
EST. 1939

**WIRELESS FAST DUAL CHARGING CLOCK  
USER MANUAL**


**HORLOGE À DOUBLE RECHARGE RAPIDE  
SANS FIL MODE D'EMPLOI**

**OROLOGIO A DOPPIA RICARICA VELOCE E  
SENZA FILI ISTRUZIONI PER L'USO**

**INSTRUCCIONES DE FUNCIONAMIENTO DEL  
RELOJ INALÁMBRICO DE CARGA DUAL RÁPIDA**

**SCHNELLER DRAHTLOSER DOPPELTER  
LADETAKT BENUTZERHANDBUCH**

## OVERVIEW




### Part A – Front and Back

- A1: Time
- A2: z<sup>z</sup> Icon
- A3: DST Icon
- A4: Snooze Icon
- A5: Alarm Time
- A6: Battery Icon
- A7: Lightning Bolt Icon
- A8: USB Port
- A9: A/C Adapter Jack
- A10: DST ON/OFF Button

### Part B – Sides

- B1: Alarm Switch
- B2: TIME SET / ALARM SET Switch



#### Part C – Top

- C1: ▼ Button
- C2: Charging Pad
- C3: SNOOZE / DIMMER Button
- C4: ▲ Button

#### Part D – Bottom

- D1: Battery Compartment

### FEATURES

- Qi wireless charging: Simply place any Qi enabled wireless charging device on the charging pad. No cable connection required.
- Digital clock with daily alarm function.
- Crisp and vibrant full colour LED display.

### POWER SOURCE

This unit uses 1 A/C power adapter and 1 x CR2032 battery for backup.

## GETTING STARTED

1. Plug in the A/C adaptor into the adaptor jack **(A9)**, remove the battery tag from the rear compartment **(D1)** to activate the clock backup battery which is already installed in the clock when you first receive it.
2. When both the A/C adaptor and CR2032 battery have been installed, the unit will automatically switch to the external power supply.
3. The CR2032 battery will store all programmed settings in case the A/C adapter is unplugged. If the CR2032 battery is removed, all programmed settings will be lost immediately when the A/C adapter is unplugged.

*NOTE: The clock will not operate without the A/C adapter.*

## SETTING THE TIME

Hold the **SNOOZE / DIMMER (C3)** button for 2 seconds to select time display in 12-hour or 24-hour format.

1. Slide **⊙ TIME SET / ☒ ALARM SET** switch **(B2)** to **⊙ TIME SET** to enter time setting mode.
2. Press **▼** or **▲** button **(C1 or C4)** to adjust the time setting. Press and hold the **▼** or **▲** button to speed up the rate at which the value changes.
3. Slide **⊙ TIME SET / ☒ ALARM SET** switch **(B2)** to **LOCK** to confirm the current displayed settings.

*NOTE: The HOUR value CANNOT be adjusted directly. The HOUR value can only be changed through the adjustment of the MINUTE value.*

## DAYLIGHT SAVINGS TIME (DST)

- To activate daylight savings time for the clock, press the **ON/OFF** button (A10). You will note that on the display, the time (A1) will increase by 1 hour and the **DST** icon (A3) will appear.
- To deactivate daylight savings time, press the **ON/OFF** button (A10). You will note that on the display, the time (A1) will decrease by 1 hour and the **DST** icon (A3) will disappear.



## SETTING THE ALARM

1. Slide **⊙ TIME SET / ☹️ ALARM SET** switch (B2) to **☹️ ALARM SET** to enter alarm setting mode.
2. Press **▼** or **▲** button (C1 or C4) to adjust the alarm time setting, slide **⊙ TIME SET / ☹️ ALARM SET** switch (B2) to **LOCK** to confirm setting.
3. Press and hold the **▼** or **▲** button to speed up the rate at which the value changes.

*NOTE: The HOUR value CANNOT be adjusted directly. The HOUR value can only be changed through the adjustment of the MINUTE value.*

## USING THE ALARM AND SNOOZE FUNCTION

1. Slide **☹️ ALARM** switch (B1) to activate or deactivate the alarm function. There are three options: **HI** (alarm sound will be louder), **LO** (alarm sound will be quieter), **OFF** (alarm will not sound at all).
2. When the alarm function is activated, the **☹️** icon (A4) will appear on the display.
3. When the alarm sounds, press the **SNOOZE / DIMMER** button (C3) to pause it and enter snooze mode which will delay the alarm for 5 minutes.

4. The alarm will sound again after 5 minutes. The **z** icon (**A2**) flashes on the display during the snooze time. This process can be repeated 7 times. After snoozing the clock 7 times, the alarm will not sound again.
5. When the alarm sounds,  icon (**A4**) flashes on the display.
6. Slide  **ALARM** switch (**B1**) to **OFF** to deactivate the alarm function or press any of the buttons to stop the alarm, with the exception of the **SNOOZE / DIMMER** button (**C3**). If no selection is made, the alarm signal will sound for 3 minutes and then stop automatically.

## USB PORT

The maximum current output of USB port is 2A.

*NOTE: Only charge devices that self-regulate.*

## BACKLIGHT

### Backlight Brightness Adjustment




Press the **SNOOZE / DIMMER** button (**C3**) to switch the backlight brightness. There are three selectable options: Low, Medium, High. Every press of the **SNOOZE / DIMMER** button (**C3**) will alternate through the 3 options.

### LED Backlight Colour

1. Press the **▼** or **▲** button (**C1** or **C4**) to select your preferred LED backlight colour.
2. To have the LED backlight colour change automatically, hold the **▼** or **▲** button for 2 seconds. Press the **▼** or **▲** button again to stop the color changing.

## QI WIRELESS CHARGING

*NOTE: You must have a Qi enabled device to use the Qi Wireless Charging function of this clock. If you have an iPhone 7 or older, you likely are not able to use this function. You must check your device's user manual to confirm if your device is compatible with this feature.*

1. Place your Qi enabled device at the center of the charging pad **(C2)**.
2. When a successful link occurs between the clock and the device, the  icon **(A6)** will appear on the screen. While the device is charging, the  icon **(A7)** will continually flash on the screen. When the device is fully charged, the  icon **(A7)** will stop flashing.
3. If an **ERROR** icon flashes on the screen, it means there is a problem which prevents the device from charging. Here are some possible fixes to try:
  - Remove any metallic object between the device and charging pad **(C2)**, including metallic cases.
  - Remove the device from the charging pad **(C2)** and wait until the **ERROR** icon disappears. Place the obstruction free device at the center of the charging pad **(C2)** to try again.

### **WARNING:**

Do not place any metallic object between the Qi enabled device and charging pad **(C2)**, this may lead to overheating and cause damage to both the device and the charging pad **(C2)**.

## CLEANING

1. Do not expose the unit to extreme temperatures, water, or severe shock.
2. Avoid cleaning the unit with any corrosive materials, such as perfume, alcohol, or cleaning agents. Always clean the unit with a damp cloth. Never spray any cleaning agents onto the unit directly.

*NOTE: You must unplug your clock from the electrical outlet before cleaning to avoid the risk of shock or damage.*

Our Products contain high quality components and are designed to facilitate recycling. Our products or product packaging are marked with the symbol below. The symbol indicates that the product must not be treated as municipal waste. It must be disposed of separately via the appropriate return and collection systems available. By following these instructions you ensure that this product is treated correctly and help to reduce potential impacts on the environment and human health, which could otherwise result from inappropriate handling. Recycling of products helps to conserve natural resources and protect the environment. For more detailed information on collection and recycling systems for this product, please contact the shop where you purchased it, your local dealer or sales / service representatives.

