


#### HOURLY CHIME SETTING

1. In normal time mode, press and hold **C** with alarm time displayed.
2. Press **A** at the same time until all days of the week appear / disappear.



#### BATTERY REPLACEMENT

When the LCD becomes dim, replace with a new LR44 battery at once.



# MARATHON

Re-order no. ST083000

Other Marathon products that may interest you:



To order or for more information, please call us at  
**1-800-822-4329**

or visit our website at  
[www.MarathonWatch.com](http://www.MarathonWatch.com)

## STOPWATCH

### USER'S INSTRUCTION

#### FEATURES

- Time / Calendar display
- Hour (12/24-hour format), minute, second, month, date and day
- Stopwatch: 1/100 second for 30 minutes, 1 second up to 24 hours



#### FUNCTION KEYS

- A. MODE button:**
- Switch among normal time mode, stopwatch mode, alarm time setting mode and normal time setting mode.
- B. START/STOP button:**
- Toggle between normal time and month/date display.
- C. SPLIT/RESET button:**
- Toggle between normal time and alarm time display.

#### DISPLAY SYMBOLS

##### Normal Time Mode

1. Day of the week
2. Hour
3. Minute
4. Second



##### Alarm Time Mode


1. Alarm time
2. Alarm icon




#### STOPWATCH MODE

In normal time mode, press **A** once to activate this mode. Press **C** to reset the stopwatch to "0:0000" before using the stopwatch.


1. Accumulate elapsed time measurement: **B-B-B-B-C**



2. Split time measurement: **B-C-C-B-C**



3. Measurement between two competitors: **B-C-B-C-C**




#### Note:

1. Press **A** to return to the normal time mode.
2. 1/100 second stopwatch for 30 minutes, and 1 second stopwatch from 31st minutes up to 24 hours.

#### TIME / CALENDAR SETTING

1. In normal time mode, press **A** three times to activate time setting mode.
2. Press **C** to select the setting items. The sequence will be: Second > Minute > Hour > Date > Month > Day.
3. Press **B** to increase the setting value and change 12/24 hour format when setting the hour.
4. Press **A** to return to normal time mode.




#### Note:

1. Press **B** to add one minute when the second is more than or equal to 30 and reset it to 00 when the value is less than 30.

#### ALARM TIME SETTING

1. In normal time mode, press **A** twice to activate this mode.
2. Press **B** to change the hour value.
3. Press **C** to select the minute and press **B** to change the minute value.
4. Press **A** to return to normal time mode.



#### Note:

1. To turn the alarm ON/OFF, press **B** and **C** at the same time.
2. The alarm will turn on automatically once you set the alarm time.
3. When the alarm is on,
  - (1) It will last one minute without pressing any button then not sound again until the next day.
  - (2) When the alarm is sounding, press **B** to activate the snooze function and the alarm will start again after 5 minutes. It will sound up to one minute then not sound again until the next day.
  - (3) Press **C** to stop the alarm.