


STOPWATCH - ST083009

USER'S INSTRUCTION

FEATURES

- Time / Calendar display
- Hour (12/24-hour format), minute, second, month, date and day
- Stopwatch: 1/100 second for 30 minutes, 1 second up to 24 hours



FUNCTION KEYS

A.MODE button:

- Switch among normal time mode, stopwatch mode, alarm time setting mode and normal time setting mode.

B.START/STOP button:

- Toggle between normal time and month/date display.

C.SPLIT/RESET button:

- Toggle between normal time and alarm time display.

DISPLAY SYMBOLS

Normal Time Mode

1. Day of the week
2. Hour
3. Minute
4. Second



Alarm Time Mode


1. Alarm time
2. Alarm icon




STOPWATCH MODE

In normal time mode, press **A** once to activate this mode. Press **C** to reset the stopwatch to "0:0000" before using the stopwatch.


1. Accumulate elapsed time measurement: B-B-B-B-C



2. Split time measurement: B-C-C-B-C



3. Measurement between two competitors: B-C-B-C-C




Note:

1. Press **A** to return to the normal time mode.
2. 1/100 second stopwatch for 30 minutes, and 1 second stopwatch from 31st minutes up to 24 hours.

TIME / CALENDAR SETTING

1. In normal time mode, press **A** three times to activate time setting mode.
2. Press **C** to select the setting items. The sequence will be: Second > Minute > Hour > Date > Month > Day.
3. Press **B** to increase the setting value and change 12/24 hour format when setting the hour.
4. Press **A** to return to normal time mode.




Note:

1. Press **B** to add one minute when the second is more than or equal to 30 and reset it to 00 when the value is less than 30.

ALARM TIME SETTING

1. In normal time mode, press **A** twice to activate this mode.
2. Press **B** to change the hour value.
3. Press **C** to select the minute and press **B** to change the minute value.
4. Press **A** to return to normal time mode.



Note:


1. To turn the alarm ON/OFF, press **B** and **C** at the same time.
2. The alarm will turn on automatically once you set the alarm time.
3. When the alarm is on,
 - (1) It will last one minute without pressing any button and will not sound again until the next day.
 - (2) When the alarm is sounding, press **B** to activate the snooze function and the alarm will start again after 5 minutes. It will sound up to one minute and not sound again

until the next day.

(3) Press **C** to stop the alarm.

HOURLY CHIME SETTING

1. In normal time mode, press and hold **C** with alarm time displayed.
2. Press **A** at the same time until all days of the week appear / disappear.



BATTERY REPLACEMENT

When the LCD becomes dim, replace with a new LR44 battery at once.



MARATHON

Re-order no. ST083009

Other Marathon products that may interest you



www.MarathonWatch.com