

USING THE JUICER



XL COLD PRESS COMPACT JUICER

SJX-1WH / SJX-1GY

BEFORE YOU BEGIN:

- Make sure the POWER SWITCH is in the OFF position **O** before you begin.
- Make sure the JUICE CONTAINER and PULP CONTAINER are in the correct position.
- Make sure the JUICE CAP is open before you begin juicing.



PREPARATION:

Prepare your fruits and/or vegetables. It is recommended to cut stringy vegetables like celery into small strips or cubes. Larger produce like carrots only need to be cut enough to fit through the XL CHUTE.

See examples below:



CELERY

Cut into strips



APPLES

Whole, Halved or Quartered



CARROTS

Whole or Halved



LEAFY GREENS

Whole or Chopped

CONTINUOUS OPERATION TIME:

Do not use the juicer continuously for longer than **20 minutes per session**. Allow the juicer to rest for 10 minutes between operations.

OVERHEAT PROTECTION:

Your juicer is equipped with an automatic shut off feature to protect your motor from burning out. If the motor overheats during juicing, your machine will automatically shut off. If this happens, it is recommended to allow your juicer to rest for 20-30 minutes after overheat protection kicks in. For additional information, refer to the troubleshooting guide on page 15.



STEP 1:

Begin by filling up the CHUTE with fresh produce for simple batch juicing.



STEP 2:

Plug in the power cord to an electrical outlet. Turn on the machine with the POWER SWITCH by pressing the line symbol **—**.

NOTE: The machine will not turn unless the parts are properly assembled. Refer to the assembly instructions on page 8.



STEP 3:

To juice even more, add produce to the QUICK FILL FLIP TOP or insert through the slot for easy continuous feed operation.



STEP 4:

Allow the juicer to run for 30 seconds after the last ingredient was fed. Then turn off the machine and close the JUICE CAP.

NOTE: The PLUNGER only needs to be used if ingredients are stuck inside the FEEDING CHUTE. Using the REVERSE Function **R** can also dislodge food.