

# ILT1000, ILT2400, ILT5000, ILT6000 API Documentation

## Revision Table

May 8 2015	v1.5	Initial Release under this form, capturing firmware revisions up to and including 3.0.5.8
May 15 2015	v1.6	Added setwireless command
June 30 2015	v1.7	<ul style="list-style-type: none"><li>• Updated getflash to add return value of -513 when asking for a minimum light level that could not be measured in the given range (Rf + voltage sensitivity) due to saturation below the minimum light level</li><li>• added setsampletimetemp functionality to change sample time without saving to flash</li><li>• added usecalfactortemp functionality to change sample time without saving to flash</li><li>• added usefeedbackrestemp functionality to change sample time without saving to flash</li></ul>
August 11 2015	v1.8	<ul style="list-style-type: none"><li>• fixed typo where getambientlevel API was listed as setambientlevel</li><li>• moved setwflisten API to OEM commands</li></ul>
August 21 2015	v1.9	<ul style="list-style-type: none"><li>• Added startpeak, stoppeak, getpeak, startintegrate, stopintegrate, getintegrate</li><li>• Added configbackup, configrestore to OEM commands</li></ul>
September 11, 2015	v2.0	<ul style="list-style-type: none"><li>• Removed references to OEM –only commands outside of the revision table.</li></ul>
January 8, 2016	v2.1	<ul style="list-style-type: none"><li>• Only non-ILTx00 updates</li></ul>
March 18, 2016	v2.2	<ul style="list-style-type: none"><li>• Update setcalfactor to note move to sensitivity factor from multiplier (FW 2.0.0.8).</li><li>• Update set100perc to indicate return value of -500 if saturated for firmware versions &gt;= 3.0.8.9</li></ul>
May 2, 2016	v2.3	<ul style="list-style-type: none"><li>• Removed “Product Generations” section.</li><li>• Add short-cuts gt (gettrans) and go (getod)</li></ul>

# ILT1000, ILT2400, ILT5000 API Documentation

The ILTxx00 devices use a simple text-based API for communication with user applications, as well as for use with a basic terminal server.

## Document Convention

The API table below contains two columns. In the first column is the API/command name. In the second column is the API/command's definition. The definition contains several elements and convention as follows.

- Actual command and responses will use the `Courier New` font.
- Command parameters are identified in [brackets], within the "Syntax" description. The brackets themselves are not used in the command syntax, as is illustrated by the "Example command" listed for any command with parameters.
- The "Normal return value(s)" and "Error return value(s)" information is pertinent to the `echooff` mode of operation (see `echoon` and `echooff` commands in the table below). When using `echoon` mode, return values are self-explanatory.
- An N/A for an "Error return value(s)" indicates that errors are not returned and not expected for this command.
- "Example return" is listed, on some commands, to provide an example of the output. In this field, any text following a dash ("-"), as well as the dash itself, are not part of the actual output and only listed to help describe the output.
- Commands are listed alphabetically.
- The optional "Persist through power-cycle" field will indicate whether or not the configuration is stored in flash memory and "sticks" through power cycles.
- Note that all commands are case sensitive, and always all-lowercase.
- The "Support Starting in Firmware Version" data indicates the firmware version where the command is supported by the manufacturer. The actual command may be present in earlier versions of firmware, but not supported.

# Theory of Operation

Below is the Theory of Operation for interfacing with the device using the API defined further below.

- The device responds to a number of commands (together known as the command-line API) delivered via the USB port.
- The USB port is configured on the device as a USB Serial Port. As a result, interfacing can be done with any standard terminal programs (hyperterminal, putty, MAC terminal window, etc), or direct programming via LabView, .NET, etc.
  - o Serial port settings are:
    - Baud Rate: 115200
    - Data Bits: 8
    - Parity bits = None
    - Stop bits = 1
    - Flow Control = None
- The device behaves as follows and in sequence:
  - a. Perform analog/digital conversion and mathematical functions as part of optical level detection
    - i. Buffer up to 4 characters of any incoming commands while performing the processing above
  - b. Check for any characters in the buffer referenced above to indicate an incoming command and process any commands as required. Important programming notes:
    - i. It can take up to 50ms for the system to complete complex analog/digital tasks and process the remainder of the command that was not buffered.
    - ii. The device determines the completion of the command by detecting a “\r” character, i.e. ASCII code 13 decimal.
  - c. Start all over from the top at (a)...
- As a result of the above device behavior, the recommended method to program each device is to:
  - o Always append commands with \r to indicate the command completion.
  - o Send the first character of the command, for example the “g” in “getcurrent\r”.
  - o Pause 50ms
    - Any `setsamplecount` settings of more than 50 (2.x firmware) and `setsampletime` settings of more than 250ms (3.0.5.9 and higher firmware) and include sampling in 50ms or greater chunks of time. During this time, command characters can be dropped. If this is the case, command returns will result in -999, indicating that the command was not understood.
    - This time delay can be lowered when `setsampletime` and `setsamplecount` settings are lower.
  - o Send the remainder of the command, i.e. “etcurrent\r”. While there are no pauses required between characters as the device is rapidly draining the incoming serial port at this point, some customers have found more success by inserting a 1ms pause between each character sent within their program.
  - o Immediately start sensing the response from the device.
    - The device will always send a response to acknowledge the status of the command completion as well as to return values for “get” commands.
    - The response will always be terminated with a “\r\n” (13 decimal, 10 decimal) sequence. This can be used to sense the end of the response and start sending the next command.
      - Regarding time-outs for command responses, “get” commands will typically respond within 100ms. “set” commands that store their configuration in flash memory can take up to 5 seconds to respond. Other special commands like “setuserdark” and “captureflash” can take longer to respond.
    - Be careful not to expect an immediate response from the device. For instance, after sending the remainder of the command, i.e. “etcurrent\r”, do not immediately check the receive buffer and give-up if data is not sensed. It can take over 1 ms for even the fastest commands to return. It is

better (more robust) to (a) send the remainder of the command, (b) continue looking for and processing a response until “\r\n” is sensed, and (c) use a timeout to detect when a response has not returned within some time period.

- Each device is single threaded, meaning that commands and responses need to be processed in sequence. A 2<sup>nd</sup> command cannot, for example, be initiated before the 1st command’s response is fully processed. As a result, if a multi-threaded application is accessing the device, a programmatic lock must be placed around device command/response sequences to make sure multiple threads do not attempt to access the device at the same time.
  - o If multiple devices are being monitored, a single lock can be used for access to all devices. This is simpler from a coding perspective, but it is not as efficient as it does not allow multiple devices to operate in parallel. For the best performance it is recommended that a per-device lock be established. This allows all devices to be accessed in parallel.
  - o As a further performance benefit when monitoring multiple devices, the delay after the first character can be performed in parallel across all devices. For example, if sending “getcurrent\r” to 5 devices, one would:
    - Send “g” to all 5 devices
    - Wait 50ms
    - Send “etcurrent\r” to all devices
    - Process the reply from all devices
- Many of the more popular command have had 2-character short-cuts added over time. This allows rapid, repeated access to sensor data because the command fits in the 4-character buffer and does not require a delay after the first character of the command. These commands, and short-cuts, are as follows:
  - o gc = getcurrent, introduced in FW version 3.0.5.4
  - o gi = getirradiance, introduced in FW version 3.0.5.4
  - o gv = getvoltage, introduced in FW version 3.0.5.4
  - o gt = gettrans, introduced in FW version 3.0.9.4
  - o go = getod, introduced in FW version 3.0.9.4

## API

<p>captureflash</p> <p>Support Starting in Firmware Version: 3.0.5.8</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b></p> <pre>capture flash [trigger type] [trigger level] [minimum light level] [timeout period] [voltage sensitivity] [trigger offset time] [integration time] [save to flash] [save only above minimum light level]</pre> <p><b>What it does:</b></p> <p>This command enters a mode where only values are sent back in response to a command. This is the default mode on power up of the device, and the mode used for programming by an application.</p> <p><b>trigger type:</b></p> <ul style="list-style-type: none"> <li>0 = trigger in (start capturing "trigger offset time" milliseconds before trigger in signal)</li> <li>1 = trigger out (start capturing "trigger offset time" milliseconds after trigger out signal)</li> <li>2 = trigger on light level (start capturing after "minimum light level" exceeded)</li> <li>3 = manual trigger (start capturing immediately)</li> </ul> <p><b>trigger level (applies to trigger type 0 and 1, ignored otherwise):</b></p> <ul style="list-style-type: none"> <li>low = trigger on logic low condition (transition from high to low)</li> <li>high = trigger on logic high condition (transition from low to high)</li> </ul> <p><b>min light level</b></p> <p>Floating point value representing the minimum light level above which capture will start when trigger type is set to 2</p> <p><b>timeout period</b></p> <p>The number of seconds (0 to 300) that the routine will wait for a trigger.</p> <p><b>voltage sensitivity</b></p> <ul style="list-style-type: none"> <li>1 = lowest sensitivity voltage gain (brightest light)</li> <li>2 = medium sensitivity voltage gain</li> <li>3 = highest sensitivity voltage (lowest light level)</li> </ul> <p><b>trigger offset time</b></p> <p>The number of milliseconds (0-20) that the trigger will be offset as follows, by trigger type:</p> <ul style="list-style-type: none"> <li>0 : not applicable</li> <li>1 : number of milliseconds before trigger in</li> <li>2 : number of milliseconds after trigger out</li> <li>3 : number of milliseconds before minimum light level is sensed</li> </ul> <p><b>integration time</b></p> <p>The number of milliseconds (1-40000) that the flash signal will be captured</p> <p><b>save to flash</b></p> <ul style="list-style-type: none"> <li>0 = do not save to flash (just capture results, see <code>getflash</code>)</li> <li>1 = save to flash (4096 data points are saved across the integration time, use <code>getlogdata</code> to download)</li> </ul> <p><b>save only above minimum light level (applicable to trigger type 2)</b></p> <ul style="list-style-type: none"> <li>0 = save all data points</li> <li>1 = only save data points above the minimum light level</li> </ul> <p><b>Normal return value:</b></p> <ul style="list-style-type: none"> <li>0 on success</li> </ul>
---	---

<p>captureflash</p> <p>(Continued)</p>	<p>Error return value(s):</p> <ul style="list-style-type: none"> <li>-500 if missing fields</li> <li>-501 if bad trigger type. Must be 0-3.</li> <li>-502 if bad trigger level. Must be “low” or “high”</li> <li>-503 if bad minimum light level. Must be greater than 0.</li> <li>-504 if bad timeout period. Must be 0-300.</li> <li>-505 if bad voltage sensitivity. Must be 1-3.</li> <li>-506 if bad trigger offset. Must be 0-20.</li> <li>-507 if bad integration time. Must be 1 – 40000.</li> <li>-508 if bad save to flash value. Must be 0 or 1.</li> <li>-509 if bad save only above min value. Must be 0 or 1.</li> <li>-510 if calibration factor not in use. See usecalfactor.</li> <li>-511 if save to flash is set to 1, but data is already in flash. See eraselogdata.</li> <li>-512 if timeout period expired before trigger was completed</li> <li>-513* if a minimum light level is too high to be measured (device will saturate before reaching the level) with given range (Rf + voltage sensitivity)</li> </ul> <p>*Added in 3.0.6.7</p> <p>Persist through power-cycle: N/A</p> <p>Example command (trigger on light level, “low” trigger level ignored, minimum light level = 20e-3 calibrated units, 2 second timeout, Low voltage sensitivity, 5 millisecond trigger offset, 40 millisecond integration time after trigger, save data to flash for later retrieval, save only the light levels above the minimum trigger level):</p> <pre>captureflash 2 low 20e-3 2 1 5 40 1 1</pre>
<p>clearambientlevel</p> <p>Support Starting in Firmware Version: 3.0.5.8</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: clearambientlevel</p> <p>What it does: This command removes any ambient levels configured with setambientlevel.</p> <p>Normal return value(s): 0 on success</p> <p>Error return value(s): N/A</p> <p>Persist through power-cycle: No</p>

<p>echooff</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     echooff</p> <p>What it does:     This command enters a mode where only values are sent back in response to a command. This is the default mode on power up of the device, and the mode used for programming by an application.</p> <p>Normal return value:     0 on success</p> <p>Error return value(s):     N/A</p> <p>Persist through power-cycle:     No</p>
<p>echoon</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     echoon</p> <p>What is does:     This command enters a verbose mode whereby contextual help is echoed back for each command completion. The mode is useful when interacting with the device from a terminal server or from the CLI program.</p> <p>Normal return value:     0 on success</p> <p>Error return value(s):     N/A</p> <p>Persist through power-cycle:     No</p>

<p><code>erasecalfactor</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>erasecalfactor [calibration number, 1-20]</code></p> <p><b>What it does:</b>  This command erases the calibration data associated with the calibration factor. This includes the calibration factor description, the current-to-irradiance multiplier, and the saturation current.</p> <p>Starting in 3.0.5.3, if the active calibration factor is erased, the cal factor is set to 0 indicating no cal factor in use.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  -500 if missing fields  -501 if bad factor number  -502 if error erasing flash</p> <p><b>Persist through power-cycle:</b>  Yes</p> <p><b>Example command:</b>  <code>erasecalfactor 5</code></p>
<p><code>eraseirrdata</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: 3.0.5.3</p>	<p><b>Syntax:</b>  <code>eraseirrdata</code></p> <p><b>What it does:</b>  This command erase any flash memory associated with the tabulated current-to-irradiance curve established with either <code>setsimpleirrcal</code> or multiple calls to <code>setirrdatapoint</code>.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  N/A</p> <p><b>Persist through power-cycle:</b>  Yes</p>



<p><code>eraselogdata</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>eraselogdata</code></p> <p><b>What it does:</b>  This command erases any log data that has been stored in the device's flash memory. See also <code>startlogdata</code> and <code>stoplogdata</code>.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  -500 if logging is currently active (must use <code>stoplogdata</code> first)  -501 error erasing the data from flash</p> <p><b>Persist through power-cycle:</b>  Yes</p>
<p><code>get100perc</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>get100perc</code></p> <p><b>What it does:</b>  Prior to 3.0.5.3, this command returns the sensor voltage at the time the 100% value was set with <code>set100perc</code>.</p> <p>Starting in 3.0.5.3, this command returns the sensor current at the time the 100% value was set with <code>set100perc</code>.</p> <p><b>Normal return value(s):</b>  Prior to 3.0.5.3: Voltage for 100% transmission, volts (firmware <math>\geq</math> 2.1.0.0) or microvolts (firmware <math>&lt;</math> 2.1.0.0)</p> <p>Starting in 3.0.5.3: Current for 100% transmission.</p> <p><b>Error return value(s):</b>  -500 if the 100% value was never set</p>
<p><code>getambientlevel</code></p> <p>Support Starting in Firmware Version: 3.0.5.8</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>getambientlevel</code></p> <p><b>What it does:</b>  This command returns the existing ambient light level that is removed from all current and light level readings.</p> <p><b>Normal return value(s):</b>  Ambient light level, based on detector current</p> <p><b>Error return value(s):</b>  N/A</p> <p><b>Persist through power-cycle:</b>  No</p> <p><b>Example return:</b>  <code>5.981e-6</code></p>

<p>getambienttemp (Gen2, Gen3)</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getambienttemp</p> <p>What it does: This command returns the ambient temperature as sensed by the device. This differs from gettemp which returns the internal temperature of the microcontroller.</p> <p>Normal return value(s): Temperature in degrees F (x100 for firmware &lt; 2.1.0.0).</p> <p>Error return value(s): -500 Command not supported</p>
<p>getapiversion</p> <p>Support Starting in Firmware Version: 2.1.0.0</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getapiversion</p> <p>What it does: This command returns the api version for the firmware. From time-to-time, the CLI API return values may change the return value or formats. When this happens the API version is increased such that programs can proactively determine the expected return values.</p> <p>API Changes from v1 to v2:</p> <ul style="list-style-type: none"> <li>• get100perc, getvoltage, getvx1, getvx17, getvagc3, getvped, getvref, set100perc all changed from returning microvolts to returning volts in decimal form</li> <li>• getcurrent changed from returning picoamps to amps in scientific notation</li> <li>• getirradiance changed from returning “pico” values to standard values in scientific notation</li> <li>• gettrans changed from returning percent transmission x 10 to percent transmission in decimal form</li> <li>• getod changed from returning optical density x 100 to optical density in decimal form</li> <li>• getambienttemp changed from returning temp x 100 to tempx1</li> <li>• getlogdata return values changed to reflect unit changes above, with all values returned in scientific notation</li> </ul> <p>API Changes from V2 to V3</p> <ul style="list-style-type: none"> <li>• Added new API’s, noted in this document as Supported Starting in Firmware Version 3.0.5.3 or later.</li> <li>• set100perc and get100perc changed to return current as opposed to voltage</li> <li>• deprecated setclockfreq, setirrdatapoint, storeirrddata, eraseirrddata, setsimpleirrcal, hiddenhelp</li> <li>• deprecated setsamplecount (use setsampletime) and getsamplecount (see getsampletime)</li> <li>• Overloaded usefeedbackres to return the setting in use if no parameters are provided</li> </ul> <p>Normal return value(s): -999 for firmware versions earlier than 2.1.0.0, indicating API version 1. 2 for firmware versions 2.1.0.0 and greater 3 for firmware versions 3.0.5.3 and greater</p> <p>Error return value(s): N/A</p>

<p>getauxserialno</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getauxserialno</p> <p>What it does: This command returns the auxiliary serial number of the device. The serial number is stored in one-time-programmable memory at the time of manufacture.</p> <p>Normal return value(s): Device serial number</p> <p>Error return value(s): -500 device serial number has not been set</p> <p>Example return: sn17839-0001</p>
<p>getbias (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.5.4</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getbias</p> <p>What it does: This command returns the level of bias voltage applied to the detector.</p> <p>Normal return value(s): 0 indicating no bias is applied 5 indicating that voltage is applied such that the anode is 5V more negative than the cathode</p> <p>Error return value(s): -501 if not supported on this generation of device</p>

<p><code>getcalfactor</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>getcalfactor</code> [optional, calibration factor, 1-20]</p> <p><b>What it does:</b>  Without the optional parameter, this command returns the calibration factor currently in use. With the optional parameter, this command returns the calibration factor details for a particular calibration factor. This includes the following information, separated by space: calibration factor description, current-to-irradiance multiplier(x1000), and saturation current in microamps. A typical use case is to use the command without the optional parameter to determine which calibration factor is in use, followed by issuing the command with the optional calibration factor to determine the details of the calibration factor definition.</p> <p><b>Normal return value(s):</b>  Without the optional command line parameter:</p> <p>0 if no calibration factor in use  1-20 indicating which calibration factor is in use</p> <p>With the optional command line parameter:</p> <p>[calibration factor description] [current-to-irradiance multiplier(x1000)] [saturation current]</p> <p><b>Error return value(s):</b>  -501 if calibration factor is out of the 1-20 range  -502 if the calibration factor is not defined</p> <p><b>Example command:</b>  <code>getcalfactor 1</code></p> <p><b>Example return:</b>  <code>calfact1 500 50</code></p>
<p><code>getcurrent</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>getcurrent</code></p> <p><b>Shortcut:</b>  <code>gc</code> (support for this shortcut starting in 3.0.5.4)</p> <p><b>What it does:</b>  This command returns the sensor current in picoamps.</p> <p><b>Normal return value(s):</b>  Current in amps (firmware<math>\geq</math>2.1.0.0) or picoamps (firmware<math>&lt;</math>2.1.0.0)</p> <p><b>Error return value(s):</b>  -500 if there is a voltage saturation, indicating the reading must be discarded</p>

<p>getdarkmode</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getdarkmode</p> <p>What it does: This command returns the dark mode currently in use by the device. The dark mode can be NO DARK (there is no consideration for photodiode dark current), FACTORY DARK (the dark current set at the factory), or USER DARK (the dark current set with <code>setuserdark</code>).</p> <p>Return value(s): 0 = NO DARK 1 = FACTORY SET 2 = USER SET</p> <p>Error return value(s): N/A</p>
<p>getdatetime (Gen2, Gen3)</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getdatetime</p> <p>What it does: This command returns the real time clock's date and time in formats as shown below. This format includes a typical date and time format (mm/dd/yyyy hh:mm:ss), followed by the Epoch time (seconds since 1970). Note that the device is programmed to UTC/GMT time and, as a result, might return a time that does not match the local timezone. Modern computer programming languages will correctly convert the Epoch time data to local time when saving the timestamped log data. This is the case with the Data Logger software.</p> <p>Return value(s): Real time clock time as shown below</p> <p>Error return value(s): -500 Command not supported</p> <p>Example return: 12/05/2013 19:02:05 1386270125</p>
<p>getecal (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.5.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getecal</p> <p>What it does: This command returns the 19 ecal data points.</p> <p>Normal return value(s): The 19 ecal data points: [1pA val] [5pA val] [10pA val] [50pA val] [100pA val] [500pA val] [1nA val] [5nA val] [10nA val] [50nA val] [100nA val] [500nA val][1uA val] [5uA val] [10uA val] [50uA val] [100uA val] [500uA val] [1mA]</p> <p>Error return value(s): N/A</p>

<p>getecaldate (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.5.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getecaldate</p> <p><b>What it does:</b> This command returns the sensor last date electrical cal (ecal) was performed, in epoch time. If an ecal as never performed, this api returns 0.</p> <p><b>Normal return value(s):</b> 0 if ecal was never performed Date in epoch time if ecal was performed</p> <p><b>Example return:</b> 1428445793 (indicating April 7 2015 22:29:53 GMT)</p> <p><b>Error return value(s):</b> N/A</p>
<p>getfactorydark</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getfactorydark</p> <p><b>What it does:</b> This command returns the dark voltage at the various transimpedance amplifier gain stages, as set at the factory.</p> <p><b>Normal return value(s):</b> On Gen1 products: The dark voltage in microvolts, of the two voltage gain stages. On Gen2 products: The dark voltage in microvolts, of the three voltage gain stages for each of three feedback resistor stages On Gen3 products: The dark voltage in microvolts, of the three voltage gain stages for each of four feedback resistor stages</p> <p><b>Error return value(s):</b> -500 if the factory dark voltage has not been set</p> <p><b>Example return:</b> Gen1 : 12756 9234 Gen2 : R1 10360 9602 9535 R2 14115 13291 13215 R3 46680 45769 25190</p>
<p>getfeedbackresnumber</p> <p>Support Starting in Firmware Version: 3.0.5.8</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getfeedbackresnumber</p> <p><b>What it does:</b> This command returns the number, not the value, of the feedback resistor in use.</p> <p><b>Normal return value(s):</b> 1 for Gen1 devices (only 1 feedback resistor) 1 – 3 for Gen2 devices 1 – 4 for Gen3 devices</p> <p><b>Error return value(s):</b> N/A</p>

<p>getflash</p> <p>Support Starting in Firmware Version: 3.0.5.8</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getflash</p> <p><b>What it does:</b> This command returns the results of the captureflash command, including the following data:</p> <p>Peak: This is the peak light level sensed during the flash capture Average: This is the average light level sensed over the integration period Integration: This is the integration of the light level over the integration period Time Above 10 Percent of Peak: This is the time (in seconds) that the signal was above 10% of the peak value. This can be considered the duration of the pulse. Peak Percent of Range: This is the percentage of the input range (defined by the feedback resistor in use and the voltage sensitivity). A number above 95 would indicate a likely saturation of the signal.</p> <p>The data labels, equal signs, and actual results are all separated by a space, facilitating parsing with a String-&gt;Split(' ') command.</p> <p><b>Normal return value(s):</b> On Gen1 products: The dark voltage in microvolts, of the two voltage gain stages. On Gen2 products: The dark voltage in microvolts, of the three voltage gain stages for each of three feedback resistor stages On Gen3 products: The dark voltage in microvolts, of the three voltage gain stages for each of four feedback resistor stages</p> <p><b>Error return value(s):</b> The 'Peak' value is returned as -512 if the capture resulted in a timeout before the trigger was sensed. In the response below, the Peak = -5.120e+02 indicates this condition, making the remainder of the values are invalid.</p> <p>Peak = -5.120e+02 Average = 6.168e-06 Integral = 2.527e-07 Time-Above-10-Percent-of-Peak = 4.096e-02 Peak-Percent-of-Range = 0</p> <p><b>Example return:</b> Peak = 1.067e-03 Average = 1.301e-05 Integral = 1.041e-06 Time-Above-10-Percent-of-Peak = 7.031e-04 Peak-Percent-of-Range = 97</p>
<p>getfeedbackres</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getfeedbackres</p> <p><b>What it does:</b> This command returns the value of the feedback resistor, in kilo-Ohms x 10.</p> <p><b>Normal return value(s):</b> Transimpedance amplifier feedback resistance in kOhms x 10</p> <p><b>Error return value(s):</b> N/A</p> <p><b>Example return (for a 3K Ohm feedback resistor):</b> 30</p>

<p>getfriendlyname</p> <p>Support Starting in Firmware Version: 3.0.5.4</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     getfriendlyname</p> <p>What it does:     This command returns the device's "friendly name".</p> <p>Normal return value(s):     Device friendly name or "NOT-DEFINED" if the friendly name has not yet been saved</p> <p>Error return value(s):     N/A</p>
<p>getfwversion</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     getfwversion</p> <p>What it does:     This command returns the firmware version running on the device.</p> <p>Normal return value(s):     Device firmware version</p> <p>Error return value(s):     N/A</p> <p>Example return:     1.3.0.5</p>
<p>getgeneration</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     getgeneration</p> <p>What it does:     This command returns the generation of the device.</p> <p>Normal return value(s):     -999 for first generation products that did not have this command defined at time of release     1 for first generation products     2 for second generation products (programmable Rf x 3, realtime clock, ambient temp sensor)     3 for second generation products (programmable Rf x 4, realtime clock, ambient temp sensor, wireless)</p> <p>Error return value(s):     N/A</p> <p>Example return:     2</p>



<p>getinfo</p> <p>Support Starting in Firmware Version: 3.0.5.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getinfo</p> <p><b>What it does:</b> This command returns a list, and ever-growing list, of critical device parameters. The command is intended as a quick diagnostic and configuration check, but can be used with parsing software to capture and extract critical configuration information.</p> <p><b>Normal return value(s):</b> See command output for the particular firmware version.</p> <p><b>Error return value(s):</b> N/A</p> <p><b>Example return:</b>  <pre> Base Serial Number = 10002201407300019 Vendor Serial Number = ILT100000002 Model Name = ILT1000-V02 Friendly Name = Right Generation = 2 FW Version = 3.0.5.8 Dark mode (0=No,1=Factory,2=User) = 1 Rf Setting (0=Auto,1=Rf1,2=Rf2,3=Rf3,4=Rf4) = 0 Rf value R1 (kOhms) = 3 Rf value R2 (kOhms) = 1000 Rf value R3 (kOhms) = 10000 Rf value R4 (kOhms) = 10000000 Rf value in use (kOhms) = 3 eCal: Disabled eCal values = 1.000e+00 1.000e+00 1.000e+00 1.000e+00 1.000e+00 1.000e+00 1.000e +00 1.000e+00 1.000e+00 1.000e+00 1.000e+00 1.000e+00 1.000e+00 1.000e+00 1.000e +00 1.000e+00 1.000e+00 1.000e+00 1.000e+00 ADC Signal Processing: Disabled Sample time (ms) = 500 Auto Sample Time: Disabled 4-20mA mode (0=Auto/log, 1=min-max/linear, 2&gt;manual) = 0 getvx1 = 0.030337 getvx17 = 0.518344 getvagc3 = 3.300000 Active voltage gain stage = 2 TIA voltage = 0.020656 getcurrent = 6.885e-06 Factory dark = R1 10360 9602 9535 R2 14115 13291 13215 R3 46680 45769 25190 User dark = R1 9735 9607 9564 R2 22885 22746 22670 R3 125018 124804 25190 Logging: Disabled Wireless Listening: Disabled </pre> </p>
--	---

<p><code>getintegrate</code></p> <p>Support Starting in Firmware Version: 3.0.7.0</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>getintegrate</code></p> <p><b>What it does:</b>  This command returns the integrated light level that started with <code>startintegrate</code>. The integral is calculated as the average light level since the beginning of <code>startintegrate</code>, multiplied by the time in seconds (resolution of 10ms).</p> <p><b>Normal return value(s):</b>  Integrated light level (units depend on the calibration factor)</p> <p><b>Error return value(s):</b>  -502 if the light level is saturating the detector at the current gain range</p> <p><b>Example return (for an integrated light level value of 4.712 milli-units):</b>  <code>4.712e-3</code></p>
<p><code>getirradiance</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>getirradiance</code></p> <p><b>Shortcut:</b>  <code>gi</code> (support for this shortcut starting in 3.0.5.4)</p> <p><b>What it does:</b>  This command returns the irradiance value in user-defined units. The device determines irradiance based on the following priority list:</p> <ol style="list-style-type: none"> <li>1. If a calibration factor is in use (see <code>usecalfactor</code>), this current-to-irradiance multiplier value is used. This is the most common method to derive irradiance.</li> <li>2. If no calibration factor is in use, or the calibration factor has its multiplier value set to 65535 (0xFFFF), the custom calibration table set with either <code>setsimpleirrca</code> or multiple calls to <code>setirrdatapoint</code> is used. This mode is no longer supported in firmware version 3.0.5.3 and later.</li> </ol> <p><b>Normal return value(s):</b>  Irradiance value in user-defined units</p> <p><b>Error return value(s):</b>  -500 if no irradiance calibration data has been set  -501 if the detector current is out of range for the current-to-irradiance curve (case #2 above) . This value is no longer returned in FW 3.0.5.2 and later.  -502 if there is a voltage saturation, indicating the reading must be discarded</p> <p><b>Example return (for an irradiance value of 7.798 milli-units):</b>  <code>7.798e-3</code></p>

<code>getirrthresholdlow</code> Support Starting in Firmware Version: 2.0.1.0 Support Ending in Firmware Version: N/A	<p><b>Syntax:</b> <code>getirrthresholdlow</code></p> <p><b>What it does:</b> This command returns the irradiance value (or light level), below which data will not be logged. It is set with <code>setirrthresholdlow</code>.</p> <p><b>Normal return value(s):</b> Minimum irradiance value for data logging, returned in scientific notation. A value of zero (0) can indicate that either the threshold was never set (0 is the default), or it was set to zero.</p> <p><b>Example return (for an irradiance value of 73.798):</b> <code>1.25e-4</code></p>
---	---

getlogdata

Support Starting in Firmware  
Version: 2.0.0.3

Support Ending in Firmware  
Version: N/A

**Syntax:**

getlogdata

**What it does:**

This command returns the log data stored in flash memory. This command can be run during an active logging session (and datalogging will continue) or after a session is stopped with `stoplogdata` or, starting in version 3.0.5.8, after `captureflash` is used with the option to save data to flash. The command will first output three values (total number of values, an integer indicating what information was logged, the logging period, followed by lines of comma-delimited data with date-time-stamp (in seconds since 1970 or "Unix epoch time") followed by all recorded values for that date-time-stamp.

**Units for Logging Period:**

Firmware <= 2.0.0.4, with `getlogdata` used after `setlogdata` :  
Logging period in seconds

Firmware >= 2.0.0.5, with `getlogdata` used after `setlogdata`  
Logging period in 10ms increments, i.e. 1=10ms, 100=1s

Firmware >= 3.0.5.8, with `getlogdata` used after `captureflash`  
Logging period in microseconds, i.e. 10=10us, 1000=1ms

**Normal return value(s):**

Total number of Date-Time-Stamp + Value pairs logged

Recorded Value Indicator bitmask as follows:

1=Optical Density (x100 for firmware < 2.1.0.0)

2=Percent Transmission (x10 for firmware < 2.1.0.0)

4=Detector Current in amps (picoamps for firmware < 2.1.0.0)

8=Detector Voltage in volts (microvolts for firmware < 2.1.0.0)

16=Device temperature (degrees F)

32=Calibrated Irradiance (see `getirradiance`)

Logging Period (see above regarding units)

Seconds Since 1970, value #1, value #2, value #n

Seconds Since 1970, value #1, value #2, value #n

....

Seconds Since 1970, value #1, value #2, value #n

**Error return value(s):**

-500 if no log data present

**Notes on returned data values:**

- If the 100% is not set, both Optical Density and Percent Transmission will return 0.
- Log data does not support negative Optical Density values
- Calibrated Irradiance will return 0 if there is no calibration data

**Example return (Notes after the '-' are for documentation purposes and not returned):**

5	- total time-stamp + value pairs
4	- detector current
60	- period in seconds (sample every minute)
1378738200, 1.595e-9	- 09 Sep 2013 14:50:00 GMT, 1.595 nanoamps
1378738260, 1.346e-9	- 09 Sep 2013 14:51:00 GMT, 1.346 nanoamps
1378738320, 1.456e-9	- 09 Sep 2013 14:52:00 GMT, 1.456 nanoamps
1378738380, 1.748e-9	- 09 Sep 2013 14:53:00 GMT, 1.748 nanoamps
1378738440, 1.637e-9	- 09 Sep 2013 14:54:00 GMT, 1.637 nanoamps

<p>getmodelName</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     getmodelName</p> <p>What it does:     This command returns the model name of the device.</p> <p>Normal return value(s):     Device model name</p> <p>Error return value(s):     N/A</p>
<p>getod</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     getod</p> <p>Shortcut:     go (support for this shortcut starting in 3.0.9.4)</p> <p>What it does:     This command returns the optical density, multiplied by 100. Because optical density is a relative measurement, this command requires that the 100% (0.00 OD) setting is established with <code>set100perc</code>. The maximum optical density returned is based on the device generation as follows:</p> <p>    Gen1: 5.000     Gen2: 8.000     Gen3: 11.000</p> <p>Normal return value(s):     Optical density (firmware&gt;=2.1.0.0) or Optical Density x 100 (firmware&lt;2.1.0.0)</p> <p>Error return value(s):     -500 if the 100% value has not been previously set with <code>set100perc</code></p> <p>Example return (for an optical density of 1.070):     1.070</p>
<p>getpeak</p> <p>Support Starting in Firmware Version: 3.0.7.0</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     getpeak</p> <p>What it does:     This command returns the peak light level that started when <code>startpeak</code> was executed.</p> <p>Normal return value(s):     Peak light level (units depend on the calibration factor)</p> <p>Error return value(s):     -502 if the light level is saturating the detector at the current gain range</p> <p>Example return (for a peak light level value of 3.465e-4):     3.465e-4</p>

<p><code>getsampletime</code></p> <p>Support Starting in Firmware Version: 3.0.5.4</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>getsampletime</code></p> <p><b>What it does:</b>  This command returns the sample time in milliseconds (see <code>setsampletime</code>). Note that if the sample time is set for automatic (<code>setsampletime 0</code>) this command will return the actual sample in time currently in use.</p> <p><b>Normal return value(s):</b>  Sample time in milliseconds, ranging from 10 to 15000</p> <p><b>Error return value(s):</b>  N/A</p> <p><b>Example return:</b>  1000 – indicating 1000ms, or 1 second sample time</p>
<p><code>getserialnumber</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>getserialnumber</code></p> <p><b>What it does:</b>  This command returns the serial number of the device. The serial number is stored in one-time-programmable memory at the time of manufacture.</p> <p><b>Normal return value(s):</b>  Device serial number</p> <p><b>Error return value(s):</b>  -500 device serial number has not been set</p> <p><b>Example return:</b>  10054201208230245</p>
<p><code>gettemp</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>gettemp</code></p> <p><b>What it does:</b>  This command returns the internal temperature of the device microcontroller. Note that, while the detector temperature can be loosely inferred from this, this is not equivalent to the detector temperature. The return value is in degrees F, with any units conversion performed by the application software.</p> <p><b>Normal return value(s):</b>  Device microcontroller temperature, in degrees F</p> <p><b>Error return value(s):</b>  N/A</p> <p><b>Example return:</b>  107</p>

<p><code>gettrans</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>gettrans</code></p> <p><b>Shortcut:</b>  <code>gt</code> (support for this shortcut starting in 3.0.9.4)</p> <p><b>What it does:</b>  This command returns the percent transmission, multiplied by 10. Because percent transmission is a relative measurement, this command requires that the 100% (0.00 OD) setting is established with <code>set100perc</code>.</p> <p><b>Normal return value(s):</b>  Percent Transmission (firmware<math>\geq</math>2.1.0.0) or Percent Transmission x 10 (firmware<math>&lt;</math>2.1.0.0)</p> <p><b>Error return value(s):</b>  -500 if the 100% value has not been previously set with <code>set100perc</code></p> <p><b>Example return (for a percent transmission of 67.3):</b>  67.300</p>
<p><code>gettriggerin</code> (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.5.9</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>gettriggerin [trigger state] [time out seconds]</code></p> <p><b>What it does:</b>  This command is for testing of the trigger in line present in some Gen2 and Gen3 devices. The [trigger state] can be "high" (expecting a logic high or "1") or "low" (expecting a logic low or "0"). [time out seconds] is the time to wait for the trigger to appear.</p> <p><b>Normal return value(s):</b>  0 if trigger not sensed within the time out period  1 if trigger sensed within the time out period</p> <p><b>Error return value(s):</b>  -500 if missing arguments  -501 if trigger state is no "low" or "high"  -502 if time out period is less than 0 seconds or greater than 300 seconds (5 minutes)</p>

<p>getuserdark</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getuserdark</p> <p><b>What it does:</b> This command returns the dark voltage at the various transimpedance amplifier gain stages, as set by the user with <code>setuserdark</code>.</p> <p><b>Normal return value(s):</b> On Gen1 products: The dark voltage in microvolts, of the two voltage gain stages. On Gen2 products: The dark voltage in microvolts, of the three voltage gain stages for each of three feedback resistor stages On Gen3 products: The dark voltage in microvolts, of the three voltage gain stages for each of four feedback resistor stages</p> <p><b>Error return value(s):</b> -500 if the user dark voltage has not been set</p> <p><b>Example return:</b> Gen1: 13014 9832 Gen2: R1 9735 9607 9564 R2 22885 22746 22670 R3 125018 124804 25190</p>
<p>getvoltage</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getvoltage</p> <p><b>Shortcut:</b> gv (support for this shortcut starting in 3.0.5.4)</p> <p><b>What it does:</b> This command returns the voltage output of the transimpedance amplifier, after it is passed through the automatic-gain-control circuit.</p> <p><b>Normal return value(s):</b> Detector voltage, in volts (firmware &gt;= 2.1.0.0) or microvolts (firmware &lt; 2.1.0.0)</p> <p><b>Error return value(s):</b> N/A</p> <p><b>Example return (for 2.415896 volts):</b> 2.415896</p>
<p>getvoltagestage</p> <p>Support Starting in Firmware Version: 3.0.5.8</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> getvoltagestage</p> <p><b>What it does:</b> This command returns the voltage sensitivity stage in use by the device.</p> <p><b>Normal return value(s):</b> 1 - 3</p> <p><b>Error return value(s):</b> N/A</p>



<p>getvped</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getvped</p> <p>What it does: This command returns the “pedestal” voltage for the transimpedance amplifier at the x1 automatic-gain-control stage. This can be used as a diagnostic to verify this important voltage, which should be between roughly 10 and 15 millivolts for Gen1 and Gen2 products.</p> <p>Normal return value(s): “Pedestal” voltage in volts (firmware &gt;= 2.1.0.0) or microvolts (firmware&lt;2.1.0.0)</p> <p>Error return value(s): N/A</p> <p>Example return (11.087 mV): 0.011087</p>
<p>getvref</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: getvref</p> <p>What it does: This command returns the reference voltage for the device’s A/D converter. This command can be used as a diagnostic if there is ever a suspicion that the voltage reference is faulty. This is should be close to, but not typically exactly, 3.3V.</p> <p>Normal return value(s): Device A/D converter reference voltage, in volts (firmware &gt;= 2.1.0.0) or microvolts (firmware&lt;2.1.0.0)</p> <p>Error return value(s): N/A</p> <p>Example return: 3.291489</p>
<p>help</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: help</p> <p>What it does: This command list the most common commands, along with their expected return value.</p> <p>Normal return value(s): List of common commands and return values.</p> <p>Error return value(s): N/A</p>

<p>set0vbias (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.5.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     set0vbias</p> <p>What it does:     This command sets the bias, on the photodiode anode, to zero volts (unbiased).</p> <p>Normal return value(s):     0 on success</p> <p>Error return value(s):      -500 if not supported, i.e. on Gen1 or Gen2 devices</p> <p>Persist through power-cycle:     No</p>
<p>set100perc</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     set100perc</p> <p>What it does:     Prior to 3.0.5.3, this command read the detectors voltage level (and by inference its current and irradiance level) and sets this as the 100% value to use in Optical Density and %Transmission calculations.</p> <p>    Starting in 3.0.5.3, this command reads the detector current level and sets this as the 100% value to use in Optical Density and %Transmission calculations.</p> <p>Normal return value(s):     Prior to 3.0.5.3: The 100% voltage value, in volts (firmware &gt;= 2.1.0.0) or microvolts (firmware&lt;2.1.0.0)</p> <p>    Starting in 3.0.5.3: The 100% current value, in amperes.</p> <p>Error return value(s):      Prior to 3.0.5.3:      1 if the value is too low to use as a 100% reference voltage, currently set at &lt; 0.020 V     2 if the value is too high to use as a 100% reference voltage, currently set at &gt; 3.200 V</p> <p>    Starting in 3.0.8.9: Return value of -500 if gain stage saturated</p> <p>Persist through power-cycle:     No</p> <p>Example return (1.421e-5... current 100% or "full scale"):     1.421e-5</p>

<p>set5vbias (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.5.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     set5vbias</p> <p>What it does:     This command sets the bias, on the photodiode anode, to -5V volts (negatively biased).</p> <p>Normal return value(s):     0 on success</p> <p>Error return value(s):      -500 if not supported, i.e. on Gen1 or Gen2 devices</p> <p>Persist through power-cycle:     No</p>
<p>setambientlevel</p> <p>Support Starting in Firmware Version: 3.0.5.8</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:     setambientlevel</p> <p>What it does:     This command sets the existing current and light-level reading as zero, effectively eliminating ambient light/power levels from subsequent readings.</p> <p>Normal return value(s):     0 on success</p> <p>Error return value(s):     N/A</p> <p>Persist through power-cycle:     No</p>

<p>setautaveraging</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> setautaveraging</p> <p><b>What it does:</b> This command sets the amount of averaging performed by the device to be set automatically based on the transimpedance amplifier voltage as follows:</p> <p>For firmware levels &lt; 2.0.0.0 Voltage &gt; 30mv, averaging equivalent of setlowaveraging 3mv &lt; Voltage &lt; 30mv, averaging equivalent to setmedaveraging Voltage &lt; 3mv, averaging equivalent to sethiaveraging</p> <p>For firmware levels &gt; 2.0.0.0 Current &gt; 10uA, averaging equivalent of setlowaveraging (0.5 sec) 0.32uA &lt; Current &lt; 10uA, averaging equivalent to setmedaveraging (1.0 sec) Current &lt; 0.32uA, averaging equivalent to sethiaveraging (2.0 sec)</p> <p>This is the default setting for averaging upon power-up.</p> <p><b>Normal return value(s):</b> 0 on success</p> <p><b>Error return value(s):</b> N/A</p> <p><b>Persist through power-cycle:</b> No for firmware &lt; 3.0.5.3 Yes for firmware &gt;= 3.0.5.3</p>
--	--

<p>setcalfactor</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b> <code>setcalfactor [calibration factor, 1-20] [desc.] [sensitivity factor] [saturation current uA]</code></p> <p><b>What it does:</b> This command defines the particular calibration factor details. Details include the calibration factor description (up to 100 characters), the sensitivity factor (Light Level = Detector Current / Sensitivity Factor), and saturation current in microamps.</p> <p>For firmware levels &lt; 2.0.0.8: <code>setcalfactor [calibration factor, 1-20] [desc.] [multiplierx1000] [saturation current uA]</code>, where Light Level = Detector Current * multiplier If the multiplier value is 0xFFFF (65535) the calibration table as established by <code>setirrdatapoint</code> will be used to convert detector current to irradiance.</p> <p><b>Normal return value(s):</b> 0 on success</p> <p><b>Error return value(s):</b> -500 if missing fields -501 if calibration factor is out of the 1-20 range -502 if multiplier &lt; 0 -503 error saving to flash</p> <p><b>Persist through power-cycle:</b> Yes</p> <p><b>Example command ("calfact1" description, 1.3e-7 sensitivity factor, 500 uA saturation current):</b> <code>setcalfactor 1 calfact1 1.3e-7 500</code></p>
---	--

<p>setcurrentloop (Gen2, Gen3)</p> <p>Support Starting in Firmware Version: 2.0.0.5</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b></p> <pre>setcurrentloop log setcurrentloop midpoint setcurrentloop [min picoamps] [max picoamps] setcurrentloop [0-24]</pre> <p><b>What it does:</b> This command controls the 4-20mA current loop output of devices that support such a current loop.</p> <p><code>setcurrentloop log</code> sets the device to output a logarithmic scale current that is in relation to the current sensed by the detector. The transfer function is:</p> <p><b>Gen2:</b>  <math>4\text{-}20\text{mA current} = (\text{LOG}_{10}(\text{detector current})+8)*3+5</math>  <math>\text{Detector Current} = 10^{((4\text{-}20\text{mA Current})-5)/3-8}</math></p> <p><b>Gen3:</b>  <math>4\text{-}20\text{mA current} = (\text{LOG}_{10}(\text{detector current})+11)*1+5</math>  <math>\text{Detector Current} = 10^{((4\text{-}20\text{mA Current})-5)/1-11}</math></p> <p>If the detector current is below 10 nA (Gen2) or 1pA (Gen3), the 4-20mA current is set to 4mA. As a result, measurements fluctuating around 10nA (Gen2) or 1pA (Gen3) will result in the 4-20mA output bouncing between 4mA and 5mA. If a calibration factor is set, the 4-20mA output will have a similar relationship to irradiance, but multiplied by the calibration factor.</p> <p><code>setcurrentloop midpoint</code> sets the device to output a linear scale where:</p> <p>4mA = 0 detector current  12mA = the detector current when this command was set  20mA = double the detector current when this command was set</p> <p><code>setcurrentloop [min picoamps] [max picoamps]</code> sets the device to output a linear scale where:</p> <p>4mA = min picoamps  20mA = max picoamps</p> <p><code>setcurrentloop [0-24]</code> sets the device to manually output the current indicated, in milliamps.</p> <p><b>Normal return value(s):</b> 0 on success</p> <p><b>Error return value(s):</b>  -500 if command not supported, i.e. on Gen1 devices  -501 if missing fields  -502 if there is a bad current loop value (applies to setcurrentloop [0-24])</p> <p><b>Persist through power-cycle:</b>  Yes for <code>setcurrentloop log</code>, <code>setcurrentloop midpoint</code>, and <code>setcurrentloop [min picoamps] [max picoamps]</code>.</p> <p>No for <code>setcurrentloop [0-24]</code>, which is intended as more of a test function.</p>
--	--

<p>setdatetime (Gen2, Gen3)</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <pre>setdatetime 12/05/2013 19:02:05</pre></p> <p><b>What it does:</b>  This command sets the real time clock's date and time. It accepts either of the following formats:  <pre>mm/dd/yyyy hh:mm:ss</pre>  <pre>mm/dd/yy hh:mm:ss</pre></p> <p>The device is designed such that this date/time setting is UTC/GMT time. The device stores all date/timestamps in Epoch time format, which is later read out and converted to local time by an application. This is the case with the Data Logger software.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b></p> <ul style="list-style-type: none"> <li>-500 if command not supported</li> <li>-501 if missing fields</li> <li>-502 if parameters are out of range</li> </ul> <p><b>Persist through power-cycle:</b>  Yes, assuming coin/cell battery is in place with adequate charge</p>
<p>setfriendlyname</p> <p>Support Starting in Firmware Version: 3.0.5.4</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <pre>setfriendlyname [friendly name, up to 30 characters]</pre></p> <p><b>What it does:</b>  This command sets the "friendly name" of the device. The friendly name is used by applications to help users easily identify which device is in use.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b></p> <ul style="list-style-type: none"> <li>-500 if missing fields</li> <li>-501 if error storing value</li> </ul> <p><b>Persist through power-cycle:</b>  Yes</p>

<p><code>sethiaveraging</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>sethiaveraging</code></p> <p><b>What it does:</b>  This command sets the averaging to be performed by the device to high, resulting in approximately 1 sample every 2 seconds. This mode provides the highest amount of over-sampling, or noise reduction. This mode is typically used for either detecting very low light levels or for monitoring noisy light sources.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  N/A</p> <p><b>Persist through power-cycle:</b>  No</p>
<p><code>setirrdatapoint</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: 3.0.5.4</p>	<p><b>Syntax:</b>  <code>setirrdatapoint [detector current nA] [irradiance x1000]</code></p> <p><b>What it does:</b>  This command sets a value pair for a custom detector current-to-irradiance function. Anywhere from 3 to 100 data points can be set with multiple calls to <code>setirrdatapoint</code>. The device will perform a linear interpolation between data points as needed. This current-to-irradiance function can be used on its own or in conjunction with <code>setcalfactor</code>.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  -500 if missing fields  -501 if the maximum data points have already been loaded  -502 if a duplicate detector current value already exists in the table</p> <p><b>Persist through power-cycle:</b>  No. See <code>storeirrdata</code> to persist between power cycling.</p> <p><b>Example command (add a data point for 134 uA = 12.345 irradiance units):</b>  <code>setirrdatapoint 134000 12345</code></p>



<p>setirrthresholdlow</p> <p>Support Starting in Firmware Version: 2.0.1.0</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <code>setirrthresholdlow [calibrated reading]</code></p> <p>What it does:  This command sets the minimum irradiance value (calibrated reading) to use in conjunction with data logging. When set, and irradiance is being monitored with data logging, data will not be recorded unless the irradiance level meets this threshold.</p> <p>Normal return value(s):  0 on success</p> <p>Error return value(s):  -500 if missing fields  -501 if parameters are out of range:  Less than 0 or greater than 1 for firmware 2.0.1.0 -&gt; 3.0.5.8  Less than 0 or greater than 1000 for firmware &gt;= 3.0.5.9  -502 if error saving to flash memory</p> <p>Persist through power-cycle:  Yes</p>
<p>setlowaveraging</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <code>setlowaveraging</code></p> <p>What it does:  This command sets the averaging to be performed by the device to low, resulting in approximately 5 samples per second.</p> <p>Normal return value(s):  0 on success</p> <p>Error return value(s):  N/A</p> <p>Persist through power-cycle:  No for firmware &lt; 3.0.5.3  Yes for firmware &gt;= 3.0.5.3</p>
<p>setmedaveraging</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <code>setmedaveraging</code></p> <p>What it does:  This command sets the averaging to be performed by the device to medium, resulting in approximately 2 samples per second.</p> <p>Normal return value(s):  0 on success</p> <p>Error return value(s):  N/A</p> <p>Persist through power-cycle:  No for firmware &lt; 3.0.5.3  Yes for firmware &gt;= 3.0.5.3</p>

<p>setsamplecount</p> <p>Support Starting in Firmware Version: 2.0.0.6</p> <p>Support Ending in Firmware Version: 3.0.5.3</p>	<p><b>Syntax:</b>     setsamplecount [1 – 200]</p> <p><b>What it does:</b>     This command sets the number of samples taken by the Analog-to-Digital converter when reading the voltage from the transimpedance amplifier. This is the immediate averaging done on the input signal, before additional averaging is done by the <code>set*averaging</code> commands. Typically a value of 200 is used (the default) for standard operation, or a value of 1 is used for high-speed sampling (up to 100 samples/sec). <b>WARNING:</b> modifying this value will impact the communication between the meter and any device talking to it over the USB port. Talk to the manufacturer for details.</p> <p><b>Normal return value(s):</b>     0 on success</p> <p><b>Error return value(s):</b>     -500 if missing fields     -501 if value is out of range</p> <p><b>Persist through power-cycle:</b>     Yes</p> <p><b>Example command (for sampling at 100/sec):</b>     setsamplecount 1</p> <p><b>Example command (for default sampling rate):</b>     setsamplecount 200</p>
---	--

<p><code>setsampletime</code></p> <p>Support Starting in Firmware Version: 3.0.5.4</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b></p> <pre>setsampletime 0</pre> <pre>setsampletime [10 - 15000]</pre> <p><b>What it does:</b> This command sets the sample time used by the Analog-to-Digital converter when reading the voltage from the transimpedance amplifier in milliseconds. <code>setsampletime 0</code> sets the sample time to automatic, resulting in 500ms for high level signals and up to 2 seconds for lower signals.</p> <p>For typical monitoring applications, sample time is rarely set below 250ms and typically at 500ms or 1000ms (1s). For high-speed sampling in conjunction with data logging (see <code>startdatalog</code>), sample times as low as 10ms can be used.</p> <p><b>Normal return value(s):</b> 0 on success</p> <p><b>Error return value(s):</b> -500 if missing fields -501 if value is out of range</p> <p><b>Persist through power-cycle:</b> Yes</p> <p><b>Example command (for auto sample time):</b> <code>setsampletime 0</code></p> <p><b>Example command (for 50ms sample time):</b> <code>setsamplecount 50</code></p>
<p><code>setsamplimetemp</code></p> <p>Support Starting in Firmware Version: 3.0.6.7</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b></p> <pre>setsamplimetemp 0</pre> <pre>setsamplimetemp [10 - 15000]</pre> <p><b>What it does:</b> This command performs the same function as <code>setsampletime</code>, but does not persist the setting through power cycles. Because the setting does not need to be saved to flash, along with being temporary, it also executes faster.</p>

<p>settriggerout (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.5.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <pre>settriggerout on settriggerout off</pre> </p> <p>What it does:  This command sets the output trigger line to either a logic 1 (“on”) or a logic 0 (“off”). This command is used for testing purposes, with the trigger out circuit being exercised as part of the captureflash command.</p> <p>Normal return value(s):  0 on success</p> <p>Error return value(s):  -500 if missing fields  -501 if bad arguments</p> <p>Persist through power-cycle:  No</p>
<p>setuserdark</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <pre>setuserdark</pre> </p> <p>What it does:  This command captures the detector voltage signal, at all automatic-gain-control stages, and stores the values in device flash memory. When used in conjunction with <code>useuserdark</code>, all subsequent readings will have this value removed automatically. Starting in firmware version 2.0.0.5, if the mode is already set to <code>useuserdark</code> then the new values will automatically be applied.</p> <p>Normal return value(s):  User dark value, in microvolts, for all gain stages (separated by a space)</p> <p>Error return value(s):  -500 if error saving setting to flash memory</p> <p>Persist through power-cycle:  Yes</p> <p>Example return:  Gen1:  13014 9832  Gen2:  R1 9735 9607 9564 R2 22885 22746 22670 R3 125018 124804 25190</p>
<p>setwireless (Gen3)</p> <p>Support Starting in Firmware Version: 3.0.6.1</p> <p>Support Ending in Firmware Version: N/A</p>	<pre>setwireless on setwireless off</pre> <p>What it does:  This command enables or disables the wireless functionality. When disabling the functionality, the system will immediately shut down the wireless part. When enabling the wireless functionality the system requires a power cycle to restore the wireless operation.</p> <p>Normal return value(s):</p>

	<p>0 on success</p> <p>Error return value(s):  -500 if missing arguments  -501 if not supported based on the device generation  -502 if bad syntax/arguments</p> <p>Persist through power-cycle:  Yes</p>
<p><code>startintegrate</code></p> <p>Support Starting in Firmware  Version: 3.0.7.0</p> <p>Support Ending in Firmware  Version: N/A</p>	<p>Syntax:  <code>startintegrate</code></p> <p>What it does:  This command starts integrating the light level at high-speed to capture fast pulses. The integrated light-level is returned with <code>getintegrate</code> and the integration is halted with <code>stopintegrate</code>. Note that <code>startintegrate</code> always resets the integrated value to 0.</p> <p>Normal return value(s):  0 on success</p> <p>Error return value(s):  None</p>

<p>startlogdata</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  startlogdata [variable bitmask] [logging period – see below] [seconds since 1970]</p> <p><b>What it does:</b>  This command defines the logging parameters, and immediately starts logging. This command cannot be run when either a logging session is already active, a session has been stopped (with stoplogdata) but the log data has not yet been erased with eraselogdata, or a captureflash session has completed with saved data that has not yet been erased with eraselogdata. The command takes three parameters, with a space between parameters, as follows:</p> <p>[variable bit mask]</p> <ul style="list-style-type: none"> <li>1=Optical Density (x100)</li> <li>2=Percent Transmission (x10)</li> <li>4=Detector Current (picoamps)</li> <li>8=Detector Voltage (microvolts)</li> <li>16=Device temperature (degrees F)</li> <li>32=Calibrated Irradiance (see getirradiance, setirrthresholdlow)</li> <li>128=Use Real Time Timestamps (as opposed to relative time stamps, Gen2 only)</li> </ul> <p><i>For firmware versions 2.0.0.1 and earlier:</i>  [logging period] = desired logging period, in seconds, divided by 10  A 1, for example, would indicate a 10 second delay between logging; a value of 360 would indicate a 3600 second delay, or 1 hour, between log entries. The maximum value is 8640, which is equivalent to 86400 seconds or 1 day. Any values above this will results in a 1 day logging period.</p> <p><i>For firmware versions 2.0.0.2 and later</i>  [logging period] = desired logging period in seconds  A 1, for example, would indicate a 1 second delay between logging; a value of 3600 would indicate a 3600 second delay, or 1 hour, between log entries. The maximum value is 86400, which is equivalent to 86400 seconds or 1 day. Any values above this will results in a 1 day logging period.</p> <p><i>For firmware versions 2.0.1.0 and later</i>  [logging period] = desired logging period, in 10 milliseconds increments.  A 1, for example, would indicate a 10 millisecond delay between logging, or 100Hz logging. A value of 6000 would indicate a 1 minute delay. The maximum value is 8640000, which is equivalent to 86400 seconds or 1 day. Any values above this will results in a 1 day logging period. A value of 0 will default to a 10ms delay. NOTE: there is a known bug that limits the maximum log period to 14.4 minutes. See your product representative for information on an update to resolve this issue if needed.</p> <p>[seconds since 1970]  This is “Unix epoch time”, with most application coding environments having a mechanism to convert a date-time structure to epoch time. This is ignored, and should be set to 0, when using real-time timestamps.</p> <p><b>Normal return value(s):</b>  0 on success</p>
---	--

<p>startlogdata (cont)</p>	<p>Error return value(s):</p> <ul style="list-style-type: none"> <li>-500 missing parameters</li> <li>-501 session already started. Must use stoplogdata and eraselogdata to start new.</li> <li>-502 errors with the variable bit mask</li> </ul> <p>Persist through power-cycle:</p> <p>Yes.</p> <p>Common usage is to use startlogdata, disconnect the device from the computer, connect the device to a battery or AC-power in the lab or field, and the device will continue logging on power up using time-stamps that are relative to the start time. In this scenario care must be taken to ensure any power down time is negligible to the desired time-stamp accuracy. Gen2 devices have the option of using a battery-back real-time clock (see 128 bitmask value above).</p> <p>Example command (to log detector current and device temperature, every 10ms (Firmware 2.0.1.0), starting at 09 Sep 2013 14:50:00 GMT. Note bitmask of 20 is 4/current + 16/temperature):</p> <pre>startlogdata 20 1 1378738200</pre> <p>Example command. Same as above, but sampling every minute (60 seconds is 6000 10ms increments) and adding 128 to the bit mask for use of a real time clock on a Gen2 device):</p> <pre>startlogdata 148 6000 0</pre>
<p>startpeak</p> <p>Support Starting in Firmware Version: 3.0.7.0</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:</p> <pre>startpeak</pre> <p>What it does:</p> <p>This command starts peak detection of the light level at high-speed to capture fast pulses of light. The peak light level is returned with getpeak and the peak detection is halted with stoppeak. Note that startpeak always resets the peak value to 0.</p> <p>Normal return value(s):</p> <p>0 on success</p> <p>Error return value(s):</p> <p>None</p>
<p>stopintegrate</p> <p>Support Starting in Firmware Version: 3.0.7.0</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:</p> <pre>stopintegrate</pre> <p>What it does:</p> <p>This command stops the integration started with startintegrate. See also getintegrate.</p> <p>Normal return value(s):</p> <p>0 on success</p> <p>Error return value(s):</p> <p>-500 if light level integration has not been started with startintegrate</p>

<p><code>stoplogdata</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>stoplogdata</code></p> <p><b>What it does:</b>  This command stops a log session that was started with <code>startlogdata</code>. Note that, because date-time-stamping is relative to the start time set with <code>startlogdata</code>, logging cannot be restarted after a <code>stoplogdata</code>. Instead, log data must first be erased using <code>eraselogdata</code>.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  -500 if no active logging session to stop</p>
<p><code>stoppeak</code></p> <p>Support Starting in Firmware Version: 3.0.7.0</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <code>stoppeak</code></p> <p><b>What it does:</b>  This command stops the peak detection started with <code>startpeak</code>. See also <code>getpeak</code>.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  -500 if peak tracking has not been started with <code>startpeak</code></p>
<p><code>storeirrdata</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: 3.0.5.3</p>	<p><b>Syntax:</b>  <code>storeirrdata</code></p> <p><b>What it does:</b>  This command stores the custom detector current to irradiance data table, as established with multiple calls to <code>setirrdatapoint</code>, in flash memory.</p> <p><b>Normal return value(s):</b>  0 on success</p> <p><b>Error return value(s):</b>  -500 if no data to store</p> <p><b>Persist through power-cycle:</b>  Yes</p>



<p><code>usecalfactor</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <code>usecalfactor [calibration number, 0-20]</code></p> <p>What it does:  This command selects a particular calibration factor (see <code>setcalfactor</code>), which in turn will define the detector current-to-irradiance multiplier as well as the detector saturation current. A calibration number of 0 is a special case. Using 0 results in no longer using any calibration factors. When this is done, <code>getirradiance</code> will only return a value if <code>setsimpleirrcal</code> or <code>setirrdatapoint</code> has been used.</p> <p>Normal return value(s):  0 on success</p> <p>Error return value(s):  -500 if missing fields  -501 if factor number is outside the 0-20 range  -502 if factor not defined  -503 if error saving to flash</p> <p>Persist through power-cycle:  Yes (firmware Version 2.0.0.0 and later), No otherwise</p> <p>Example command:  <code>usecalfactor 5</code></p>
<p><code>usecalfactortemp</code></p> <p>Support Starting in Firmware Version: 3.0.6.7</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <code>usecalfactortemp [calibration number, 0-20]</code></p> <p>What it does:  This command performs the same function as <code>usecalfactor</code>, but does not persist the setting through power cycles. Because the setting does not need to be saved to flash, along with being temporary, it also executes faster.</p>
<p><code>usefactorydark</code></p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax:  <code>usefactorydark</code></p> <p>What it does:  This command will cause all subsequent readings to remove the factory dark value before presenting any voltage, current, etc. readings. This is the default dark setting upon power up.</p> <p>Normal return value(s):  0 on success</p> <p>Error return value(s):  -500 if there has been no factory dark value set</p> <p>Persist through power-cycle:  No</p>

<p>usefeedbackres (Gen2, Gen3)</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <pre>usefeedbackres [resistor selection 0-4] usefeedbackres</pre></p> <p><b>What it does:</b>  For Gen2 devices, which have 3 available feedback resistors, this command selects the resistor to be used as follows:</p> <p>0: have the device automatically select a resistor based on light-level  1: use feedback resistor #1, usually the lowest value resistor  2: use feedback resistor #2  3: use feedback resistor #3  4: use feedback resistor #4 (Gen3 only)</p> <p>Starting in 3.0.5.4, issuing usefeedbackres without parameters returns the value of the feedback resistor in use [0=feedback resistor 1, 1=feedback resistor 2, etc.]</p> <p>Starting in 3.0.6.7, issuing usefeedbackres without parameters returns the value of usefeedbackres setting [0=auto, 1=fixed to feedback resistor 1, 2=fixed to feedback resistor 2, etc.].</p> <p><b>Normal return value(s):</b>  0 on success (for the first syntax above)  0-4, depending on the feedback resistor directive (for the second syntax above)</p> <p><b>Error return value(s):</b>  -500 if missing parameters (pre 3.0.5.4)  -501 if the device does not support multiple feedback resistors  -502 if the resistor selection value out of range  -503 resistor selected, but error saving the change to flash memory</p> <p><b>Persist through power-cycle:</b>  Yes</p>
<p>usefeedbackrestemp</p> <p>Support Starting in Firmware Version: 3.0.6.7</p> <p>Support Ending in Firmware Version: N/A</p>	<p><b>Syntax:</b>  <pre>usefeedbackrestemp [resistor selection 0-4] usefeedbackrestemp</pre></p> <p><b>What it does:</b>  This command performs the same function as usefeedbackres, but does not persist the setting through power cycles. Because the setting does not need to be saved to flash, along with being temporary, it also executes faster.</p>

<p>usenodark</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: usenodark</p> <p>What it does: This command will eliminate any dark current consideration.</p> <p>Normal return value(s): 0 on success</p> <p>Error return value(s): N/A</p> <p>Persist through power-cycle: No</p>
<p>useuserdark</p> <p>Support Starting in Firmware Version: 2.0.0.3</p> <p>Support Ending in Firmware Version: N/A</p>	<p>Syntax: useuserdark</p> <p>What it does: This command will cause all subsequent readings to remove the user dark value (see <code>setuserdark</code>) before presenting any voltage, current, etc. readings.</p> <p>Normal return value(s): 0 on success</p> <p>Error return value(s): -500 if there has been no user dark value set</p> <p>Persist through power-cycle: No</p>

## OEM Only

<p>setwflisten</p> <p>Support Starting in Firmware Version: 3.0.5.3</p> <p>Support Ending in Firmware Version: N/A</p>	<pre>setwflisten on setwflisten off setwflisten tempon setwflisten tempoff</pre> <p>What it does: This command disables any listening for commands on the secondary serial port. This is the port that the wireless (WiFly) part uses, but may be used by other devices in the future, including 3<sup>rd</sup>-party connection to the device.</p> <p>Normal return value(s): 0 on success</p> <p>Error return value(s): -500 if missing arguments -502 if bad syntax/arguments</p> <p>Persist through power-cycle: Yes for on/off parameters No for tempon/tempoff parameters</p>
--	---