




Change the way you think about time

maru

INSTRUCTION MANUAL




1. How to read the time

- This watch uses an “always on” LCD display to show the time.


I. Regular mode

- The time is displayed in a similar way to an analog clock
- Hours are shown by the marker that points to the inside of the display. Minutes are shown by the marker that points to the outside of the display.

Example 08:00



Example 03:35



2. Operating the basic functions


I. Turning on the backlight

- You can illuminate the display for a short time with the EL backlight by pressing button A.
- This function only works in a very dark environment.

II. How to read the date

- Press button B to display the date. The date icon indicates that you are in date mode.
- The month is shown by the marker that points to the inside of the display, the day is shown by the marker that points to the outside of the display.

Example: May 19th




- The display will change back to time mode after a short time.


III. How to check the alarm time

- Press button B twice to display the alarm time.
- The alarm mode icon indicates that you are in alarm mode.
- The alarm on icon indicates that the alarm is on.
- The display will change back to time mode after a short time.

Example: 6:20 am
Alarm On



Example: 8:15 pm
alarm off



3. How to set the time and animation

- Press and hold button A for 3 seconds to enter setting mode.


Note: after 7 seconds of inactivity setting mode will deactivate.

I. Setting the hour

- The time icon and hour marker will flash when you are in hour setting mode.
- The AM/PM icon in setting mode indicates that you are setting the time in AM or PM.
- Press button B to increase the hour as required.
- Hold button B to increase the hours more quickly.

Example: 12:05 PM

Hour Setting




- Press button A to confirm and move to the minutes.

Note: after 7 seconds of inactivity setting mode will deactivate.

II. Setting the minutes

- The time icon and the minute marker will flash when you are in minute setting mode.
- Press button B to increase the minutes as required.
- Hold button B to increase the minutes more quickly.

Example: 12:09 PM
Minute Setting




- Press button A to confirm and move to the animation.
Note: after 7 seconds of inactivity setting mode will deactivate.

V. Setting the animation

- This watch has an animation feature. When set, the display will animate every 5 minutes.

Example: segments will animate



- Press button B to turn the animation on or off.
 - In setting mode, when the animation is on, the display will animate. When the animation is off, the display will flash.
 - Press button A to confirm and exit setting mode.
- Note: after 7 seconds of inactivity setting mode will deactivate.

4. How to set the date

- Press button B to display the date.
- Press and hold button A for 3 seconds to enter date setting mode.


Note: after 7 seconds of inactivity setting mode will deactivate.

I. Setting the month

- The date icon and the month marker will flash when you are in month setting mode.
- Press button B to increase the month as required.
- Hold button B to increase the month more quickly.

Example: October 25th
Month Setting

Month (October)
flashing
Date icon
flashing
Day (25th)



Button A

Button B


- Press button A to confirm and move to date.

Note: after 7 seconds of inactivity setting mode will deactivate.

II. Setting the date

- The date icon and the date marker will flash when you are in date setting mode.
- Press button B to increase the date as required.
- Hold button B to increase the date more quickly.

Example : October 26th
Day Setting



- Press button A to confirm and exit setting mode.
Note: after 7 seconds of inactivity setting mode will deactivate.

5. How to set the alarm time

- Press button **B** twice to display the alarm time.

Note: after 7 seconds of inactivity setting mode will deactivate.

I. Turning the alarm on or off

- Press button **A** to turn the alarm on or off. The alarm icon indicates that the alarm is on.


Example 1: Alarm On

7:45 am

Alarm On/Off Setting

45 minutes

7 hours
AM



Alarm On
icon

Alarm icon

- Hold button **A** for 3 seconds to enter alarm setting mode.

Note: after 7 seconds of inactivity setting mode will deactivate.

II. Setting the alarm hour

- The alarm icon and the hour marker will flash.
- The AM / PM icon in setting mode indicates that you are setting the alarm time in AM or PM.

- Press button B to increase the hour as required.
- Hold button B to increase the hours more quickly.

Example 2: Alarm off

8:45 am


Hours Setting

45 minutes

8 hours

flashing

AM



Alarm icon
flashing

- Press button A to confirm and move to alarm minutes.
Note: after 7 seconds of inactivity setting mode will deactivate.

III. Setting the alarm minutes

- The alarm icon and the minute marker will flash.
- Press button B to increase the minutes as required.
- Hold button B to increase the minutes more quickly.


Example 2: alarm off

8:00 am

minutes setting

8 hours

AM



00 minutes
flashing

Alarm icon

- Press button A to confirm and exit setting mode.
Note: after 7 seconds of inactivity setting mode will deactivate.

8. User information

I. Battery

- This watch uses a CR2025 replaceable watch battery.
- Battery lifetime will vary depending on use, but is estimated to last for at least one year.
- To maximize battery life you should limit use of the EL backlight.

II. Warranty

- This watch is covered by a 1 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

III. Caution

- This watch has limited water resistance. Please do not use the watch in the shower, for swimming or for other water related activities.

SPECIFICATIONS

Case Materials	Wood
Strap Materials	Wood
Case Dimensions	41 x 52 x 13 mm
Finish	Clear coating
Maximum Fit Wrist Size	213 mm (approx.)
Weight	60g
Display	LCD with EL backlight
Battery	CR2025

