



Change the way you think about time


# QUASAR

## INSTRUCTION MANUAL




# 1. How to read the time

- Quasar has 3 display modes [Number], [Pattern] & [Animation]
- You may also choose to display the time in [12hr] or [24hr] modes.
- See section 5 “How to set the time” to change your preference.
- You can illuminate the display for a short time with the EL backlight by pressing button A. This function works best at night time.



- The 3rd display mode [Animation] causes the display to transition between [Number] & [Pattern] as shown above.

## 2. How to read the date

- Press button B to display the date.
- The date icon  indicates that you are in date mode.
- You can illuminate the display for a short time with the EL backlight by pressing button A.
- The date can be displayed as MM/DD or DD/MM. See section 6 “How to set the date” to change your preference.
- The display will change back to time mode after a short time.

Number mode



Date icon


Pattern mode



December 5th  
(12 / 05)

### 3. How to check the alarm time

- Press button B twice to display the alarm time.
- The alarm mode icon  indicates that you are in alarm mode.




10:20 PM (alarm on)



Pattern mode



06:30 AM (alarm on)

## 4. How to use the stopwatch

- Press button B three times to display the stop watch.
- The stopwatch icon  indicates that you are in stopwatch mode.
- Press button A to start & stop the timer.
- Hold button A for 3 seconds to reset the timer.
- The maximum timer is: 12hrs 59 mins & 59 secs



## 5. How to set the time

- When the time is displayed, press and hold button B for 3 seconds to enter setting mode.

\*Note after 10 seconds of inactivity setting mode will deactivate

### I. Setting the hour

- The current hour will be flashing.
- Press button A to increase the hour.
- Press button B to confirm.

08 hours

Note: In [12hr] mode the PM icon will show for PM times.



### II. Setting the minutes

- The current minutes will be flashing.
- Press button A to increase the minutes.  
(Hold A to increase quickly)
- Press button B to confirm.

23 minutes



### III. Setting 12/24 Hour Mode

- The display will flash the current hour mode (12 or 24)
- Press button A to change the hour mode.
- Press button B confirm.



12 hour mode




24 hour mode



## IV. Setting the display mode

- The current display mode will be shown.
- Press button A to change the display mode.
- Press button B to confirm & finish.



Number mode

Pattern mode



Animation mode

## 6. How to set the date

- When the date is displayed, press and hold button B for 3 seconds to enter date setting mode.

\*Note after 10 seconds of inactivity setting mode will deactivate

### I. Setting the year

- The year will flash when you are in year setting.
- Press button A to increase the year as required.  
(Hold A to increase quickly)
- Press button B to confirm.

### II. Setting the month

- The date mode icon will be displayed and the month will flash when you are in month setting.
- Press button A to increase the month as required.
- Press button B to confirm.

### III. Setting the date

- The date mode icon will be displayed and the date will flash when you are in date setting.
- Press button A to increase the date as required.  
(Hold A to increase quickly)
- Press button B to confirm.

## IV. Setting the date layout

- The current date layout mode will flash.
- Press button A to change the date layout.
- Press button B to confirm & finish.



MM.DD



DD.MM

## 7. How to set the alarm


- When the alarm time is displayed, press and hold button B for 3 seconds to enter alarm setting mode.

\*Note after 10 seconds of inactivity setting mode will deactivate

- The alarm mode icon indicates that you are in alarm setting mode.
- Press button A to turn the alarm ON or OFF. The alarm on icon will light up when the alarm is on.
- Press button B to confirm.
- The alarm hour will be flashing.
- Press button A to increase the alarm hour as required.
- Press button B to confirm.
- The alarm minutes will be flashing.
- Press button A to increase the alarm minutes as required.
- Press button B to confirm and finish.

09:30 PM (alarm on)

Note: In [12hr] mode the PM icon will show for PM times.



## 8. User information

### I. Battery

- This watch uses a CR2025 replaceable watch battery.
- Battery lifetime will vary depending on use, but is estimated to last for at least one year.
- To maximize battery life you should limit use of the EL backlight.

### II. Warranty

- This watch is covered by a 1 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

### III. Caution

- This watch is water resistant to 3ATM. Please do not use the watch in the shower, for swimming or for other water related activities.

## SPECIFICATIONS

Case Material	Stainless Steel
Strap Material	Stainless Steel
Case Dimensions	39 mm x 45 mm x 11.5 mm
Finish	Polished
Maximum Fit Wrist Size	210mm (approx.)
Weight	105g
Display	LCD with EL backlight
Battery	CR2025
Water Resistance	3ATM