




Change the way you think about time

# ZONE

## INSTRUCTION MANUAL



# 1. How to read the time

- This watch uses an LCD “always on” display to show the time.
- The digits are displayed in hexagonal shapes, starting with the hours at the top, minutes in the center and second at the bottom.
- The hexagon on the right of the display shows fractions of seconds.

Example 1:  
08:50:36

Hours: 08

Minutes: 50

Seconds: 36

fractions of seconds:



Digits:



Example 2:  
12:47:09



## 2. Operating the basic functions

### I. Turning on the backlight

- You can illuminate the display for a short time with the EL backlight by pressing button A.
- This function works best at night time.


### II. How to read the date

- Press button B to display the date. The date icon indicates that you are in date mode.
- The date is displayed in the same way as the time, with the month at the top, the date in the center and the year at the bottom.

Example 1:

May 23rd 2012

month .....  
date .....  
date indicator .....  
Year .....



Example 2:

February 9th  
2012



Example 3:

June 1st  
2012



- The display will change back to time mode after a short time.

### III. How to check the alarm time


- Press button B twice to display the alarm time.
- The alarm mode icon indicates that you are in alarm mode.
- The alarm on/off icon indicates that the alarm is either on or off.
- The display will change back to time mode after a short time.

Example 1:

alarm time: 06:20 AM

alarm off

month .....  
date .....  
alarm on indicator .....  
AM indicator .....  
alarm indicator .....



Example 2:

alarm time: 07:15 AM

alarm off



Example 3:

alarm time: 03:45 PM

alarm on



### 3. How to set the time and animation

- Press and hold button A for 3 seconds to enter setting mode.

Note: after 7 seconds of inactivity setting mode will deactivate.

#### I. Setting the hour

- The time icon and hour digits will flash when you are in hour setting mode.
- The AM/PM icon in setting mode indicates that you are setting the time in AM or PM.
- Press button B to increase the hours as required.
- Hold button B to increase the hours more quickly.

Example: 5:17 PM

hour setting



- Press button A to confirm and move to minutes.

Note: after 7 seconds of inactivity setting mode will deactivate.

## II. Setting the minutes

- The time icon and the minute digits will flash when you are in minute setting mode.
- Press button B to increase the minutes as required.
- Hold button B to increase the minutes more quickly.

Example: 5:19 PM  
hour setting

time indicator  
blinking .....

minutes blinking .....



button A

button B

- Press button A to confirm and move to seconds.

Note: after 7 seconds of inactivity setting mode will deactivate.

## III. Setting the seconds

- The time icon and the seconds digits will flash when you are in seconds setting mode.
- Press button B to set the seconds to zero.

time indicator  
blinking .....

seconds blinking .....



button A

button B

- press button A to confirm and move to fractions of seconds setting.

Note: after 7 seconds of inactivity setting mode will deactivate.

## IV. Turning fractions of seconds on / off

- You can choose to have fractions of seconds on or off when the time is shown
- Press button B to turn fractions of seconds on or off.



- press button A to confirm and move to animation setting.  
Note: after 7 seconds of inactivity setting mode will deactivate.

## V. Setting the animation

- This watch has an animation feature. When set, the animation will appear every 15 minutes between 6pm to midnight and shows the hexagons move around the screen.

Example: animation on

Hexagon ..... animating



- Press button B to turn the animation on or off.
- In setting mode, when the animation is on, the hexagons move around the screen.
- In setting mode, when the animation is off, all the hexagons blink.
- Press button A to confirm and exit setting mode.



## 4. How to set the date

- Press button B to display the date.
- Press and hold button A for 3 seconds to enter date setting mode.

Note: after 7 seconds of inactivity setting mode will deactivate.


### I. Setting the year

- The date icon and the year digits will flash when you are in setting mode.
- Press button B to increase the year as required.
- Hold button B to increase the years more quickly.

Example : 2012  
years setting

date indicator  
blinking

years blinking



- Press button A to confirm and move to the month.

Note: after 7 seconds of inactivity setting mode will deactivate.


### I. Setting the month

- The date icon and the month digits will flash when you are in month setting mode.
- Press button B to increase the month as required.
- Hold button B to increase the month more quickly.

Example : August  
month setting

month blinking

date indicator  
blinking



- Press button A to confirm and move to date.

Note: after 7 seconds of inactivity setting mode will deactivate.


### III. Setting the date

- The date icon and the date digits will flash when you are in date setting mode.
- Press button B to increase the date as required.
- Hold button B to increase the date more quickly.

Example : August 20th  
month setting

date blinking

date indicator  
blinking



- Press button A to confirm and exit setting mode.

Note: after 7 seconds of inactivity setting mode will deactivate.

## 5. How to set the alarm time


- Press button B twice to display the alarm time.

Note: after 7 seconds of inactivity setting mode will deactivate.

### I. Turning the alarm on or off

- Press button A to turn the alarm on or off. The alarm icon indicates that the alarm is on.

Example 1: alarm on  
alarm on/off setting



Example 2: alarm off  
alarm on/off setting



- Hold button A for 3 seconds to enter alarm setting mode.  
Note: after 7 seconds of inactivity setting mode will deactivate.

## II. Setting the alarm hour

- The alarm icon and the hour digits will flash.
- The AM / PM icon in setting mode indicates that you are setting the alarm time in AM or PM.
- Press button B to increase the hour as required.
- Hold button B to increase the hours more quickly.

Example: 07:00 am alarm on



- press button A to confirm and move to alarm minutes.  
Note: after 7 seconds of inactivity setting mode will deactivate.

## III. Setting the alarm minutes

- The alarm icon and the minute digits will flash.
- Press button B to increase the minutes as required.
- Hold button B to increase the minutes more quickly.

Example: 07:09 am alarm on



- Press button A to confirm and exit setting mode.  
Note: after 7 seconds of inactivity setting mode will deactivate.

## 8. User information

### I. Battery

- This watch uses a CR2032 replaceable watch battery.
- Battery lifetime will vary depending on use, but is estimated to last for at least one year.
- To maximize battery life you should limit use of the EL backlight.

### II. Warranty

- This watch is covered by a 1 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

### III. Caution

- This watch is water resistant to 3ATM. Please do not use the watch in the shower, for swimming or for other water related activities.

## SPECIFICATIONS

Case Materials	Stainless Steel
Strap Materials	Stainless Steel
Case Dimensions	39 x 45.5 x 10.5 mm
Finish	brushed
Maximum Fit Wrist Size	210mm (approx.)
Weight	140g
Display	LCD with EL backlight
Battery	CR2025
Water Resistance	3ATM

