

FLOATING OASIS SAFETY INFORMATION FOR PROPER USE

- Your Floating Oasis is designed to be used in a large body of water with a minimum depth of 10 feet. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- This product is NOT recommended for use on land or in swimming pools.
- The Floating Oasis is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. This product does not have any braking or steering devices. Persons who use this product assume all risk of injury.
- The Floating Oasis is designed for stable, anchored flotation. It should never be towed, pushed or pulled by any type of watercraft. Towing the pad is dangerous and could also cause damage to the product.
- Never jump from a boat, dock, or other high surface onto the Floating Oasis due to the risk of injury and / or damage to the product.
- Once you find a safe location to place your Floating Oasis, attach the tether directly to your own mooring or anchor. If you plan to leave the Floating Oasis in the water for an extended period during the day, we strongly recommend attaching a highly-visible buoy and / or flags to mark your position (not included).
- The Floating Oasis is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal flotation device life vest before entering the water.
- Do not fall asleep on the Floating Oasis, as drowning may occur.
- We do not recommend children playing on the Floating Oasis without adult supervision.
- Never use the Floating Oasis while under the influence of alcohol or drugs.
- Never use the Floating Oasis while tired or fatigued. Used extreme caution while swimming between the shore and the Floating Oasis. Do not attempt to swim this distance if you are tired or fatigued.
- Never enter the water or play on the Floating Oasis alone.
- The Floating Oasis will support up to 1,500 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the Floating Oasis. Do not dive from the Floating Oasis.
- Never use the Floating Oasis in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect pad, tethers, elastic cords, anchors and hardware before each use.
- If the Floating Oasis is anchored, precautions should be taken to eliminate activities that could cause entanglement in the rope and / or anchoring device.
- The Floating Oasis should always be kept visible on the water. Even though the pad is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the Floating Oasis during low light conditions such as storms or non-daylight hours.
- Always secure the Floating Oasis from unauthorized or unsupervised use. Remove the Floating Oasis from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR FLOATING OASIS

- The Floating Oasis is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your Floating Oasis it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the Floating Oasis from the water and let dry, then roll and secure using the straps. Store in a location protected from the elements away from the shore.



ULTIMATE FLOATING OASIS SAFETY INFORMATION FOR PROPER USE

- Your Ultimate Floating Oasis is designed to be used in a large body of water with a minimum depth of 10 feet. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- This product is NOT recommended for use on land or in swimming pools.
- The Ultimate Floating Oasis is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. This product does not have any braking or steering devices. Persons who use this product assume all risk of injury.
- The Ultimate Floating Oasis is designed for stable, anchored flotation. It should never be towed, pushed or pulled by any type of watercraft. Towing the pad is dangerous and could also cause damage to the product.
- Never jump from a boat, dock, or other high surface onto the Ultimate Floating Oasis due to the risk of injury and / or damage to the product.
- Once you find a safe location to place your Ultimate Floating Oasis, attach the tether directly to your own mooring or anchor. If you plan to leave the Ultimate Floating Oasis in the water for an extended period during the day, we strongly recommend attaching a highly-visible buoy and / or flags to mark your position (not included).
- The Ultimate Floating Oasis is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal flotation device life vest before entering the water.
- Do not fall asleep on the Ultimate Floating Oasis, as drowning may occur.
- We do not recommend children playing on the Ultimate Floating Oasis without adult supervision.
- Never use the Ultimate Floating Oasis while under the influence of alcohol or drugs.
- Never use the Ultimate Floating Oasis while tired or fatigued. Used extreme caution while swimming between the shore and the Ultimate Floating Oasis. Do not attempt to swim this distance if you are tired or fatigued.
- Never enter the water or play on the Ultimate Floating Oasis alone.
- The Ultimate Floating Oasis will support up to 1,500 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the Ultimate Floating Oasis. Do not dive from the Ultimate Floating Oasis.
- Never use the Ultimate Floating Oasis in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect pad, tethers, elastic cords, anchors and hardware before each use.
- If the Ultimate Floating Oasis is anchored, precautions should be taken to eliminate activities that could cause entanglement in the rope and / or anchoring device.
- The Ultimate Floating Oasis should always be kept visible on the water. Even though the pad is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the Ultimate Floating Oasis during low light conditions such as storms or non-daylight hours.
- Always secure the Ultimate Floating Oasis from unauthorized or unsupervised use. Remove the Ultimate Floating Oasis from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR ULTIMATE FLOATING OASIS

- The Ultimate Floating Oasis is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your Ultimate Floating Oasis it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the Ultimate Floating Oasis from the water and let dry, then roll and secure using the straps. Store in a location protected from the elements away from the shore.



PERSONAL FLOATING OASIS SAFETY INFORMATION FOR PROPER USE

- Your Personal Floating Oasis is designed to be used in a large body of water or swimming pool with a minimum depth of 4 feet. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- This product is NOT recommended for use on land.
- The Personal Floating Oasis is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. This product does not have any braking or steering devices. Persons who use this product assume all risk of injury.
- The Personal Floating Oasis should never be towed, pushed or pulled by any type of watercraft. Towing is dangerous and could also cause damage to the product.
- Never jump from a boat, dock, land, or other high surface onto the Personal Floating Oasis due to the risk of injury and / or damage to the product.
- If you plan to leave the Personal Floating Oasis in the water for an extended period during the day, we strongly recommend attaching a highly-visible buoy and / or flags to mark your position (not included), especially in a large body of water.
- The Personal Floating Oasis is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal flotation device life vest before entering the water.
- Do not fall asleep on the Personal Floating Oasis, as drowning may occur.
- We do not recommend children playing on the Personal Floating Oasis without adult supervision.
- Never use the Personal Floating Oasis while under the influence of alcohol or drugs.
- Never use the Personal Floating Oasis while tired or fatigued. Used extreme caution while swimming between the shore and the Personal Floating Oasis. Do not attempt to swim this distance if you are tired or fatigued.
- Never enter the water or play on the Personal Floating Oasis alone.
- The Personal Floating Oasis will support up to 250 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the Personal Floating Oasis. Do not dive from the Personal Floating Oasis.
- Never use the Personal Floating Oasis in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect pad before each use.
- The Personal Floating Oasis should always be kept visible on the water. Even though the pad is brightly colored, additional visibility such as buoys and / or flags may be needed, especially in a large body of water.
- Never store or use the Personal Floating Oasis during low light conditions such as storms or non-daylight hours.
- Always secure the Personal Floating Oasis from unauthorized or unsupervised use. Remove the Personal Floating Oasis from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR PERSONAL FLOATING OASIS

- The Personal Floating Oasis is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your Personal Floating Oasis it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the Personal Floating Oasis from the water and let dry, then store in a location protected from the elements.



FLOATION IQ

H WATER HAMMOCK SAFETY INFORMATION FOR PROPER USE

- Your H Water Hammock is designed to be used in a large body of water or swimming pool with a minimum depth of 4 feet. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- This product is NOT recommended for use on land.
- The H Water Hammock is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. This product does not have any braking or steering devices. Persons who use this product assume all risk of injury.
- Never jump from a boat, dock, diving board, or other high surface onto the H Water Hammock due to the risk of injury and / or damage to the product.
- The H Water Hammock is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal floatation device life vest before entering the water.
- Do not fall asleep on the H Water Hammock, as drowning may occur.
- We do not recommend children playing on the H Water Hammock without adult supervision.
- Never use the H Water Hammock while under the influence of alcohol or drugs.
- Never use the H Water Hammock while tired or fatigued. Use extreme caution while swimming between the shore and the H Water Hammock. Do not attempt to swim this distance if you are tired or fatigued.
- Never enter the water or play on the H Water Hammock alone.
- The H Water Hammock will support up to 250 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the H Water Hammock.
- Never use the H Water Hammock in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect the H Water Hammock before each use.
- The H Water Hammock should always be kept visible on the water. Even though the product is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the H Water Hammock during low light conditions such as storms or non-daylight hours.
- Always secure the H Water Hammock from unauthorized or unsupervised use. Remove the H Water Hammock from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR H WATER HAMMOCK OASIS

- The H Water Hammock is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your H Water Hammock it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the H Water Hammock from the water and let dry, then store in a location protected from the elements.



LIBATION FLOATATION STATION SAFETY INFORMATION FOR PROPER USE

- Your Libation Floatation Station is designed to be used in a large body of water or swimming pool. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- The Libation Floatation Station is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. Persons who use this product assume all risk of injury.
- Never jump from a boat, dock, or other high surface onto the Libation Floatation Station due to the risk of injury and / or damage to the product.
- The Libation Floatation Station is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal flotation device life vest before entering the water.
- We do not recommend children playing with the Libation Floatation Station without adult supervision.
- Never use the Libation Floatation Station while under the influence of alcohol or drugs.
- The Libation Floatation Station will support up to 75 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the Libation Floatation Station.
- Never use the Libation Floatation Station in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect the Libation Floatation Station before each use.
- The Libation Floatation Station should always be kept visible on the water. Even though the product is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the Libation Floatation Station during low light conditions such as storms or non-daylight hours.
- Always secure the Libation Floatation Station from unauthorized or unsupervised use. Remove the Libation Floatation Station from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR LIBATION FLOATATION STATION

- The Libation Floatation Station is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your Libation Floatation Station it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the Libation Floatation Station from the water and let dry, then store in a location protected from the elements.



PERSONAL LIBATION FLOATATION STATION SAFETY INFORMATION FOR PROPER USE

- Your Personal Libation Floatation Station is designed to be used in a large body of water or swimming pool. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- The Personal Libation Floatation Station is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. Persons who use this product assume all risk of injury.
- The Personal Libation Floatation Station is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal flotation device life vest before entering the water.
- We do not recommend children playing with the Personal Libation Floatation Station without adult supervision.
- Never use the Personal Libation Floatation Station while under the influence of alcohol or drugs.
- The Libation Floatation Station will support up to 2 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the Personal Libation Floatation Station.
- Never use the Personal Libation Floatation Station in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect the Personal Libation Floatation Station before each use.
- The Personal Libation Floatation Station should always be kept visible on the water. Even though the product is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the Personal Libation Floatation Station during low light conditions such as storms or non-daylight hours.
- Always secure the Personal Libation Floatation Station from unauthorized or unsupervised use. Remove the Libation Floatation Station from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR PERSONAL LIBATION STATION

- The Personal Libation Floatation Station is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your Libation Floatation Station it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the Personal Libation Floatation Station from the water and let dry, then store in a location protected from the elements.



PERSONAL KICKBOARD TRAINER SAFETY INFORMATION FOR PROPER USE

- Your Personal Kickboard Trainer is designed to be used in a large body of water or swimming pool. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- This product is NOT recommended for use on land.
- The Personal Kickboard Trainer is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. Persons who use this product assume all risk of injury.
- Never jump from a boat, dock, or other high surface onto the Personal Kickboard Trainer due to the risk of injury and / or damage to the product.
- The Personal Kickboard Trainer is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal floatation device life vest before entering the water.
- We do not recommend children playing on the Personal Kickboard Trainer without adult supervision.
- Never use the Personal Kickboard Trainer while under the influence of alcohol or drugs.
- Never use the Personal Kickboard Trainer while tired or fatigued.
- Never enter the water or play on the Personal Kickboard Trainer alone.
- The Personal Kickboard Trainer will support up to 25 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the Floating Oasis.
- Never use the Personal Kickboard Trainer in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect the Personal Kickboard Trainer before each use.
- The Personal Kickboard Trainer should always be kept visible on the water. Even though the Personal Kickboard Trainer is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the Personal Kickboard Trainer during low light conditions such as storms or non-daylight hours.
- Always secure the Personal Kickboard Trainer from unauthorized or unsupervised use. Remove the Personal Kickboard Trainer from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Do not eat, consume, or ingest the any part of this item.

CARE AND MAINTENANCE OF YOUR PERSONAL KICKBOARD TRAINER

- The Personal Kickboard Trainer is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your Personal Kickboard Trainer it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the Personal Kickboard Trainer from the water and let dry, then store in a location protected from the elements.



HYDRAPONG SAFETY INFORMATION FOR PROPER USE

- Your HydraPong is designed to be used in a large body of water or swimming pool. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- The HydraPong is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. Persons who use this product assume all risk of injury.
- Never jump from a boat, dock, or other high surface onto the HydraPong due to the risk of injury and / or damage to the product.
- The HydraPong is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal flotation device life vest before entering the water.
- We do not recommend children playing on the HydraPong without adult supervision.
- Never use the HydraPong while under the influence of alcohol or drugs.
- Never use the HydraPong while tired or fatigued.
- Never enter the water or play on the HydraPong alone.
- The HydraPong will support up to 50 lbs. of evenly distributed weight. Do not exceed the recommended weight.
- Do not swim or play under the HydraPong.
- Never use the HydraPong in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect the HydraPong before each use.
- The HydraPong should always be kept visible on the water. Even though the HydraPong is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the HydraPong during low light conditions such as storms or non-daylight hours.
- Always secure the HydraPong from unauthorized or unsupervised use. Remove the HydraPong from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Not intended for children. Adult supervision is required at all times.
- Do not eat, consume, or ingest the any part of this item.

CARE AND MAINTENANCE OF YOUR HYDRAPONG

- The HydraPong is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your HydraPong it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the HydraPong from the water and let dry, then store in a location protected from the elements.



H₂O 3-IN-A-ROW SAFETY INFORMATION FOR PROPER USE

- Your H₂O 3-In-A-Row is designed to be used in a large body of water or swimming pool. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- The H₂O 3-In-A-Row is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. Persons who use this product assume all risk of injury.
- Never jump from a boat, dock, or other high surface onto the H₂O 3-In-A-Row due to the risk of injury and / or damage to the product.
- The H₂O 3-In-A-Row is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal floatation device life vest before entering the water.
- We do not recommend children playing with the H₂O 3-In-A-Row without adult supervision.
- Do not use the H₂O 3-In-A-Row game pieces as individual floatation devices.
- Never use the H₂O 3-In-A-Row while under the influence of alcohol or drugs.
- Never use the H₂O 3-In-A-Row while tired or fatigued.
- Never enter the water or play on the H₂O 3-In-A-Row alone.
- The H₂O 3-In-A-Row will not support up any additional weight, this is not a personal floatation device.
- Do not swim or play under the H₂O 3-In-A-Row.
- Never use the H₂O 3-In-A-Row in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect the H₂O 3-In-A-Row before each use.
- The H₂O 3-In-A-Row should always be kept visible on the water. Even though the H₂O 3-In-A-Row is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the H₂O 3-In-A-Row during low light conditions such as storms or non-daylight hours.
- Always secure the H₂O 3-In-A-Row from unauthorized or unsupervised use. Remove the H₂O 3-In-A-Row from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Not intended for children below the age of 5. Adult supervision is required at all times.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR H₂O 3-IN-A-ROW

- The H₂O 3-In-A-Row is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your H₂O 3-In-A-Row it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the H₂O 3-In-A-Row from the water and let dry, then store in a location protected from the elements.





OBJECT OF THE GAME
Be the first player to
get 3-In-A-Row!


HOW TO PLAY

Decide who will make the first move on the board. Traditionally, the first player goes with "X" but the players can decide which symbol they prefer. After the first player places their piece on the board the second player will place their piece. The two players will alternate taking turns until one of the players has reached 3-In-A-Row!

HOW TO WIN

A win can be achieved either—

- A) Horizontally
- B) Vertically
- C) Diagonally



BATTLEPONG SAFETY INFORMATION FOR PROPER USE

- Your BattlePong is designed to be used in a large body of water or swimming pool. Place it in an area away from boat traffic and free of obstructions, including but not limited to, docks, pilings, weeds, logs, sandbars, rocks or other objects.
- The BattlePong is to be used for recreational purpose only. Use of this product involves inherent risks of personal injury. Persons who use this product assume all risk of injury.
- Never jump from a boat, dock, or other high surface onto the BattlePong due to the risk of injury and / or damage to the product.
- The BattlePong is not intended as a floatation device for poor swimmers – it is recommended that all users wear an approved US Coast Guard personal floatation device life vest before entering the water.
- We do not recommend children playing with the BattlePong without adult supervision.
- Do not use the BattlePong game pieces as individual floatation devices.
- Never use the BattlePong while under the influence of alcohol or drugs.
- Never use the BattlePong while tired or fatigued.
- Never enter the water or play on the BattlePong alone.
- The BattlePong will not support any additional weight, this is not a personal floatation device.
- Do not swim or play under the BattlePong.
- Never use the BattlePong in rough surface conditions, during storms or when there is lightning. If an unexpected storm arises, seek shelter on shore immediately.
- Inspect the BattlePong before each use.
- The BattlePong should always be kept visible on the water. Even though the BattlePong is brightly colored, additional visibility such as buoys and / or flags may be needed.
- Never store or use the BattlePong during low light conditions such as storms or non-daylight hours.
- Always secure the BattlePong from unauthorized or unsupervised use. Remove the BattlePong from the water when not in use to avoid unsupervised or unauthorized use. Do not leave on the water year-round.
- Not intended for children. Adult supervision is required at all times.
- Do not eat, consume, or digest the any part of this item.

CARE AND MAINTENANCE OF YOUR BATTLEPONG

- The BattlePong is made from cross-linked polyethylene foam and does not require any other floatation device or air, so set up and maintenance are simple.
- Use a sponge to easily wipe clean of any foreign materials that could scuff or tear the surface.
- As with all products, to protect the surface skin and color, it is recommended to reduce exposure to direct UV sun light for extended periods of time. UV rays are damaging to the surface and could cause fading and hazing of the surface if left in sunlight for weeks at a time. To prolong the life and look of your BattlePong it needs to be kept dry and protected from direct sunlight when not in use.
- For long storage periods, remove the BattlePong from the water and let dry, then store in a location protected from the elements.



BATTLEPONG PLAYING INSTRUCTIONS



PREPARE FOR BATTLE

You and your opponent are facing each other, with the game board in front of each other. Place your fleet of 4 ships on your side of the grid*. Ships can be placed vertically, horizontal, or diagonally. Once you have your fleet positioned, place a cup in each opening and fill with water.

For an added challenge, do not use cups and leave the fleet openings open.

*Your fleet will naturally drift and move when playing in the pool or lake.

HOW TO PLAY

Determine two teams consisting of 1-4 players. Decide who will fire the first shot to initiate the battle. You and your opponent will alternate turns, one shot per turn to try and hit each other's fleet.

IT'S A SHOT!

If you sink a shot that hits a ship, your opponent removes the cup from their ship.

SINKING SHIP

Once all of the cups have been removed from your opponent's ship they must announce which ship has been sunk.

BATTLEPONG WINNER

If you are the first to sink your opponent's entire fleet, you win the battle!