



Rev. 12/12/18

Electrical/Shipping Certification Form for Destroyit® 4606/4108 High Capacity Shredder

Please note that we cannot ship the equipment until this form is completed and returned to MBM.
(Fax to: 843-552-2974, attn: Customer Service Department).

POWER REQUIREMENTS:

1. 208/230 VAC, 50/60 HZ, 3-Phase STABLE VOLTAGE
_____ customer initials. **PHASE CONVERTER STRICTLY PROHIBITED. VOIDS ALL WARRANTY.**

2. 20 Amp circuit breaker with outlet for a type L15/20-220V plug

Please indicate the measured no-load voltage at the electrical connection intended for the shredder:

A-B _____ A-C _____ B-C _____ A-ground _____ B-ground _____ C-ground _____

Machines may be hard-wired to a circuit breaker. The power cord is 12 AWG (3 conductors and 1 ground).

SHIPPING REQUIREMENTS:

All elevators/doors must accommodate the following weights and dimensions:

4606. Shipping weight: 715 lbs. Dimensions (D x W x H): 35" x 37" x 75" (crated) / 30" x 29" x 67" (uncrated).

4108. Shipping weight: 957 lbs. Dimensions (D x W x H): 75" x 39" x 65" (crated) / 65" x 27" x 57" (uncrated).

Please indicate door openings the shredder will pass through (W x H): _____

Shipping address:

Company name: _____

Address: _____

City: _____ State: _____ Zip: _____

Special requirements: _____

I understand the electrical and shipping requirements for this paper shredder and hereby certify that our facility meets these requirements.

Customer name: _____ Title _____

Signature: _____ Date _____

IMPORTANT:

The 4606/4108 shredders are engineered to shred only the types of material listed in the product descriptions contained in MBM Corporate communications. The shredding of unapproved material will void warranty. They are not designed to be used in any type of mobile shredding activities and doing so will also void warranty.

Proper oiling of the cutting shafts is imperative for the correct operation of the machine. It is the customer's responsibility to ensure that the machine is properly oiled. Note: 4108 shredder is equipped with an auto oiler.

Cannot be used with phase converter.

_____ customer initials.

SELLING DEALER:

I have checked the requirements for this paper shredder and confirm that the facility listed above meets these requirements. I have also requested the customer to check the TIP & TELL indicator upon receipt.

Dealer name: _____

Sales/service person name: _____ Title _____

Signature: _____ Date _____

INSTALLING DEALER:

I have checked the requirements for this paper shredder and confirm that the facility listed above meets these requirements. I have also requested the customer to check the TIP & TELL indicator upon receipt.

Dealer name: _____

Sales/service person name: _____ Title _____

Signature: _____ Date _____

MBM Corporation is not responsible for any charges incurred as a result of incorrect electrical or shipping information. Additional charges may apply for special handling.