

• In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl recommends an inspection every 12 months and after any exceptional event in the life of the product.  
 • PPE inspection should be conducted with the manufacturer's Instructions for Use.  
 Download the instructions at [PETZL.COM](https://www.petzl.com).

# PROGRESS CAPTURE PULLEY

## User information

Surname

Address

Identifier

## PPE information

Model

Serial number

Year of manufacture

Date of purchase

Date of first use

**Manufacturer:** Petzl, ZI Cidex 105A - 38920 Crolles - France

				<b>N/A</b>
Good condition (G)	To monitor (TM)	To repair (TR)	Do not use, retire (R)	Not applicable

### 1. Known product history

Usage conditions or exceptional event during use (examples: fall or fall arrest, use or storage at extreme temperatures, modification outside manufacturer's facilities...):

					N/A
---	---	---	---	---	-----

### 2. Preliminary observations

Verify the presence and legibility of the serial number and the CE mark.  
 Verify that the product lifetime has not been exceeded.  
 Compare with a new device to verify there are no modifications or missing elements.

### 3. Checking the attachment hole and the fixed side plate

- Check the condition of the attachment hole (marks, deformation, cracks, corrosion...).
- Check the condition of the fixed side plate (marks, deformation, cracks, corrosion).
- Check the condition of the rivets (marks, deformation, cracks, corrosion, absence of play...).

### 4. Checking the moving side plate

- Check the condition of the moving side plate (marks, deformation, dirt, cracks, wear).
- Verify that the moving side plate opens and closes properly.
- Verify that the two side plates are properly aligned when the moving side plate is closed (play).

### 5. Checking the cam

- Check the condition of the cam (marks, deformation, cracks, corrosion, absence of foreign bodies). Check that all teeth are present and check their state of wear. The teeth must not be dirty. If necessary, clean them with a brush.
  - Check the cam's rotation and the effectiveness of the return spring.
  - Verify that the cam catch is working properly.
- Only on MINI TRAXION (red catch) and MICRO TRAXION (button).

### 6. Checking the sheave

- Check the condition of the sheave (marks, deformation, cracks, corrosion, absence of foreign bodies).
- Verify that the sheave turns freely.

### 7. Progress capture pulley function check

- Install your progress capture pulley on an anchor and install a compatible rope around the sheave.
- With the cam deactivated, circulate the rope in both directions.
- With the cam activated, make sure the rope circulates in one direction and blocks in the other direction.

## Comments (detail here any defects found on the product and accomplished tasks)

### VERDICT

Product **fit** to remain in service

Product **unfit** to remain in service

Inspected by

Company

Date

Next inspection date