

• In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl recommends an inspection every 12 months and after any exceptional event in the life of the product.
 • PPE inspection should be conducted with the manufacturer's Instructions for Use.
 Download the instructions at PETZL.COM.



SCORPIO

User information

Surname

Address

Identifier

PPE information

Model

Serial number

Year of manufacture

Date of purchase

Date of first use

Manufacturer: Petzl, ZI Cidex 105A - 38920 Crolles - France

					N/A
Good condition (G)	To monitor (TM)	To repair (TR)	Do not use, retire (R)		Not applicable

1. Known product history

Usage conditions or exceptional event during use (examples: fall or fall arrest, use or storage at extreme temperatures, modification outside manufacturer's facilities...):

					N/A
-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------	-----

2. Preliminary observations

Verify the presence and legibility of the serial number and the CE mark.
 Verify that the product lifetime has not been exceeded.
 Compare with a new device to verify there are no modifications or missing elements.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

3. Identify your lanyard model (SCORPIO 50-100 kg / SCORPIO 40-120 kg)

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

4. Checking the condition of the lanyard arms

- Remove the carabiners and STRINGS from the different arms.
- Look for wear and damage due to use (cuts, fuzziness, signs of chemicals...).
- Move the connectors to inspect the hidden parts.
- Check the condition of the safety stitching on both sides. Look for any threads that are loose, worn, or cut.
- Check the condition of the point where the lanyard arms attach to the energy absorber. SCORPIO 50-100 kg: Metal ring (nicks, wear, cracks, deformation...). SCORPIO 40-120 kg: Textile loop (cuts, fuzziness, sings of chemicals...). SCORPIO 40-120 kg: Swivel (nicks, wear, cracks, deformation...).

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

5. Checking the condition of the energy absorber

- Check the condition of the pouch. Look for wear and damage due to use (cuts, fuzziness, signs of chemicals...).
- Open the pouch and pull out the energy absorber.
- Look for wear and damage due to use (cuts, fuzziness, signs of chemicals...).
- Verify that the absorber retainer is present. SCORPIO 50-100 kg: plastic retainer (if absent do not replace with a cable tie). SCORPIO 40-120 kg: cable tie.
- Check the condition of the safety stitching on both sides. Look for any threads that are loose, worn, or cut.
- Verify that the energy absorber has not sustained an impact load (verify that none of the fabric between the straps has been torn).

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

6. Checking the condition of the attachment loop

- Look for wear and damage due to use, especially at the girth hitch (cuts, fuzziness, signs of chemicals...).
- Put the energy absorber back in the pouch and close it.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

7. Checking the condition of the lanyard end connectors

- For connector inspection, see the inspection form for your connector model at Petzl.com.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

8. Checking the protection elements

- Check the condition of the STRINGS.
- Reinstall the STRINGS on the arms.
- Reinstall the connectors.
- Verify that the connector/sling/STRING assembly is correct.
- Verify that the STRING correctly positions the connector.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

Comments (detail here any defects found on the product and accomplished tasks)

VERDICT

Product **fit** to remain in service

Product **unfit** to remain in service

Inspected by

Company

Date Next inspection date