



• In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl recommends an							
inspection every 12 months and after any exceptional event in the life of the product.							
<ul> <li>PPE inspection should be conducted with the manufacturer's Instructions for Use.</li> </ul>							
Download the instructions at PETZL.COM.							

## MICROFLIP

User information **PPE** information Surname Model Address Serial number Year of manufacture Date of purchase Identifier Date of first use Manufacturer: Petzl, Zl Cidex 105A - 38920 Crolles - France X ⊗• 🔂  $\oslash$ Q N/A To repair (TR) Do not use, retire (R) Good condition (G) To monitor (TM) Not applicable 1. Known product history Usage conditions or exceptional event during use (examples: fall or fall arrest, use or storage at extreme temperatures, modification outside manufacturer's facilities...) : Q ☆ ⊗•7  $\oslash$ N/A 2. Preliminary observations Verify the presence and legibility of the serial number and the CE mark.
Verify that the product lifetime has not been exceeded. · Compare with a new device to verify there are no modifications or missing elements. 3. Inspecting the rope clamp • Check the condition of the rope clamp using the corresponding inspection procedure form. Dismantling/removing the rope clamp from the lanyard is not necessary for inspection. 4. Checking the rope terminations Check the condition of the protective sheaths (cracks, deformation...). . Move the sheaths to check the condition of the attachment holes and of the visible part of the cable (fraying, wear, cracks, deformation, corrosion...). 5. Inspecting the reinforced rope • Check the condition of the sheath over the full length of the rope (cuts, wear, burns, fuzzy areas or signs of chemicals...). • Do a tactile inspection over the full length of the reinforced rope to check for any sign of cable deterioration (broken areas, swelling, soft spots...). • If necessary, remove the rope and replace it with a Petzl replacement reinforced lanyard for MICROFLIP. Follow the installation instructions in the Instructions for Use provided with the replacement lanyard. 6. Function check

• Install your lanyard on an anchor at very low height; carry out the following checks with your feet on the ground.

• Verify that shortening the lanyard goes smoothly.

• Pulling back on the lanyard, verify that there is no slippage.

Comments (detail here any defects found on the product and accomplished tasks)						
VERDICT			Inspected by			
	Product <b>fit</b> to remain in service	C	Company			
	Product <b>unfit</b> to remain in service	D	Date		Next inspection date	