

Boat's Name: \_\_\_\_\_ Length: \_\_\_\_\_ Model: \_\_\_\_\_

Name: \_\_\_\_\_

Address: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_

Phone: \_\_\_\_\_ Email: \_\_\_\_\_

## ENGINE ROOM

### ENGINE(S)

- Fill fuel tanks and add stabilizer to gasoline
- Change oil and filter
- Change fuel filters/separators in engine(s)
- Check coolant level in freshwater-cooling system and add coolant if necessary
- Run antifreeze through raw-water-cooling system
- Make sure water strainers are filled with antifreeze
- Fog cylinders in gasoline engines
- Top up battery electrolyte level and put batteries on marine charger

### INSTALLED GENERATOR

- Change oil and filter
- Change fuel filters/separators
- Check coolant level in freshwater-cooling system and add coolant if necessary
- Run antifreeze through raw-water-cooling system
- Make sure water strainers are filled with antifreeze

### OTHER SYSTEMS

- Flush and fill air conditioning and refrigeration system with antifreeze
- Run antifreeze through watermaker and pickle as per owner's manual

## OUTBOARDS

- Fill installed fuel tanks and add stabilizer
- Flush engine with muffs and fresh water.
- Turn off fuel supply and fog while running (Note that some newer outboards have an automatic winterizing feature)
- Drain gear case and add fresh lubricant
- Store unit in lowest position
- Inspect/replace anodes
- Empty fuel from portable 4-stroke tanks into car tank and take them home for storage

## OUTDRIVES

- If water intake is in lower unit, flush and run antifreeze through using muffs
- Drain gear oil and add fresh lubricant
- Inspect/replace anodes

## BELOW DECKS

- Pump out holding tank and add antifreeze to head
- Drain water heater and bypass it
- Drain freshwater system and run antifreeze through it
- Run antifreeze through live well, deck washdown pump, etc., per owner's manual
- Drain shower sump and other places where water pools
- Remove food
- Open lockers to air
- Take home cushions or store on their sides
- Take home portable electronics
- Close propane valves and take home portable canisters
- Verify bilge pump and switch operate properly
- Clean and dry bilges
- Secure all ports and hatches
- Turn off all circuit breakers except for bilge pump and smoke/vapor alarms

## IN THE WATER

- Close all seacocks except for cockpit drains
- Plug exhaust ports
- Check docklines and chafe guards – center boat in slip
- Add or adjust fenders for proper placement

## BEFORE YOU GO

- Tie off tiller/steering wheel
- Cover/shrinkwrap boat
- Lock cabin and leave spare key with marina manager