

# PULSAR 510 DL LITE AUTO-DRAW VAPE PEN | MANUAL

# SPECS:

Size: 4.6 x 0.8 x 0.8 inches (116 x 20 x 20mm)

Maximum Cartridge Size: 0.4 inches (11.5mm) diameter, 2.3 inches (59mm) length

Battery Capacity: 320mAh

Voltage: 3.6V Charging: USB-C Resistance: <0.8 Ω

#### POWER ON/OFF:

Quickly pull - draw in air - from mouthpiece 5 times to switch the power on or off. The light will flash once.

#### CHARGING:

Blue light on - Charging Light off - Fully Charged Light will flash 3 times when disconnected from USB

#### LOW BATTERY:

Blue light will flash 10 times to alert user to low battery, and will then enter standby. Charge before continuing use.

### PROTECTION FEATURES:

Battery life/cartridge protection: After 10 continuous seconds of use, the blue light will flash 2 times, and the automatic vape time cutoff will activate, turning off the heat (but not the power). Over-voltage/short-circuit protection: blue light will come on for 2 seconds, and device will fully turn off.

# KIT INCLUDES:

1 x Pulsar 510 DL Battery 1 x Bottom Magnetic Connector

## HOW TO USE:

- 1. Make sure that the bottom magnetic connector is properly connected to the bottom of the unit. The battery will not charge if the bottom connector is not attached.
- 2. Attach battery to USB-C cable and connect to a power source. You will see the light flash once when the battery is connected.
- 3. Allow the battery to fully charge before first use. The light will turn blue while charging and turn off when fully charged.
- 4. Remove the bottom magnetic connector and firmly screw in the 510 threaded cartridge of your choice.
- 5. Insert the cartridge into the device and ensure that the bottom magnetic connector is properly connected. Blue light will turn on for 1 second.
- 6. If the unit is powered off, place your lips on the mouthpiece and give it 5 quick pulls to power on.
- 7. Simply pull from mouthpiece to activate the cartridge vapor and enjoy your session!

#### **CLEANING INSTRUCTIONS:**

- 1. Remove the bottom magnetic connector from the battery portion.
- 2. Wipe the outside and inside portion of the bottom magnetic connector with an isopropyl alcohol pad. Use an alcohol swab to wipe any excess oil out of the 510 screw-in connector.
- 3. To clean the inside air pathway, use an alcohol-soaked swab. Using a circular motion, work your way up and down the air pathway until you do not see any more oil on the swab.
- 4. Do not submerge any part of the device in cleaning solution. Allow all parts to air dry prior to resuming use.

IMPORTANT SAFETY WARNINGS

• Do not expose to extreme temperatures or direct sunlight.

• Do not drop the device or accessories.

Do not drop or submerge in any liquid.Do not modify the electronics in any way.

• This device is intended for adults only. Do not sell or provide to minors. Keep all parts, concentrates, herbs, and liquids away from children and pets. This is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, personal injury, and may void warranty.

The mouthpiece is NOT removable. Attempting to remove it could impair or permanently disable the breath control functionality.

U-0578-23