

Using the Pulsar® APX Volt

1. Turn the unit on by pressing the button rapidly 5 times.
2. Press the fire button 2 times quickly to cycle through preset voltages. Desired voltage level is set when LED stops flashing.
3. Remove mouthpiece and place product inside quartz dish.
4. Do not overfill. 1/4 gram max is suggested.
5. Hold fire button until product is melted to prime concentrate.
6. At this point the Volt is ready for use.
7. Hold power button and inhale to receive preferred amount of vapor.
6. Turn the unit off by pressing the button rapidly 5 times.

Important Safety Warnings:

Do not expose to extreme temperature or direct sunlight. Do not drop the Pulsar® APX Volt or accessories. Do not drop or submerge in any liquid. Do not modify the electronics in any way. Only charge using Pulsar® brand chargers and Pulsar® brand accessories. Pulsar® APX Volt is intended for adults only. Do not sell or provide to minors. Keep all parts, concentrates, herbs, and liquids away from children and pets. Pulsar® APX Volt is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, or personal injury.

Limited Warranty:

Pulsar® APX Volt is guaranteed from manufacturer defects or malfunction from the original date of purchase for a period of 1 year. This limited warranty protects against manufacturer defects under normal use and does not apply to normal wear and tear, improper use, and accidental damage from dropping or submerging in liquid, improper cleaning, neglect, or any other damage that is not a result of defective materials or workmanship. If your Pulsar® APX Volt qualifies for servicing, we will repair or replace, at our discretion and expense, any defective parts or materials. Purchaser must provide a copy of the original dated sales receipt and may be required to provide shipping to return defective parts or materials. We intend to complete all repairs/replacements within 7 business days, although this timeframe may vary depending on shipping, replacement part availability, or other related factors. The lawful and proper use of this device is a condition of sale. Any improper use of the Pulsar® APX Volt will void the warranty. Warranty is non transferable. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state

For warranty servicing, contact us at:
www.PulsarVaporizers.com

PULSAR®
ENJOY HIGHER CULTURE™

www.PulsarVaporizers.com

Manufactured By Pulsar®
Asheville, NC 28806



USER MANUAL

Thank you for purchasing the Pulsar® APX Volt! In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in injury and may void your warranty.

HELPFUL TIPS:

Once the product is loaded into the quartz cup, heat until fully melted. This primes product for optimal use and flavor.

Do not overfill. Generally, 1/4 gram of concentrate is the max fill.

Wipe quartz cup clean with cotton swab between each session to maintain flavor.

Do not turn Volt on its side or upside down when concentrate is heated. It can spill, and can cause injury as well as waste product.

Be sure to turn off the unit when finished by pressing the ON/OFF button 5 times.

KIT CONTENTS:

APX Volt Vaporizer Battery
Borosilicate Mouthpiece
Quartz Cup Chamber Atomizer
Silicone Container 32mm
Micro USB Charging Cable
Wax Tool

TECH SPECS:

- Battery Size: 30.8mm x 22.2mm x 53.25mm
- Input: DC.5V, 1A
- Battery Capacity & Output: 1100mAh Lithium Battery
- Atomizer Resistance: 0.4Ω
- Pure Quartz Cup Chamber
- Heating time: 5 seconds
- Voltage Settings: 2.5V / 2.8V / 3.2V / 3.7V
- Micro USB Charging Port
- 5-Minute Safety Auto Shut Off
- Battery Recharge Cycle count: 300+

CHARGING INSTRUCTIONS

IMPORTANT:

You will need to fully charge your Pulsar® APX Volt before using it. Insert charging cable into unit & the other end into a dedicated USB port or wall socket if using AC wall adapter (Not Included). Set Pulsar® APX Volt on its side – do not let unit dangle from charge cord. This puts pressure on the charger plug that can result in the unit not charging fully. When it is time to recharge the unit after use, allow to cool, and remove the wax atomizer before laying the unit on its side to charge. This will help keep your concentrates in place.

- Battery Charge Time: Allow approximately 1.5 hours for the first full charge. Do not charge for more than 24 hours.
- Battery Charging: Battery indicator light will show charging connection is made by pulsing red.
- Low Battery Indication: When the battery requires charging, the battery icon will show red and will not heat.
- The Pulsar® APX Volt battery will deliver approximately 1.5 hours of continuous power, depending on use. Both the battery and chargers are designed to prevent overcharging. ONLY USE APPROVED PULSAR® CHARGERS! Failure to do so can damage the battery, which can result in property damage or personal injury and may void the warranty.