



Thank you for purchasing the Pulsar® Elite Series Mini eNail Kit to vaporize waxy concentrates! In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in damage or injury and may void your warranty.

#### WARNING:

Use with caution. Must be 18 years of age or older to operate. Coil element becomes extremely hot. Do not touch once powered on. Do not leave unattended while powered on. Do not attempt to change the shape of the already formed coil in any way. Do not leave the unit on for longer than 5 continuous hours. Do not let any liquids, waxes or gels touch coil. Do not use a temperature setting higher than  $1200\,^\circ\text{F}$ . Do not customize or modify unit internally or externally. Failure to follow cautionary tips may void warranty.

### This Kit Includes:

- Pulsar® Elite Series Mini eNail Power and Temperature Control Box with Digital Screen
- Accommodates 20mm Nails
- 5ft. Removable Power Cord
- 4ft. Heating Coil Cord
- Grade 2 Titanium 10/14/19mm Universal Nail
- Titanium Carb Cap

# Technical Specifications:

Digital Display with Push Button Controls Rear On/Off Switch Temperature: 0°F-1200°F Voltage: 90-150v Power: 150w



#### PLEASE NOTE:

Make sure the coiled heater fits over your nail.

If the coll fits too tightly into the nail, do not force it. Instead unscrew the dish, insert into the coil and reassemble.

Plug the coiled heater into the control box.

Plug power cord Into the control box and connect to a power outlet.

Carefully fit and insert nail into chosen glass concentrate rig. Make sure all water and nail assemblies are well matched and securely placed for use.

Press the power switch on the back of the control box to turn the unit ON/OFF.

## How to Set Temperature:

Use the up and down arrows to set the desired temperature. Unit has a temp range of 0°F to 1200°F.

Hold the button down to increase number changing speed.

The numbers will flash ten times indicating desired temperature is set. Place desired concentrate onto the unit and inhale gently, cover the nail with provided carb cap as needed.

**WARNING**: Coil and Nail will get extremely hot during operation. Allow to completely cool before touching.



### Important Safety Warnings

Do not expose to extreme temperature or direct sunlight. Do not drop the unit or accessories. Do not submerge in any liquid. Do not modify the electronics in any way. Please allow the full cool down time between cycles or cleaning. Pulsar® Elite Series eNoils and accessories are intended for adults only. Do not sell, provide or allow access to minors, Keep all parts, concentrates, herbs, and liquids away from children and pets. Pulsar® products are not medical devices and are not intended to diagnose, freat, mitigate, cure or prevent any aliment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage or personal injury.

#### Limited Warranty

The Pulsarii Elite Series Is guaranteed from manufacturer defects or malfunction from date of purchase for a period of 6 months for the heating cord. and 1 year for the control box. This limited warranty protects against manufacturer defect under normal use and does not apply to normal wear & tear; Improper use; occidental damage from dropping or submerging in liquid; Improper cleaning; neglect; or any other damage finat is not a result of defective materials or workmanship. If your Pulsarii Elite Series qualifies for servicing, we will repair or replace, at our discretion and expense, any defective ports or materials. Purchaser must provide a copy of the original dated sales receipt and may be required to provide shipping to return defective parts or materials. We intend to complete all repairs/replacements within 7 business days, although this timeframe may vary depending on shipping, replacement part availability, or other related factors. The lawful and proper use of this device is a condition of sale. Any improper use of the Pulsarii Elite series will void the warranty, Warranty is non-transferable. This warranty gives you specific legal rights, and you may also have other rights within vary from state to state.

Important Note: All nails are disposable attachments. Once a nail is used, no warranty coverage or replacement will be affered.

For warranty servicing, contact us at: www.PulsarVaporizers.com