



WAX/SMOKER USER MANUAL

Thank you for purchasing the Pulsar® Go Series Wax/Smoker! In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in injury and may void your warranty.

HELPFUL TIPS:

- Before using you Go Series Wax/Smoker, first, fully charge the unit, and then heat the atomizers several times empty. This will burn off any impurities collected during manufacturing.
- To load the herb atomizer, place ground herb directly onto the Ceramic Power Pad, prior to heating. Fill about halfway up. Once loaded, begin heating, and observe the amount of smoke inside the glass chamber to gauge the size cloud you would like to inhale.
- To load the wax atomizer, you can place your concentrate directly on the cool quartz coils, prior to heating; or, you can prime your coils by gently pre-heating them, and placing your concentrate on the slightly warmed coils. Once loaded, begin heating, and observe the amount of vapor inside the glass chamber to gauge

- the size cloud you would like to inhale.
- For both herb and wax atomizers, after pressing, and holding the button for the initial heating time of 5 seconds, release the button, and then instantly, press again, for 3 seconds and repeat. This technique of pulsing the atomizers, simulates “stoking” the material, like a traditional pipe. Always allow atomizer to reheat for 5 seconds after having completely cooled.
- Be sure to turn off the unit when you are done by pressing the on/off button 5 times.

KIT CONTENTS:

- Wax/Smoker Unit
- Glass Mouthpiece
- 1x Herb Replaceable Atomizer
- 1x Wax Replaceable Atomizer
- Micro USB Charging Cable
- Cleaning Brush
- Wax Tool
- USB Cable
- Silicone Container

TECH SPECS:

- Input: 5V/1A
- Battery Capacity: 1100mAh
- Battery Output: 30W
- Wax Atomizer Resistance: 0.7Ω (Pure Quartz Chamber - Triple Quartz Coil)
- Herb Atomizer Resistance: 0.5Ω (Pure Quartz Chamber - Ceramic Power Pad)
- Heating time: 5 seconds
- Temperature Range: 932°F-1112°F
- Temperature Indicator
 - Red Light: Heating up
 - Green Light: Device ready
- Micro USB Charging Port
- 5-Minute Safety Auto Shut Off
- Battery Recharge Cycle count: 300+
- Battery Charge Indicator

CHARGING INSTRUCTIONS:

- Battery Power & Charging Indicator
 - Green Light: 100%
 - Yellow Light: 70%
 - Red Light: 30%
 - Light glows Red while charging, turning to Green when fully charged.

IMPORTANT: You will need to fully charge your Pulsar® Go Series Wax/Smoker before using it. Insert charging cable into unit & the other end into a dedicated USB port or wall socket if using AC wall adapter (Not Included). Set Pulsar® Go Series Wax/Smoker on its side – do not let unit dangle from charge cord. This puts pressure on the charger plug that can result in the unit not charging fully.

- **Battery Charge Time:** Allow approximately 1.5 hours for the first full charge. Do not charge for more than 24 hours.
- **Battery Charging:** Battery indication light will show charging connection is made by glowing Red. When fully charged, light turns to Green.

The Pulsar® Go Series Wax/Smoker battery will deliver approximately 1.5 hours of continuous power, depending on use. Both the battery and chargers are designed to prevent overcharging. **ONLY USE APPROVED PULSAR® CHARGERS!** Failure to do so can damage the battery, which can result in property damage or personal injury and may void the warranty.

Using the Pulsar® Go Series Wax/Smoker

1. Load the chamber.
2. Turn the unit on by pressing the button rapidly 5 times. Light will flash Green 3 times to confirm it is powering on.
3. The unit will begin heating immediately after the button is pressed and held. The LED light will turn from Red to Green as the unit reaches the desired temperature (5 seconds).
 - After the initial heating, you can press, or pulse the button, and the atomizers will heat almost instantaneously.
4. Release the button to halt the heating process as the smoke builds inside the glass mouthpiece.
5. Inhale.
6. Turn the unit off by pressing the button rapidly 5 times.

Important Safety Warnings:

Do not expose to extreme temperature or direct sunlight.

Do not drop the Pulsar® Go Series Wax/Smoker or accessories.

Do not drop or submerge in any liquid.

Do not modify the electronics in any way.

Only charge using Pulsar® brand chargers and Pulsar® brand accessories.

Pulsar® Go Series Wax/Smoker is intended for adults only.

Do not sell or provide to minors.

Keep all parts, herbs, and liquids away from children and pets.

Pulsar® Go Series Wax/Smoker is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, or personal injury.

Limited Warranty:

Pulsar® Go Series Wax/Smoker is guaranteed from manufacturer defects or malfunction from the original date of purchase for a period of 1 year. This limited warranty protects against manufacturer defects under normal use and does not apply to normal wear and tear, improper use, and accidental damage from dropping or submerging in liquid, improper cleaning, neglect, or any other damage that is not a result of defective materials or workmanship. If your Pulsar® Go Series Wax/Smoker qualifies for servicing, we will repair or replace, at our discretion and expense, any defective parts or materials. Purchaser must provide a copy of the original dated sales receipt and may be required to provide shipping to return defective parts or materials. We intend to complete all repairs/replacements within 7 business days, although this timeframe may vary depending on shipping, replacement part availability, or other related factors. The lawful and proper use of this device is a condition of sale. Any improper use of the Pulsar® Go Series Wax/Smoker will void the warranty. Warranty is nontransferable. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

For warranty servicing, contact us at:
www.PulsarVaporizers.com

PULSAR®
ENJOY HIGHER CULTURE™

www.PulsarVaporizers.com
Manufactured By Pulsar®
Asheville, NC 28806