



This is a guide to replacing a broken spark plug boot for your WEN 56380i Inverter Generator. This guide is best used in conjunction with the 56380i manual, included as a physical copy with your unit and available on the WEN website page for the 56380i (link [here](#)), by clicking “Click here to view the product manual”.

If at any point you need assistance, have questions, or want to order parts, call WEN customer service at 1-800-232-1195, M-F, 8-5 Central Time, or email techsupport@wenproducts.com.

If replacing any parts, use only genuine replacement parts purchased from WEN Products. Use of replacement parts not sold by WEN Products will void your warranty and could lead to decreased performance or injury.

TABLE OF CONTENTS

Tools needed	1
Replacing the broken spark plug boot	1

TOOLS NEEDED

- Pair of pliers
- Phillips-head screwdriver

ENSURE THAT THE ENGINE IS COOL BEFORE BEGINNING ANY MAINTENANCE OR REPAIR WORK. FOLLOW ALL SAFETY PROCEDURES LISTED IN YOUR OWNER’S MANUAL. USE COMMON SENSE. AVOID INJURY.

REPLACING THE BROKEN SPARK PLUG BOOT

1. Make sure the engine is cool.	
2. Use the Phillips-head screwdriver to remove the two screws shown at right.	
3. Remove the panel.	
4. Locate the spark plug boot. Move the ignition coil (with spark plug boot still attached) out of the way.	

5. Use a pair of pliers to remove the broken part of the spark plug boot from the spark plug. Pull it outwards, away from the engine.

6. Make sure the ignition coil is easily accessible.



7. Use one hand to hold the ignition coil wiring steady. Twist the spark plug boot off the ignition coil (counterclockwise).



8. Twist the new spark plug boot onto the ignition coil (clockwise) until it is tight. While holding the wiring, tug the spark plug boot sideways to see if it loosens. If so, tighten the boot more. It should not move when tugged.

9. Push the boot onto the spark plug. Re-assemble the side panel. Check to make sure the generator starts up properly.

QUESTIONS? PROBLEMS?

Contact WEN Customer Service at 1-800-232-1195, M-F, 8-5 CST, or email techsupport@wenproducts.com