# PERFECT Lite/Lite Advanced

The PERFECT saddle stool has an ergonomic design that promotes a natural S curve of the spine and an optimal active seating position. This active way of sitting enhances the circulation. The saddle stool makes it possible to easily move around your workplace.

### Description

Seat height	46-85 cm	
Seat dimensions	32x39 cm	
Gas spring options	3	
Alternative castors	Yes	
Base diameter	50 cm	
Adjustable seat	Yes, 15°	
Upholstery	Scandinavian leather, vinyl or fabric	
Weight	8 kg	
Max. load	120 kg	
Warranty	5 years	

### Accessories

Foot ring	Foot rest while working in high chair positions
Foot control	Foot operated height adjustment
SWING arm rest	Arm rest that doubles as a back and abdominal support. Can swivel 360° for complete freedom and versatility
Lumbar support	Provides adjustable lumbar support



### Seat Heights

User height	Gas spring	Seat height	Seat height with SWING
< 160 cm	Short	46-60 cm	51-62 cm
160-175 cm	Standard	52-71 cm (Standard)	57-73 cm
> 175 cm	High	59-85 cm	64-87 cm



## Key Features

#### Mechanism

Two lever spring adjusted mechanism allows for adjustable height and up to 15° lateral movement.

#### Seat

Unisex mould with recyclable polymer frame.

#### Padding

Upholstered with injection moulded polyurethane foam, recyclable when using a certain process.

#### Upholstery

Our standard vinyl contains 100% polyurethane with cotton and polyester backing. It is PVC and Phthalate free. It is also OEKO-TEX certified, which means that the upholstery is easy to clean, and resistant to disinfectants and common cleaning product.

#### Gas spring

Columns are available in three sizes. The spring is made of polished steel in Germany using nitrogen, a sustainable gas existing in 78% of normal air. Gas springs are maintenance-free and recyclable.

#### Base

Polished recyclable aluminium.

#### Castors

Cores are made from polyamide 6 and tread is made of recyclable polyurethane. (Note: larger castor base is required when using SWING support arm).

