



vth range

Oil Free Air Compressors

ultra quiet air

Model								
VTH75	L/Min	Ltrs	Bar	kW HP	Volts/Hz	dB(A)	KG	CM-hxwx d
	120	24	8	0.55 0.75	220-240/50	72	32	62x68x28
VTH75D	L/Min	Ltrs	Bar	kW HP	Volts/Hz	dB(A)	KG	CM-hxwx d
	120	24	8	0.55 0.75	220-240/50	72	43	63x68x40
FAD	1 Bar	2 Bar	3 Bar	4 Bar	5 Bar	6 Bar	7 Bar	8 Bar
L/Min	108	96	85	74	65	57	48	45

-40°C Dewpoint based on 50% duty cycle

Quality is the primary component built into each Bambi VT Oil free compressor.

Our VTH range uses the proven Vee Twin pump unit found in all other VT applications and mounts it on two different horizontal receivers for applications where a vertical model would be too tall.

Model								
VTH150	L/Min	Ltrs	Bar	kW HP	Volts/Hz	dB(A)	KG	CM-hxwx d
	175	50	8	1.1 1.5	220-240/50	74	41	69x84x28
VTH150D	L/Min	Ltrs	Bar	kW HP	Volts/Hz	dB(A)	KG	CM-hxwx d
	175	50	8	1.1 1.5	220-240/50	74	52	69x84x44
FAD	1 Bar	2 Bar	3 Bar	4 Bar	5 Bar	6 Bar	7 Bar	8 Bar
L/Min	159	153	142	130	119	110	99	96

-40°C Dewpoint based on 50% duty cycle

The VTH has the same advanced technical features as its vertical siblings, including a soft start solenoid valve to protect the compressor from overload, internally coated receivers to ensure that the air is contamination free and high quality components to ensure an extended service life and low maintenance. Every model is available with our innovative air drier with after-cooler designed to deliver a -40°C Dewpoint for “desert dry” air – with an integral coalescing filter to collect and remove water droplets as small as 0.01 microns.

Model								
VTH200	L/Min	Ltrs	Bar	kW HP	Volts/Hz	dB(A)	KG	CM-hxwx d
	220	50	8	1.5 2.0	220-240/50	74	46	69x84x28
VTH200D	L/Min	Ltrs	Bar	kW HP	Volts/Hz	dB(A)	KG	CM-hxwx d
	220	50	8	1.5 2.0	220-240/50	74	57	69x84x44
FAD	1 Bar	2 Bar	3 Bar	4 Bar	5 Bar	6 Bar	7 Bar	8 Bar
L/Min	193	178	164	150	142	130	122	116

-40°C Dewpoint based on 50% duty cycle

Bambi Air Compressors are made with pride in Birmingham, West Midlands – we have a fine heritage of compressor manufacture for applications that require the highest possible air quality for critical applications. Our central base is ideal for distribution across the UK, with next day delivery possible on all models from our range and a fully comprehensive after-sales range of spares.

Every VTH compressor is protected by a comprehensive warranty extending to 5 years for the air receiver and 2 years for the compressor pump (subject to terms).



VTH75D



VTH150D



VTH200D

