Versa Lift Mounted Wall Switch Control Kit

MOUNTED WALL SWITCH CONTROL KIT INSTRUCTIONS:

To avoid system malfunction, DO NOT connect these controls to the power head until you complete all steps in the <u>Versa Lift Installation</u>
<u>Guide up to and INCLUDING Steps 8.1 thru 9.1!</u>

* * THEN FOLLOW THESE INSTRUCTIONS * *

9.3. Mounted Wall Switches Control Kit Contents:

- Non-Locking Switch Plate (1)
- Key-Locking Switch Plate (1)
- 6-32 x 1/2" Flat Head Phillips Screws (4)
- Wall Plates with Screws, White (2)
- 10-ft. Upstairs Control Cord (1)
- 50-ft. Downstairs Control Cord (1)

9.4. Install the Non-Locking Wall Switch Upstairs Plug the 10-ft control cord into the non-locking switch plate. Install the non-locking switch plate into an single

plate. Install the non-locking switch plate into an single gang wall box **upstairs** using two 6-32 x ½" flat head phillips screws (Fig. 1a). Tighten the screws lightly!

9.4. Install the Key-Locking Wall Switch Downstairs Plug the 50-ft control cord into the key-locking switch plate. Install the key-locking switch plate into a single gang wall box **downstairs** using two 6-32 x ½" flat head

phillips screws (Fig. 1b). Tighten the screws gently!

9.6. Plug in the Upstairs Wall Switch

Install the plug for the **upstairs** wall switch (10-ft.) control cord into the Lift Head **control port #2** (Fig. 1c).

9.7. Plug in the Downstairs Wall Switch

Install the plug for the **downstairs** wall switch (50-ft.) control cord into the Lift Head **control port #1** (Fig. 1c).

