

SUGGESTED LAUNDERING INSTRUCTIONS

WASH, DRY,
CHANGE,
REPEAT.

Our sheets were designed to look
AHHmazing every time.



COMPHY

Developed for Spa. Designed for Ahh.

SUGGESTED LAUNDERING INSTRUCTIONS

MICROFIBER TWILL PRODUCTS | PROGRAMMABLE MACHINES

BREAK/SUDS CYCLE	10 minutes	Hot water (160°)	Low water level	Alkali at 1500-2000 ppm
RINSE 1	2 minutes	Hot water (140°)	High level	
RINSE 2	2 minutes	Warm water (120°)	High level	
RINSE 3	2 minutes	Warm water	High level	
FINAL RINSE	4 minutes	Cold water	Low level	Sour to appropriate pH levels
EXTRACT	1 or 2 minutes	Slow speed		

DRYING 15 minutes at medium heat (130-140°). After 5 minute cool down, remove from dryer immediately.

IRONING/FOLDING If sheets are folded promptly after dryer removal, they should not need to be pressed.
If you use an ironer, we recommend a temperature of 340° and suggested speed of 110 FPM.
Variations (or adjustments) may be necessary depending on humidity, time of year, equipment, etc.

FOR OPTIMAL RESULTS:

Use water-soluble massage oil, lotion, or cream.

Laundry products in a full load and do not use bleaches.

Wash as soon as possible. If you cannot wash right away, place soiled goods in plastic bags to keep the air from oxidizing the spa oils.

Wash in high temperatures of 160-170° with high levels of alkalinity.

Using solvents in addition to a high temperature alkaline bath is helpful.

Please contact customer service regarding any laundry concerns at CustomerService@comphy.com.

For information about Comphy's limited product warranty, please visit www.Comphy.com or contact us at: (323) 225-8234

All measurements are based on 100 lbs of washer capacity.